

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-1 A/P DISENG Annunciators (Glareshield)****22-10-1-1**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative.

NOTE:

1. RNP APCH (LNAV or LNAV/VNAV or LPV) operations permitted.
2. LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Autopilot Disengage Annunciators in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the Flight Guidance Control Panel on the glareshield.
2. Make appropriate entry in the aircraft journey log.

— — — —**ISS III R05****APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49**22-10-1. 1**

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-1 A/P DISENG Annunciators (Glareshield)****22-10-1-2**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided autopilot is not used.

NOTE:

1. One must be operative for RNP APCH (LNAV or LNAV/VNAV or LPV) operations.
2. LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Autopilot Disengage Annunciators in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the Flight Guidance Control Panel on the glareshield.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R05**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-2 Autopilot****22-10-2-1 Autopilot**

Interval	Installed	Required	Procedure
B	1	0	NIL

Any mode functioning normally may be used.

NOTE:

- Must be operative for RNP APCH (LNAV or LNAV/VNAV or LPV) and CAT II operation.
- LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Autopilot in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard inoperative Autopilot in the flight compartment.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R05**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-2 Autopilot****22-10-2-2 Autopilot Pitch Trim System (AP PITCH TRIM FAIL)**

Interval	Installed	Required	Procedure
B	1	0	NIL

May be inoperative provided:

- a) Manual pitch trim is operative,
- b) Autopilot is considered inoperative and not used, and
- c) Flap Auto Pitch Trim (AUTO TRIM FAIL) is considered inoperative and not used.

NOTE: Must be operative for CAT II operation.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Autopilot in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- 1. Placard inoperative Autopilot in the flight compartment.
- 2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-3 Tactile Control Steering (TCS) Switches****22-10-3-1**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative TCS switch(es) must be placarded on the control column handwheel(s).

Operating Procedures

None required.

Maintenance Procedures

1. Label relevant TCS switch(es) as "INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-3 Tactile Control Steering (TCS) Switches****22-10-3-2**

Interval	Installed	Required	Procedure
D	2	1	NIL

May be inoperative on the pilot not flying side.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative TCS switch(es) must be placarded on the control column handwheel(s).

Operating Procedures

None required.

Maintenance Procedures

1. Label relevant TCS switch(es) as "INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-3. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-4 Flight Guidance Control Panel (FGCP)****22-10-4-1**

Interval	Installed	Required	Procedure
C	1	1	NIL

Individual modes of operation may be inoperative provided that heading bugs, nav source selectors and course selection functions are operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative flight guidance control panel indicators must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Label relevant inoperative switches/controls/indicators on flight guidance control panel as "INOP".
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-4 Flight Guidance Control Panel (FGCP)****22-10-4-2 Flight Guidance Control Panel Indicators (AP, HIS SEL only)**

Interval	Installed	Required	Procedure
C	4	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative flight guidance control panel indicators must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Label relevant inoperative switches/controls/indicators on flight guidance control panel as "INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-4. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-5 Yaw Damper System**

Interval	Installed	Required	Procedure
B	1	0	(M)

May be inoperative.

NOTE:

1. Autopilot will not be available.
2. Cat II operation not permitted.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Yaw Damper/Actuator must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Pull and clip circuit breakers: YD AU (E3); APAU ROLL (E2); APAU PITCH (E1); on the avionics circuit breaker panel.
2. Placard "AP/YD INOP" on flight guidance control panel.
3. If the Y/D actuator has failed, a rudder travel check should be made to confirm full rudder movement using the PFCS Indicator on the MFD. If the Y/D actuator has failed in a position other than the center position (ie. Failed in an extended or retracted position), the Y/D actuator must be replaced prior to dispatch.
4. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-6 A/P DIS Switches****22-10-6-1**

Interval	Installed	Required	Procedure
B	2	0	(M)

May be inoperative provided the Autopilot is considered inoperative and not used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Control Wheel Disengage Switch/Switches must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard Control wheel Switch on control wheel/wheels. Placard Flight Guidance Controller (Autopilot Switch) on glareshield panel if both switches are inoperative.
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-6. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-6 A/P DIS Switches****22-10-6-2**

Interval	Installed	Required	Procedure
C	2	1	NIL

One may be inoperative provided:

- The Autopilot is not used below 1,000 ft. AGL,
- Approach minimums do not require the use of the autopilot, and
- The pilot flying has the operative disconnect.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Control Wheel Disengage Switch/Switches must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard Control wheel Switch on control wheel/wheels. Placard Flight Guidance Controller (Autopilot Switch) on glareshield panel if both switches are inoperative.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-6. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-7 Go-Around (GA) Switches****22-10-7-1**

Interval	Installed	Required	Procedure
C	2	1	(O)

One may be inoperative.

Minimum Equipment List Procedures (MELP)

Note: If one or both switches are failed in the “Failed Closed” (Continuously Signalling Go-Around) position, MEL relief is not applicable.

Placard

Inoperative “Go-Around (GA)” Switch/Switches must be placarded in the flight compartment.

Operating Procedures

Prior to first dispatch, before pressing the Go-Around (GA) switches, verify that “GO AROUND” mode is NOT annunciated in the Flight Mode Annunciator (FMA) section of the No. 1 and No 2. Primary Flight Displays (PFD). Neither “Wing LVL” nor “GA” should be annunciated.

1. If “GO AROUND” annunciation exists, one or both “GA” switches may be failed in the closed position.
2. If no “GO-AROUND” annunciation exists, press and release the operating “GA” switch and check that the “GO-AROUND” mode is annunciated in the FMA of the PFD 1 and/or 2, and that the pitch command and lateral command are set to the appropriate pitch and “WING LVL” respectively.

Maintenance Procedures

1. Placard the inoperative Go-Around switches in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DAT 0 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-7. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUTOMATIC FLIGHT CONTROL******ATA 22*****22-10-7 Go-Around (GA) Switches****22-10-7-2**

Interval	Installed	Required	Procedure
A	2	0	(O)

May be inoperative for one flight day.

Minimum Equipment List Procedures (MELP)

Note: If one or both switches are failed in the “Failed Closed” (Continuously Signalling Go-Around) position, MEL relief is not applicable.

Placard

Inoperative “Go-Around (GA)” Switch/Switches must be placarded in the flight compartment.

Operating Procedures

Prior to first dispatch, before pressing the Go-Around (GA) switches, verify that “GO AROUND” mode is NOT annunciated in the Flight Mode Annunciator (FMA) section of the No. 1 and No 2. Primary Flight Displays (PFD). Neither “Wing LVL” nor “GA” should be annunciated.

1. If “GO AROUND” annunciation exists, one or both “GA” switches may be failed in the closed position.
2. If no “GO AROUND” annunciation exists, Disengage the Autopilot using A/P pushbutton and revert to wing level (Basic mode). Manually maintain pitch at 10 deg.

Maintenance Procedures

1. Placard the inoperative Go-Around switches in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

22-10-7. 2