

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-10-1 Lavatory Smoke Detection System****26-10-1A**

Interval	Installed	Required	Procedure
C	1	0	(M)(O)

For each lavatory, where the Smoke Detector fails to test, the lavatory smoke detection system may be inoperative provided:

- Lavatory is not used by passengers for any purpose,
- Lavatory waste receptacle is empty,
- Lavatory door is locked closed and placarded INOPERATIVE - DO NOT ENTER,
- Lavatory is used only by crew members, and
- In-flight service waste bags are not stored in the lavatory.

NOTE: The above mentioned provisos are not intended to preclude crew member lavatory inspections which must be detailed in the (O) procedures.

Minimum Equipment List Procedures (MELP)**Placard**

- Inoperative Lavatory Smoke Detection System must be placarded in the flight compartment.
- Placard lavatory door "INOPERATIVE - DO NOT ENTER".

Operating Procedures

- Ensure all crew members have been briefed that the lavatory Smoke Detector is inoperative.
- Crew member to periodically inspect lavatory.

Maintenance Procedures

- Placard Lavatory Smoke Detection System in flight compartment.
- Ensure lavatory waste receptacle is empty.
- Lock lavatory door by inserting a pen or similar object in the hole located on the door slide latch and sliding it to the locked position.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-1. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-10-1 Lavatory Smoke Detection System

26-10-1A

4. Placard lavatory door "INOPERATIVE - DO NOT ENTER".
5. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-10-1 Lavatory Smoke Detection System****26-10-1B**

Interval	Installed	Required	Procedure
C	1	0	(M#)(O)

For each lavatory, where the Smoke Detector indicates a failed condition intermittently or continuously, the lavatory smoke detection system may be inoperative provided:

- Smoke detector is deactivated,
- Lavatory is not used by passengers for any purpose,
- Lavatory waste receptacle is empty,
- Lavatory door is locked closed and placarded INOPERATIVE - DO NOT ENTER,
- Lavatory is used only by crew members. And
- In-flight service waste bags are not stored in the lavatory.

NOTE: The above mentioned provisos are not intended to preclude crew member lavatory inspections which must be detailed in the (O) procedures.

Minimum Equipment List Procedures (MELP)**Placard**

- Inoperative Lavatory Smoke Detection System must be placarded in the flight compartment.
- Placard lavatory door "INOPERATIVE - DO NOT ENTER".

Operating Procedures

- Ensure all crew members have been briefed that the lavatory Smoke Detector is inoperative.
- Crew member to periodically inspect lavatory.

Maintenance Procedures

- Pull circuit breaker SMK DET LAV/CG01 on the Right Essential Bus.
- Gain access to the Lavatory Smoke Detector.
- Disconnect tape and stow Smoke Detector electrical connector.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-1. 3



DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-10-1 Lavatory Smoke Detection System

26-10-1B

4. Reset breaker SMK DET LAV/CG01 on the Right Essential Bus.
5. Placard Lavatory Smoke Detection System in flight compartment.
6. Ensure lavatory waste receptacle is empty.
7. Lock lavatory door by inserting a pen or similar object in the hole located on the door slide latch and sliding it to the locked position.
8. Placard lavatory door "INOPERATIVE - DO NOT ENTER"
9. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-1. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-10-1 Lavatory Smoke Detection System****26-10-1-1 Non-passenger Carrying Operations****26-10-1-1A**

Interval	Installed	Required	Procedure
B	1	0	(O)

For each lavatory, where the Smoke Detector fails to test, the Lavatory Smoke Detection System may be inoperative for non-passenger carrying operations provided:

- Crew members are the only occupants of the aircraft,
- Occupants are briefed as to which smoke detection system(s) is/are inoperative, and
- In-flight service waste bags are not stored in the lavatory.

NOTE: The above mentioned provisos are not intended to preclude crew member lavatory inspections which must be detailed in the (O) procedures.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Lavatory Smoke Detection System must be placarded in the flight compartment.

Operating Procedures

- Ensure all crew members have been briefed that the lavatory Smoke Detector is inoperative.
- Crew member to periodically inspect lavatory.

Maintenance Procedures

- Placard Lavatory Smoke Detection System in flight compartment.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-1. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-10-1 Lavatory Smoke Detection System****26-10-1-1 Non-passenger Carrying Operations****26-10-1-1B**

Interval	Installed	Required	Procedure
B	1	0	(M#)(O)

For each lavatory, where the Smoke Detector indicates a failed condition intermittently or continuously, the Lavatory Smoke Detection System may be inoperative for non-passenger carrying operations provided:

- Smoke Detector is deactivated,
- Crew members are the only occupants of the aircraft,
- Occupants are briefed as to which smoke detection system(s) is/are inoperative, and
- In-flight service waste bags are not stored in the lavatory.

NOTE: The above mentioned provisos are not intended to preclude crew member lavatory inspections which must be detailed in the (O) procedures.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Lavatory Smoke Detection System must be placarded in the flight compartment.

Operating Procedures

- Ensure all crew members have been briefed that the lavatory Smoke Detector is inoperative.
- Crew member to periodically inspect lavatory.

Maintenance Procedures

- Pull circuit breaker SMK DET LAV/CG01 on the Right Essential Bus.
- Gain access to the lavatory Smoke Detector.
- Disconnect tape and stow Smoke Detector electrical connector.
- Reset breaker SMK DET LAV/CG01 on the Right Essential Bus.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-1. 6



DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-10-1 Lavatory Smoke Detection System

26-10-1-1 Non-passenger Carrying Operations

26-10-1-1B

- 5. Placard Lavatory Smoke Detection System in flight compartment.
- 6. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-1. 7

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-10-2 Aft Baggage Compartment Smoke Detectors****26-10-2-1**

Interval	Installed	Required	Procedure
C	2	1	(M#)

One may be inoperative provided:

- Affected smoke detector is deactivated,
- All inlet and outlet valves are considered inoperative and deactivated in closed position,
- VENT VALVE INLT and VENT VALVE OTLT CLOSED advisory lights are verified illuminated prior to each flight, and
- Live animals are not carried.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Baggage Compartment Smoke Detector and deactivated Aft Baggage Compartment Vent Valves must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Pull appropriate circuit breaker on the R ESS Bus for the inoperative smoke detector as follows:
 - SMK DET LAV/CGO1 or
 - SMK DET BAG/CGO2.
- Disconnect tape and stow electrical connector from affected smoke detector on unit.
- Reset pulled circuit breaker on the R ESS Bus:
 - SMK DET LAV/CGO1 or
 - SMK DET BAG/CGO2.
- Pull and clip the appropriate circuit breakers on the R Main Circuit Breaker panel for the following configurations:
 - With "2" Vents installed CGO VENT VLS.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-2. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-10-2 Aft Baggage Compartment Smoke Detectors

26-10-2-1

- b) With “4” Vents installed CGO VENT VALVES 1 and CGO VENT VALVES 2.
- 5. On the Fire Protection Panel verify the following “CLOSED” advisory lights are illuminated for the following configurations:
 - a) With “2” Vents installed:
 - i. AFT BAGGAGE – VENT VALVE INLT, and
 - ii. AFT BAGGAGE – VENT VALVE OTLT.
 - b) With “4” Vents installed:
 - i. CARGO – VENT VALVE INLT 1 and 2, and
 - ii. CARGO – VENT VALVE OTLT 1 and 2.
- 6. Placard Fire Protection Panel with:
 - a) “AFT BAGGAGE SMOKE DETECTOR INOP”, and
 - b) “INLET and OUTLET VENT VALVES CLOSED”.
- 7. Make appropriate entry in journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-2. 2

DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-10-2 Aft Baggage Compartment Smoke Detectors

26-10-2-2

Interval	Installed	Required	Procedure
C	2	0	(M#)

One or more may be inoperative provided:

- a) Baggage compartment is empty, or for ballast purpose, use of bags (made of glass fiber or Kevlar) of sand or ingots of non-magnetic metals (such as lead) is acceptable, and
- b) Affected smoke detectors are deactivated.

Minimum Equipment List Procedures (MELP)

Placard

Inoperative Aft Baggage Compartment Smoke Detectors must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Pull the appropriate circuit breakers on the R ESS Bus for inoperative smoke detector as follows:
 - a) SMK DET LAV/CGO1 and/or
 - b) SMK DET BAG/CGO2.
2. Disconnect tape and stow each smoke detector electrical connector at inoperative units.
3. Reset pulled circuit breakers LAV/CGO1 on the R ESS Bus:
 - a) SMK DET LAV/CGO1 and/or
 - b) SMK DET BAG/CGO2.
4. Placard Fire Protection Panel with "AFT BAGGAGE SMOKE DETECTORS INOP".
5. Make appropriate entry in the aircraft journey log.

ISS III R00

APPROVED BY DAW DELHI, DATE 05-06-2023

Signature valid
DELHI, DATE -

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-2.3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-10-3 Forward Baggage Compartment Smoke Detector**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided the baggage compartment is empty, or for ballast purpose, use of bags (made of glassfiber or kevlar) of sand or ingots of non-magnetic metals (such as lead) is acceptable.

NOTE: Only applicable if Forward Baggage Compartment is installed.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Baggage Compartment Smoke Detectors must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Pull breaker for BAG/CGO2 (R ESSENTIAL Bus).
2. Disconnect tape and stow connector at unit.
3. Reset breaker.
4. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-10-4 APU Fire Detection System**

Interval	Installed	Required	Procedure
D	1	0	(M#)

May be inoperative provided:

- The APU fuel shut-off valve is verified closed, and
- The APU is considered inoperative and is not used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative APU Fire Detection System must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Turn all aircraft electrical power off.
- Gain access to the APU Compartment Advance Pneumatic Detector (APD) through the APU access door 312AL.
- Disconnect the electrical connector (2600-P26) from the APD.
- Using a jumper pin assembly, jumper pins C & D of 2600-P26 (Part Number MS3456KS14S-5S).
- Tape and stow electrical connector 2600-P26 (Part Number MS3456KS14S-5S).
- Cap connector 2600-J26 on the APD.
- Apply DC power to aircraft buses.
- Ensure the "CHECK FIRE DET" warning light has been extinguished in the cockpit.
- Ensure APU POWER switchlight is selected off at overhead APU Control Panel.
- Verify that APU Fuel Shut-Off Valve is closed as indicated by the white advisory light "APU FUEL VALVE CLOSED" on the fire protection panel and that the green advisory "APU FUEL VALVE OPEN" light is extinguished.
- If the "APU FUEL VALVE OPEN" light is on or if the "APU FUEL VALVE CLOSED" light is extinguished, verify that APU Fuel Shut-Off Valve is closed as follows:
 - Method A:

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-4. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-10-4 APU Fire Detection System

1. Pull and Collar L ESS BUS circuit breaker APU Fuel SOV/IND.
2. Attempt to start APU. If APU fails to start, then APU FUEL VALVE is closed.

NOTE: The APU may spin up momentarily, until residual fuel in the manifold is consumed. Also the APU FADEC may log a fault for the uncommanded shutdown/unsuccessful start.

b) Method B:

1. Open center wing dry bay access panel 521BT.
2. Verify that the position indicator arm of the APU fuel shut-off valve is in the CLOSED position.
3. Reinstall access panel 521BT.

NOTE: For instructions on removal and installation of access panel, refer to Maintenance Manual PSM 1-84-2, Chapter 57.

c) Method C:

1. Feed a borescope through the aft dry bay drain port in the LH armpit to access the dry bay area.
2. Locate the APU fuel Feed Shut-off Valve is in Closed position.
3. Verify that the INDICATOR ARM on the APU Fuel Feed Shut-off Valve is in Closed position.

12. Remove DC power from aircraft buses.

13. Placard APU Control and APU Fire Protection Panels in the flight compartment.

14. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-10-4. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-1 APU Fire Extinguishing System**

Interval	Installed	Required	Procedure
D	1	0	(M#)

May be inoperative provided the APU is considered inoperative and is not used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative APU Fire Extinguishing System must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Turn all aircraft electrical power off.
2. Gain access to the APU fire-extinguishing bottle through access door 311 AB.
3. Disconnect the electrical connector (2600-P12) from the pressure switch-gauge.
4. Using a jumper pin assembly, jumper pins A & B of 2600-P12 (Part Number MS3476L8-33SW).
5. Tape and stow connector 2600-P12 (Part Number MS3476L8-33SW).
6. Cap connector 2600-J12 on fire bottle.
7. Apply power to aircraft DC electrical bus system.
8. Ensure the 'CHECK FIRE DET' warning light has been extinguished in the cockpit.
9. Ensure APU POWER switchlight is selected off at overhead APU Control Panel.
10. Verify that APU FUEL VALVE annunciator light indicates CLOSED (white) on the APU Fire Protection Panel.
11. If APU FUEL VALVE annunciator light indicates OPEN (green) or both OPEN (green) and CLOSED (white) annunciators are extinguished, use the following procedure to confirm that the valve has closed:
 - a) Apply DC power to aircraft buses.
 - b) Pull and collar circuit breaker "APU FUEL SOV/IND" on Left Essential 28 VDC Circuit Breaker Panel.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-1. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-20-1

APU Fire Extinguishing System

- c) Attempt to start APU. If APU fails to start, then the APU fuel shutoff valve is closed.

NOTE: The APU may spin up momentarily, until residual fuel in the manifold is consumed. Also, the APU FADEC may log a fault for the uncommanded shutdown/unsuccessful start.

12. Placard APU Control and APU Fire Protection Panels in the flight compartment.

13. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-2 Lavatory Fire Extinguishing System****26-20-2A**

Interval	Installed	Required	Procedure
C	1	0	(M)(O)

For each lavatory the lavatory fire extinguishing system may be inoperative provided the lavatory smoke detection system is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Lavatory Fire Extinguisher (s) must be placarded in the lavatory and in the flight compartment.

Operating Procedures

Crew member to periodically inspect the lavatory.

Maintenance Procedures

1. Placard Lavatory Fire Extinguisher System and Lavatory Waste Receptacle.
2. Place placard in flight compartment indicating that the lavatory fire extinguishing system is inoperative.
3. Apply power to DC ESSENTIAL buses.
4. Ensure LAV/CGO1 circuit breaker on R ESSENTIAL bus is closed. Check that the green indicator light on the lavatory smoke detector illuminates.
5. Push and hold the Lavatory Smoke Detector Self Test Switch and observe the following:
 - a) Audible warning sounds from smoke detector.
 - b) A single chime on the PA system.
 - c) Red alarm indicator light on the smoke detector illuminates and the cabin red repeater lights on the exit signs illuminate.
6. Push and release the interrupt switch on the detector and observe the following:
 - a) Audible warning from the detector stops.
 - b) Cabin red repeater lights on the exit signs extinguish.
 - c) Red alarm indicator light on the smoke detector remains illuminated.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-2. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

FIRE PROTECTION

ATA 26

26-20-2 Lavatory Fire Extinguishing System

26-20-2A

7. Release the self-test switch and ensure the red warning lamp extinguishes.
8. Remove the DC power from the essential buses.
9. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-2 Lavatory Fire Extinguishing System****26-20-2B**

Interval	Installed	Required	Procedure
C	1	0	(M)(O)

For each lavatory the lavatory fire extinguishing system may be inoperative provided:

- Lavatory is not used by passengers for any purpose,
- Lavatory waste receptacle is empty,
- Lavatory door is locked closed and placarded "INOPERATIVE - DO NOT ENTER", and
- Lavatory is used only by crew members.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Lavatory Fire Extinguisher (s) must be placarded in the lavatory and in the flight compartment.

Operating Procedures

Crew member to periodically inspect the lavatory.

Maintenance Procedures

- Placard Lavatory Fire Extinguisher in flight compartment.
- Ensure lavatory waste receptacle is empty.
- Lock lavatory door by inserting a pen or similar object in the hole located on the door slide latch and sliding it to the locked position.
- Placard lavatory door "INOPERATIVE - DO NOT ENTER".
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-2. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-2 Lavatory Fire Extinguishing System****26-20-2-1 Non-passenger Carrying Operations**

Interval	Installed	Required	Procedure
B	-	0	NIL

For each lavatory the lavatory fire extinguishing system may be inoperative for non-passenger carrying operations provided:

- Crew members are the only occupants of the aircraft, and
- Occupants have been briefed as to which lavatory fire extinguishing system(s) is/are inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

- Inoperative Lavatory Fire Extinguisher(s) must be placarded in the flight compartment.
- Placard lavatory door "INOPERATIVE - DO NOT ENTER".

Operating Procedures

None required.

Maintenance Procedures

None required.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-2. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-3 Portable Fire Extinguishers**

Interval	Installed	Required	Procedure
D	4	4	(M)(O)

Any in excess of those required by regulations may be inoperative or missing provided:

- The inoperative fire extinguisher(s) is/are removed from the passenger cabin, flight deck, and its location is placarded "INOPERATIVE", or it is removed from the installed location, secured out of sight and the fire extinguisher and its installed location are placarded "INOPERATIVE".
- Required distribution is maintained in the passenger compartment and flight deck, and
- Procedures are established to alert crew of missing portable fire extinguishers.

NOTE: Required distribution is one in flight compartment and three in passenger cabin.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Portable Fire Extinguisher.

Operating Procedures

Inform all crew members of any missing Portable Fire Extinguishers.

Maintenance Procedures

- Remove and placard inoperative Portable Fire Extinguishers from flight compartment and passenger cabin or remove from aircraft and placard its installed location as "INOPERATIVE".
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-4 Baggage Compartment Fire Extinguishers****26-20-4-1 Low Rate Discharge Bottle (LRD)**

Interval	Installed	Required	Procedure
C	1	0	(M#)

May be inoperative provided the forward baggage compartment (if installed) and aft baggage compartment are empty, or for ballast purpose, use of bags (made of glass fibre or Kevlar) of sand or ingots of non-magnetic metals (such as lead) is acceptable.

Minimum Equipment List Procedures (MELP)**Placard**

Placard Fire Protection Panel in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures**One LRD Bottle installed on aircraft (Type Spec and 86 Passenger Configurations)**

1. Turn all aircraft electrical power off.
2. Gain access to the LRD fire-extinguishing bottle through access door 311 AB.
3. Disconnect the electrical connector (2600-P14) from the pressure switch.
4. Using a jumper pin assembly, jumper pins A & B of 2600-P14 (Part Number MS27467T9B98S).
5. Tape and stow connector 2600-P14 (Part Number MS27467T9B98S).
6. Cap connector 2600-J14 on fire bottle.
7. Ensure the "CHECK FIRE DET" warning light has been extinguished in the flight compartment.
8. Visually confirm that the forward baggage compartment (if installed) and aft baggage compartment are empty and placarded "INOPERATIVE – DO NOT USE".
9. Placard the Fire Protection Panel in flight compartment.
10. Make appropriate entry in the aircraft journey log.

(Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-4 Baggage Compartment Fire Extinguishers****26-20-4-1 Low Rate Discharge Bottle (LRD)****Two LRD Bottles installed on aircraft (Cargo-Combi Configuration)**

1. Turn all aircraft electrical power off.
2. Gain access to the LRD fire-extinguishing bottles 1 and/or 2 through access door 311 AB.
3. Disconnect the electrical connector (2600-P31 and/or 2600-P14) from the pressure switch.
4. Using a jumper pin assembly, jumper pins A & B of 2600-P31 and/or 2600-P14 (mating connector part number 340AS001B92N and 340FS001B92N respectively).
5. Tape and stow connectors
6. Cap connector 2600-P31 and/or 2600-J14 on fire bottle.
7. Ensure the "CHECK FIRE DET" warning light has been extinguished in the flight compartment.
8. Visually confirm that the baggage compartment is empty and placarded "INOPERATIVE – DO NOT USE".
9. Placard the Fire Protection Panel in flight compartment.
10. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-4. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-4 Baggage Compartment Fire Extinguishers****26-20-4-2 High Rate Discharge Bottle (HRD)**

Interval	Installed	Required	Procedure
C	2	0	(M#)

May be inoperative provided the associated baggage compartment is empty, or for ballast purpose, use of bags (made of glass fibre or Kevlar) of sand or ingots of non-magnetic metals (such as lead) is acceptable.

Minimum Equipment List Procedures (MELP)**Placard**

Placard Fire Protection Panel in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures**Aft HRD Bottle**

1. Turn all aircraft electrical power off.
2. Gain access to the HRD fire-extinguishing bottle through access door 311 AB.
3. Disconnect the electrical connector (2600-P13) from the pressure switch.
4. Using a jumper pin assembly, jumper pins A & B of 2600-P13 (Part Number MS27467T9B98S).
5. Tape and stow connector 2600-P13 (Part Number MS27467T9B98S).
6. Cap connector 2600-J13 on fire bottle.
7. Ensure the "CHECK FIRE DET" warning light has been extinguished in the flight compartment.
8. Visually confirm that the aft baggage compartment is empty and placarded "INOPERATIVE - DO NOT USE".
9. Placard the Fire Protection Panel in flight compartment.
10. Make appropriate entry in the aircraft journey log.

(Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-4. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FIRE PROTECTION******ATA 26*****26-20-4 Baggage Compartment Fire Extinguishers****26-20-4-2 High Rate Discharge Bottle (HRD)****Forward HRD Bottle (if forward baggage compartment is installed)**

1. Turn all aircraft electrical power off.
2. Gain access to the forward HRD fire-extinguishing bottle by removing the halon box base panel located in the forward baggage compartment.
 - a) Remove the fillet seal from all the joints and angles of the base panel.
 - b) Remove all the screws and washers that attach the base panel.
 - c) Remove the base panel from the halon box.
3. Disconnect the electrical connector (2600-P31) from the pressure switch.
4. Using a jumper pin assembly, jumper pins A & B of 2600-P31 (Part Number MS3476L8-33SW).
5. Tape and stow connector 2600-P31 (Part Number MS3476L8-33SW).
6. Cap connector 2600-J31 on fire bottle.
7. Ensure the "CHECK FIRE DET" warning light has been extinguished in the flight compartment.
8. Visually confirm that the aft baggage compartment is empty and placarded "INOPERATIVE – DO NOT USE".
9. Placard the Fire Protection Panel in flight compartment.
10. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

26-20-4. 4