

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-20-1 Pressure Refueling System****28-20-1-1 REFUEL**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided the fuel transfer system is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative REFUEL (manual pressure refueling system) is placarded in the flight compartment and on the External Refuel/ Defuel Panel.

Operating Procedures

None required.

Maintenance Procedures

1. Ensure sufficient fuel in tanks for fuel transfer.
2. Apply AC and DC power to aircraft electrical busses.
3. Ensure that the appropriate fuel system circuit breakers FUEL HLCU & REFUEL DEFUEL on L ESSENTIAL BUS, BATT REFUEL & REFUEL DEFUEL on R ESSENTIAL bus and FUEL AUX PUMP 1 & 2 on 115V AC Frequency Panel (three phase) are closed.

NOTE: During fuel transfer, the donor TANK FUEL LOW caution light may come on momentarily due to collector bay fuel level falling faster than main tank level.

4. Select the FUEL page on the MFD.
5. At the FUEL CONTROL TRANSFER panel, transfer from Tank 1 to Tank 2:
 - a) Fuel TRANSFER switch – TO TANK 2.
 - b) Check both VALVE OPEN, TO TANK 2 TRANSFER SW arrow and TANK 1 AUX PUMP indication appears on the FUEL page of the MFD, and TANK 1 AUX PUMP ON advisory light illuminates.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-20-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-20-1 Pressure Refueling System****28-20-1-1 REFUEL**

6. At completion of transfer:
 - a) Fuel TRANSFER switch – Off.
 - b) Check both VALVE CLOSED indicators appear, TO TANK 2 TRANSFER SW arrow and TANK 1 AUX PUMP indication OFF on the FUEL page of the MFD, and TANK 1 AUX PUMP ON advisory light out.
7. Transfer from Tank 2 to Tank 1:
 - a) Fuel TRANSFER switch – TO TANK 1.
 - b) Check both VALVE OPEN, TO TANK 1 TRANSFER SW arrow and TANK 2 AUX PUMP indication appears on the FUEL page of the MFD, and TANK 2 AUX PUMP ON advisory light illuminates.
8. At completion of transfer:
 - a) Fuel TRANSFER switch – Off.
 - b) Check both VALVE CLOSED indicators appear, TO TANK 1 TRANSFER SW arrow and TANK 2 AUX PUMP indication OFF on the FUEL page of the MFD, and TANK 2 AUX PUMP ON advisory light out.

NOTE:

1. Maximum fuel imbalance is indicated by the FUEL quantity readout on ED and fuel gauge pointers on FUEL page of the MFD changing from white to amber and [BALANCE] indication appears, flashing on ED.
 2. If TANK 1 QTY or TANK 2 QTY is inoperative, the [BALANCE] indication is also inoperative.
9. Remove AC and DC electrical power from aircraft.
 10. Placard Pressure Refueling System on External Refuel/Defuel Panel in rear underside of No. 2 Nacelle, also on LEFT and/or RIGHT DC CIRCUIT BREAKER panel.
 11. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-20-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-20-1 Pressure Refueling System****28-20-1-2 PRESELECT REFUEL**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided the fuel transfer system is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative PRESELECT (automatic pressure refueling system) is placarded in the flight compartment and on the External Refuel/Defuel Panel.

Operating Procedures

None required.

Maintenance Procedures

1. Ensure sufficient fuel in tanks for fuel transfer.
2. Apply AC and DC power to aircraft electrical busses.
3. Ensure that the appropriate fuel system circuit breakers FUEL HLCU & REFUEL DEFUEL on L ESSENTIAL BUS, BATT REFUEL & REFUEL DEFUEL on R ESSENTIAL bus and FUEL AUX PUMP 1 & 2 on 115V AC Frequency Panel (three phase) are closed.

NOTE: During fuel transfer, the donor TANK FUEL LOW caution light may come on momentarily due to collector bay fuel level falling faster than main tank level.

4. Select the FUEL page on the MFD.
5. At the FUEL CONTROL TRANSFER panel, transfer from Tank 1 to Tank 2:
 - a) Fuel TRANSFER switch – TO TANK 2.
 - b) Check both VALVE OPEN, TO TANK 2 TRANSFER SW arrow and TANK 1 AUX PUMP indication appears on the FUEL page of the MFD, and TANK 1 AUX PUMP ON advisory light illuminates.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-20-1. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-20-1 Pressure Refueling System****28-20-1-2 PRESELECT REFUEL**

6. At completion of transfer:
 - a) Fuel TRANSFER switch – Off.
 - b) Check both VALVE CLOSED indicators appear, TO TANK 2 TRANSFER SW arrow and TANK 1 AUX PUMP indication OFF on the FUEL page of the MFD, and TANK 1 AUX PUMP ON advisory light out.
7. Transfer from Tank 2 to Tank 1:
 - a) Fuel TRANSFER switch – TO TANK 1.
 - b) Check both VALVE OPEN, TO TANK 1 TRANSFER SW arrow and TANK 2 AUX PUMP indication appears on the FUEL page of the MFD, and TANK 2 AUX PUMP ON advisory light illuminates.
8. At completion of transfer:
 - a) Fuel TRANSFER switch – Off.
 - b) Check both VALVE CLOSED indicators appear, TO TANK 1 TRANSFER SW arrow and TANK 2 AUX PUMP indication OFF on the FUEL page of the MFD, and TANK 2 AUX PUMP ON advisory light out.

NOTE:

3. Maximum fuel imbalance is indicated by the FUEL quantity readout on ED and fuel gauge pointers on FUEL page of the MFD changing from white to amber and [BALANCE] indication appears, flashing on ED.
 4. If TANK 1 QTY or TANK 2 QTY is inoperative, the [BALANCE] indication is also inoperative.
9. Remove AC and DC electrical power from aircraft.
 10. Placard Pressure Refueling System on External Refuel/Defuel Panel in rear underside of No. 2 Nacelle, also on LEFT and/or RIGHT DC CIRCUIT BREAKER panel.
 11. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-20-1. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-20-1 Pressure Refueling System****28-20-1-3 REFUEL AND PRESELECT REFUEL**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- Fuel transfer system is verified operative, and
- Procedures are established and used for gravity refueling.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Pressure Refueling System is placarded in the flight compartment and on the External Refuel/Defuel Panel.

Operating Procedures

None required.

Maintenance Procedures

- Alternative fueling procedures are established for gravity refueling and used.
- Ensure sufficient fuel in tanks for fuel transfer.
- Apply AC and DC power to aircraft electrical busses.
- Ensure that the appropriate fuel system circuit breakers FUEL HLCU & REFUEL DEFUEL on L ESSENTIAL BUS, BATT REFUEL & REFUEL DEFUEL on R ESSENTIAL bus and FUEL AUX PUMP 1 & 2 on 115V AC Frequency Panel (three phase) are closed.

NOTE: During fuel transfer, the donor TANK FUEL LOW caution light may come on momentarily due to collector bay fuel level falling faster than main tank level.

- Select the FUEL page on the MFD.
- Transfer from Tank 1 to Tank 2:
 - Fuel TRANSFER switch – TO TANK 2.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-20-1. 5

28-20-1 Pressure Refueling System

28-20-1-3 REFUEL AND PRESELECT REFUEL

- b) Check both VALVE OPEN, TO TANK 2 TRANSFER SW arrow and TANK 1 AUX PUMP indication appears on the FUEL page of the MFD, and TANK 1 AUX PUMP ON advisory light illuminates.
7. At completion of transfer:
 - a) Fuel TRANSFER switch – Off.
 - b) Check both VALVE CLOSED indicators appear, TO TANK 2 TRANSFER SW arrow and TANK 1 AUX PUMP indication OFF on the FUEL page of the MFD, and TANK 1 AUX PUMP ON advisory light out.
8. Transfer from Tank 2 to Tank 1:
 - a) Fuel TRANSFER switch – TO TANK 1.
 - b) Check both VALVE OPEN, TO TANK 1 TRANSFER SW arrow and TANK 2 AUX PUMP indication appears on the FUEL page of the MFD, and TANK 2 AUX PUMP ON advisory light illuminates.
9. At completion of transfer:
 - a) Fuel TRANSFER switch Off.
 - b) Check both VALVE CLOSED indicators appear, TO TANK 1 TRANSFER SW arrow and TANK 2 AUX PUMP indication OFF on the FUEL page of the MFD, and TANK 2 AUX PUMP ON advisory light out.

NOTE:

1. Maximum fuel imbalance is indicated by the FUEL quantity readout on ED and fuel gauge pointers on FUEL page of the MFD changing from white to amber and the [BALANCE] indication appears, flashing on ED.
 2. If TANK 1 QTY or TANK 2 QTY is inoperative, the [BALANCE] indication is also inoperative.
10. Remove AC and DC electrical power from aircraft.
 11. Placard Pressure Refueling System on External Refuel/Defuel Panel in rear underside of No. 2 Nacelle, also on LEFT and/or RIGHT DC CIRCUIT BREAKER panel.
 12. Make appropriate entry in the aircraft journey log.

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-20-2 MASTER VALVE CLOSED Light (Refuel/Defuel Panel)**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided the REFUEL/DEFUEL SHUT-OFF VALVE is verified closed following refueling.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative MASTER VALVE CLOSED indicator light is placarded in the flight compartment and on the Refuel/Defuel Panel.

Operating Procedures

None required.

Maintenance Procedures

1. Remove the right hand nacelle access panel 423AT.
2. Visually verify the REFUEL/DEFUEL SHUT-OFF VALVE is in the closed position by the physical indication lever on the REFUEL/DEFUEL SHUT-OFF VALVE Actuator.
3. Verify no fuel leak from refuel/defuel adapter.
4. Reinstall access panel 423AT.
5. Placard on the rear underside of No. 2 Nacelle (inside External Refuel/Defuel panel) and in the flight compartment.
6. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-20-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-1 Height Measuring Unit (Magnetic Dipsticks)**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided the fuel quantity is determined by other approved means.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Height Measuring Unit (HMU) in the flight compartment and on External Refuel/Defuel Panel.

Operating Procedures

None required.

Maintenance Procedures

1. Placard on the rear underside of No. 2 Nacelle (inside External Refuel/Defuel panel) and in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-2 Fuel TANK °C Temperature Indication (on ESID)**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Fuel Tank Temperature Indication in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative Fuel Tank Temperature Indication on the ESID in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-3 FUELING ON Caution Light**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided prior to each flight:

- The REFUEL/OFF/DEFUEL switch is confirmed OFF, and
- The Refuel/Defuel access panel is verified closed.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative FUELING ON caution light must be placarded in the flight compartment.

Operating Procedures

Following each refueling, ensure that the REFUEL/OFF/DEFUEL switch on the external refuel panel is selected OFF and panel is confirmed closed.

Maintenance Procedures

- Placard FUELING ON caution light on the Caution and Warning Panel in the flight compartment.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-4 TANK 1 AUX PUMP and TANK 2 AUX PUMP
Advisory Lights**

Interval	Installed	Required	Procedure
C	2	1	(O)

May be inoperative provided:

- The associated ENG FUEL PRESS caution light and Aux Fuel Pump are verified operative, and
- Both flight compartment FUEL QTY Indications are verified operative, and
- Operations are conducted in compliance with AFM Supplement 95, OPERATION WITH AN INOPERATIVE AUX PUMP ADVISORY LIGHT.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative AUX PUMP advisory light must be placarded in the flight compartment.

Operating Procedures

Operations are conducted in compliance with AFM Supplement 95 OPERATION WITH AN INOPERATIVE TANK AUX PUMP ADVISORY LIGHT.

Maintenance Procedures

- Placard AUX PUMP advisory light on fuel control panel in the flight compartment.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-5 #1 TANK FUEL LOW and #2 TANK FUEL LOW Caution Lights**

Interval	Installed	Required	Procedure
C	2	1	(O)

May be inoperative provided:

- The associated flight compartment FUEL QTY Indication is verified operative and is periodically monitored during flight, and
- The associated engine FF (Fuel Flow) Indication is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative TANK FUEL LOW caution light must be placarded in the flight compartment.

Operating Procedures

1. Apply DC electrical power to the aircraft buses.
2. Ensure that fuel quantity is displayed on both master FUEL QTY indicators on the Engine Display and the Multi-Function Display (ESID) in the Flight Compartment.
3. Check that the FF indications on the Engine Display in the flight compartment indicate 0 pph.
4. Start both engines and run at ground idle. Check that the Fuel Flow Indicators on the Engine Display in the flight compartment indicate positive flow.
5. Shut down both engines.
6. Remove electrical power from the aircraft buses.

Maintenance Procedures

1. Placard TANK FUEL LOW caution light on Caution and Warning Panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-6****Refuel/Defuel/Transfer VALVE (OPEN/
CLOSED) Advisory Lights**

Interval	Installed	Required	Procedure
C	2	1	(M)

May be inoperative provided the fuel transfer system and flight compartment FUEL QTY Indications are verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative VALVE OPEN/CLOSED advisory light must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Apply DC and AC electrical power to the aircraft buses.
2. Ensure that fuel quantity is displayed on both master FUEL QTY indicators on the ESID Fuel Page and the Engine Display in the flight compartment.
3. At the FUEL CONTROL panel, select TRANSFER switch to TANK 1 position and observe that the TANK 2 AUX PUMP advisory light is illuminated and that fuel begins to transfer from tank 2 to tank 1 as indicated on the ESID fuel quantity indicators on the Engine Display in the flight compartment.
4. Select TRANSFER switch to TANK 2 position and observe that the TANK 1 AUX PUMP advisory light is illuminated and that fuel begins to transfer from tank 1 to tank 2 as indicated on the ESID fuel quantity indicators on the Engine Display in the flight compartment.
5. Return the TRANSFER switch to the center position.
6. Remove electrical power from the aircraft buses.
7. Placard inoperative VALVE OPEN/CLOSED advisory light on the FUEL CONTROL panel in the flight compartment.
8. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-6. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-7 External Refuel/Defuel Panel FUEL QTY Indicators**

Interval	Installed	Required	Procedure
C	2	0	(M)

May be inoperative provided the fuel quantity is determined by other approved means prior to each flight.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative external refuel/defuel panel fuel quantity indicator(s) must be placarded in the flight compartment and on the right nacelle.

Operating Procedures

None required.

Maintenance Procedures

1. Apply DC electrical power to the aircraft buses.
2. Level the aircraft prior to refueling by:
 - a) Following an approved leveling procedure, or
 - b) Placing the aircraft on a reasonably flat/level area on the ramp.

NOTE: The aircraft is considered level when the turn and slip indicator (inclinometer) is in the center location on the pilot and co-pilot's PFDs

3. Following each refueling, determine the fuel quantity using Flight Compartment Indicators or the magnetic dipsticks (refer to Ramp Servicing Manual).
4. Placard the inoperative fuel tank quantity indicator(s) at the external refuel/defuel panel on rear underside of right nacelle.
5. Remove electrical power from the aircraft buses.
6. Placard the inoperative fuel tank quantity indicator(s) at the Engine Display and ESID in the flight compartment.
7. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-7. 1



Interval	Installed	Required	Procedure
C	2	0	(M)

Minimum Equipment List Procedures (MELP)

Maintenance Procedures

- CAUTION:** WHEN REFUELING, ENSURE THAT FUEL FLOW HAS STOPPED BY VERIFYING THAT THE QUANTITIES DISPLAYED ON THE TANK 1 AND TANK 2 FUEL QTY INDICATORS, ON THE REFUEL/DEFUEL PANEL, HAVE STOPPED INCREASING.

4. Confirm that the quantities displayed on the FUEL QTY indicators on the Multi-Function Display in the flight compartment have also stopped increasing.
5. The refuel hose may now be disconnected from the refuel adapter.
6. Remove electrical power from the aircraft buses.
7. Placard REFUEL SHUTOFF advisory light on the external refuel/defuel panel.
8. Make appropriate entry in the aircraft journey log.

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-9 APU FUEL VALVE Advisory Light****28-40-9-1 OPEN**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- The OPEN light is extinguished, and
- The CLOSED light is illuminated when the APU is selected OFF.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative APU FUEL OPEN advisory light must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Apply DC electrical power to the aircraft buses.
2. Ensure that the OPEN light on the overhead Fire Control Panel is extinguished.
3. Ensure that the CLOSED light on the overhead Fire Control Panel is illuminated when the APU is selected OFF.
4. Inoperative APU FUEL OPEN advisory light must be placarded in the flight compartment.
5. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■**ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49**28-40-9. 1**

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-9 APU FUEL VALVE Advisory Light****28-40-9-2 CLOSED**

Interval	Installed	Required	Procedure
D	1	0	(M)

May be inoperative provided:

- APU is not operated, and
- The APU fuel shut off valve is verified closed.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative APU FUEL CLOSED advisory light must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures**Method A****NOTE:** If access to the center wing dry bay is not practical, the APU fuel shutoff valve may be verified closed by the following procedure:

- Apply DC power to aircraft buses.
- Pull and collar circuit breaker "APU FUEL VALVE" on Left Essential 28VDC Circuit Breaker Panel.
- Attempt to start APU. If APU fails to start, then the APU fuel shutoff valve is verified closed.

NOTE: The APU may spin up momentarily until residual fuel in the manifold is consumed, then shut down. Also, the APU FADEC may log a fault for the uncommanded shutdown/unsuccessful start.

- Placard APU FUEL CLOSED advisory light on the Fire Control Panel in the flight compartment.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-9. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-9 APU FUEL VALVE Advisory Light****28-40-9-2 CLOSED**

5. Make appropriate entry in the aircraft journey log.

Method B:

1. Open center wing dry bay access panel 521BT and verify that the position indicator arm of the APU fuel shutoff valve is in the CLOSED position.

NOTE: For removal of the access panel, please refer to Maintenance Manual PSM 1-84-2, Chapter 57.

2. Placard APU FUEL CLOSED advisory light on the Fire Control Panel in the flight compartment.
3. Make appropriate entry in the aircraft journey log.

Method C:

1. Feed a borescope/flexiscope through the wing dry bay drain port in the LH armpit to access the dry bay area.
2. Locate the APU Fuel Feed Shut-off valve.
3. Verify that INDICATOR ARM on the APU Fuel Feed Shut-off Valve is in CLOSED position.
4. Placard APU FUEL CLOSED advisory light on the Fire Control Panel in the flight compartment.
5. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-9. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-10 Flight Compartment Fuel QTY Indications (on ESID)**

Interval	Installed	Required	Procedure
C	2	1	(M)

May be inoperative provided:

- The fuel quantity is determined by other approved means prior to each flight,
- The Fuel Flow Indications are operative, are monitored during flight, and fuel consumption is recorded,
- TANK FUEL LOW caution light is operative, and
- Aircraft is dispatched with wing tanks balanced

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative FUEL QTY indicator in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

Following each refueling:

- Level the aircraft by:
 - Following an approved leveling procedure, or
 - Placing the aircraft on a reasonably flat/level area on the ramp.

NOTE: The aircraft is considered level when the turn and slip indicator (inclinometer) is in the center location on the pilot and co-pilot's PFDs or by viewing the Flight Management System data page to ensure the pitch is between -3 to plus 3 degrees and the roll is less than 3 degrees.

- With the aircraft level, following each refueling, verify fuel quantity using HMU dipsticks or Refuel/Defuel Panel FUEL QTY Indicators.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-10. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-10 Flight Compartment Fuel QTY Indications (on ESID)****NOTE:**

1. The HMU dipstick reading should be taken at least 5 minutes after refueling is completed.
2. The HMU dipstick readable range is between 850 to 5000lb (385 to 2270kg) per tank/wing or 15% to 85% of total usable fuel quantity of 5862 lb per tank/wing.

Verification of Low Level Sensor to be performed once

1. Level the aircraft by:
 - a) Following an approved levelling procedure, or
 - b) Placing the aircraft on a reasonably flat/level area on the ramp.

NOTE: The aircraft is considered level when the turn and slip indicator (inclinometer) is in the center location on the pilot and co-pilot's PFDs or by viewing the Flight Management System data page to ensure the pitch is between -3 to plus 3 degrees and roll is less than 3 degrees.

2. Install wheel chokes on all three gears.
3. Set EMERG BRAKE lever to the PARK position.
4. Run engine at IDLE on the side where fuel quantity is functional.
5. Ensure engine on side where fuel quantity indication is inoperative is off.
6. Record current fuel quantity on side with operative fuel quantity indicator.
7. Apply brakes with brake pedals and ensure aircraft does not move.
8. Set EMERG BRAKE lever to the OFF position.
9. Ensure PARKING BRAKE caution light goes out.
10. Transfer fuel from the fuel tank with the inoperative fuel quantity indication to the opposite fuel tank (which has an operational fuel quantity indicator), until you see the TANK FUEL LOW caution light illuminates for the tank with the inoperative fuel quantity gauge.

NOTE: Make sure you do not exceed the maximum fuel capacity of the wing tank when transferring fuel.

NOTE: TANK FUEL LOW caution light should illuminate at approx. 355 ±45 lbs (160±20 kg) of fuel in the tank.

11. Record the new fuel quantity on side with operative fuel quantity indicator. The amount of fuel that was transferred to the tank with the operation fuel quantity indicator, should than be transferred back to the fuel tank with the inoperative fuel quantity indicator.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-10. 2



DHC-8-402

MINIMUM EQUIPMENT LIST

FUEL

ATA 28

28-40-10 Flight Compartment Fuel QTY Indications (on ESID)

12. Once transfer is complete, move TRANSFER switch to the OFF position.
13. Set EMER BRAKE lever to the PARK position.
14. Shut engine down.
15. Remove wheel chokes.
16. Placard inoperative FUEL QTY Indicator on the Fuel Control Panel in the flight compartment.
17. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-10. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****FUEL******ATA 28*****28-40-11 Fuel Inlet Temperature Indications (on Engine Display)**

Interval	Installed	Required	Procedure
A	2	1	(O)

May be inoperative for one flight provided the TANK AUX PUMP Advisory Lights are operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Fuel Inlet Temperature Indication on the Engine Display must be placarded in the flight compartment.

Operating Procedures

1. For the side with the inoperative Fuel Inlet Temperature Indication ensure that the appropriate TANK 1 AUX PUMP or TANK 2 AUX PUMP switch is selected.
2. Check appropriate TANK AUX PUMP ON advisory light illuminates.

Maintenance Procedures

1. Placard the fuel inlet Temperature Indication in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

28-40-11. 1