

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-10-1 Parking/Emergency Brake Accumulator Hand Pump**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided accumulator pressure is verified prior to engine start.

Minimum Equipment List Procedures (MELP)**Placard**

Placard the inoperative parking/emergency brake accumulator hand pump in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the inoperative parking/emergency brake accumulator hand pump in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-10-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-10-2 HYD FSOV OPEN Indication Light**

Interval	Installed	Required	Procedure
C	2	1	(M)

One may be inoperative provided:

- The associated HYD FSOV is verified open, and
- The associated HYD FSOV CLOSED indication light is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative HYD FSOV OPEN Indicator Light for associated system on fire control panel in flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Place ground lock pins into main landing gear and engage nose wheel ground locking mechanism.
- Test the associated Hydraulic Firewall Shutoff Valve (HYD FSOV) and the HYD VALVES CLOSED indicator light, to confirm they are operative:
 - Connect and energize DC or AC power.
 - Open and tag circuit breakers for, BATTERY PWR- FIRE EXT/CONT AMP - 1&2 ENG and, BATTERY PWR- FIRE EXT/CONT AMP - CARGO, on the right essential bus.
 - Check that BATTERY PWR-HYD SOV - ENG 1 and BATTERY PWR-HYD SOV - ENG 2 circuit breakers on the right essential bus are closed.
 - Do an operational test of the associated hydraulic firewall shut-off valve as follows:
 - In the nacelle, visually check the shut-off valve position indicator. Make sure that the indicator arm shows the OPEN position.

NOTE: Access the shut-off valve through the main landing gear door.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-10-2. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

HYDRAULIC POWER

ATA 29

29-10-2

HYD FSOV OPEN Indication Light

- ii. On the flight compartment fire protection panel, pull the associated “PULL FUEL/HYD OFF” fire handle.
 - iii. In the associated nacelle, make sure that the shut-off valve indicator arm shows the CLOSED position.
 - iv. In the flight compartment, make sure that the white HYD VALVES CLOSED indicator light illuminates.
 - v. On the flight compartment fire protection panel, push the associated “PULL FUEL/HYD OFF” fire handle in.
 - vi. In the nacelle, make sure that the shut-off valve indicator arm shows the OPEN position.
 - vii. In the flight compartment, make sure that the white HYD VALVES CLOSED indicator light extinguishes.
 - e. Remove the external power.
 - f. Remove the tags and close circuit breakers for, BATTERY PWR- FIRE EXT/CONT AMP - 1&2 ENG and, BATTERY PWR- FIRE EXT/CONT AMP - CARGO, on the right essential bus.
3. Placard INOPERATIVE HYD FSOV OPEN Indicator Light for associated system on fire control panel in flight compartment.
4. Make appropriate entry in journey log.
- ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-10-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-1 HYD PRESS 1 and HYD PRESS 2 Indications**

Interval	Installed	Required	Procedure
C	2	1	(M)

May be inoperative provided:

- The associated ENG HYD PUMP Caution Light is verified operative, and
- The associated HYD QTY Indication is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative HYD PRESS 1 or 2 gauge in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Apply DC electrical power to the aircraft buses.
2. Check hydraulic fluid quantity at HYD QTY gauge on MFD and compare with fluid quantity at associated remote hydraulic quantity indicator located in the respective engine nacelle, below hydraulic system reservoir. Ensure that hydraulic fluid level is adequate.
3. Start the engine associated with the inoperative indicator and run to Ground Idle. Check that ENG HYD PUMP caution light goes out.
4. Shut down associated engine.
5. Remove electrical power from the aircraft buses.
6. Placard inoperative HYD PRESS 1 or 2 gauge on the MFD in the flight compartment.
7. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-2 HYD PRESS STBY Indication**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided:

- Normal operation of the Standby Hydraulic Pump is verified before each flight, and
- HYD PRESS 1 and HYD PRESS 2 Indications are verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative HYD PRESS STBY gauge in the flight compartment.

Operating Procedures

1. Apply AC and DC power to aircraft electrical buses.

NOTE: If buses are to be powered from an engine, only start engine 2.

2. Select the STBY HYD PRESS switch.
3. Check that the HYD PRESS 1 gauge on the MFD reads approximately 2800 to 3100 psi.
4. Remove power from AC and DC buses.

Maintenance Procedures

1. Placard inoperative HYD PRESS STBY gauge on the MFD in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-2. 1



Interval	Installed	Required	Procedure
C	2	0	(M)(O)

- HYD QTY 1 and HYD QTY 2 Indications are verified operative, and
- ENG HYD PUMP Caution Lights are verified operative.

1. Placard inoperative Nacelle Hydraulic Quantity Indicator(s) in the flight compartment and on the indicator(s) in the associated main landing gear wheel well.
2. Make appropriate entry in the aircraft journey log.

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-4 #1 STBY HYD PUMP HOT Caution Light**

Interval	Installed	Required	Procedure
A	1	0	NIL

May be inoperative provided:

- STBY HYD PRESS Indication is operative, and
- Repairs are made within one flight day.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative #1 STBY HYD PUMP HOT caution light in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard inoperative #1 STBY HYD PUMP HOT caution light on the caution and warning panel in the flight compartment.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-5 HYD QTY 3 Indication**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- The System #3 Aft Fuselage Hydraulic Quantity Indicator is verified operative, and
- Adequate fluid quantity is verified before each flight.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative HYD QTY 3 indicator in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard inoperative HYD QTY 3 indicator on the MFD in the flight compartment.
- Check hydraulic fluid quantity at associated remote hydraulic quantity indicator located in aft fuselage equipment bay below hydraulic system 3 reservoir. Ensure that hydraulic fluid level is adequate. Correct hydraulic fluid quantity level is identified by QUANTITY vs. FLUID TEMP graph located adjacent to remote quantity indicator.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-6 System #3 Aft Fuselage Hydraulic Quantity Indicator**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided HYD QTY 3 Indication is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative aft fuselage hydraulic quantity indicator in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative aft fuselage hydraulic quantity indicator in the flight compartment and on the indicator in the aft fuselage equipment bay.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-6. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-7 HYD PRESS 3 Indication**

Interval	Installed	Required	Procedure
C	1	0	(M#)

May be inoperative provided:

- The #3 HYD PUMP Caution Light is verified operative, and
- The HYD QTY 3 Indication is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative HYD PRESS 3 indication in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Apply AC and DC power to aircraft electrical buses.
2. Check hydraulic fluid quantity at HYD QTY 3 gauge on MFD and compare with fluid quantity at associated remote hydraulic quantity indicator located in the aft fuselage equipment bay, below hydraulic system reservoir. Ensure that hydraulic fluid level is adequate. Correct hydraulic fluid quantity level is identified by QUANTITY vs. FLUID TEMP graph located adjacent to remote quantity indicator.
3. With neither engine running, access the aft fuselage equipment bay through access panel 311AB, and depress the manual relief button on the system 3 isolation valve to depressurize the system 3 accumulator.
4. Ensure that the #3 HYD PUMP caution light is illuminated.
5. Press the HYD #3 ISOL VLV button to open the system 3 isolation valve.
6. Ensure that the #3 HYD PUMP caution light is extinguished (the DC motor pump will start when the valve is selected open).
7. Select the Standby Hydraulic Pump (SPU) and PTU to ON.
8. Ensure that the ELEVATOR PRESS caution light is illuminated.
9. Select the Standby Hydraulic Pump (SPU) and PTU to NORM.
10. Ensure that the ELEVATOR PRESS caution light is extinguished.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-7. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

HYDRAULIC POWER

ATA 29

29-30-7

HYD PRESS 3 Indication

11. Press the HYD #3 ISOL VLV button to close the system 3 isolation valve.
12. Placard inoperative HYD PRESS 3 indicator on the MFD in the flight compartment.
13. Make appropriate entry in the aircraft journey log.



ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-7. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-8 PTU CNTRL ON Advisory Light****29-30-8-2 Post Modsum 4-126354 or 4-126425****29-30-8-2A PTU CNTRL ON Advisory Light (White)**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided Pressure Green Cross Hatch Advisory Light is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative PTU CNTRL ON advisory light must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard PTU CNTRL advisory light at PTU CNTRL switch on HYDRAULIC CONTROL panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-8. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-8 PTU CNTRL ON Advisory Light****29-30-8-2 Post Modsum 4-126354 or 4-126425****29-30-8-2B PTU CNTRL FAIL Advisory Light (Amber)**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided Pressure Green Cross Hatch Advisory Light is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative PTU CNTRL FAIL advisory light must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard PTU CNTRL advisory light at PTU CNTRL switch on HYDRAULIC CONTROL panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-8. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST****HYDRAULIC POWER****ATA 29****29-30-8 PTU CNTRL ON Advisory Light****29-30-8-2 Post Modsum 4-126354 or 4-126425****29-30-8-2C PTU CNTRL pressure Green Cross Hatch Advisory Light (Green)**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided:

- The HYD PRESS 2 indication is verified operative,
- The #2 ENG HYD PUMP caution light is verified operative, and
- The hydraulic Power Transfer Unit is verified operative prior to each flight.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative PTU CNTRL Pressure green cross hatch advisory light must be placarded in the flight compartment.

Operating Procedures

ONLY PTU WILL BE VERIFIED OPERATIVE THROUGH STEPS 5 TO 10 PRIOR TO EACH FLIGHT. STEPS 1-4 WILL BE PERFORMED ONLY ONCE FOR TEN-DAY (C) RELIEF.

1. Apply DC power to aircraft electrical buses.
2. Ensure that HYD PRESS 2 indicator indicates 0 psi and the #2 ENG HYD PUMP caution light is illuminated.
3. Start engine #2 and run at Idle. Check that HYD PRESS 2 indicator indicates 2900 to 3100 psi and the #2 ENG HYD PUMP caution light goes out.
4. Shut down engine #2.
5. Start engine #1 and run to idle,

OR

Apply 400 Hz 115V AC electrical power to aircraft using a ground power unit. Set the STBY HYD PRESS push button switch to ON, which is located on the HYDRAULIC CONTROL Panel and observe that switch-light illuminates green.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-8. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-8 PTU CNTRL ON Advisory Light****29-30-8-2 Post Modsum 4-126354 or 4-126425****29-30-8-2C PTU CNTRL pressure Green Cross Hatch Advisory Light
(Green)**

CAUTION: MONITOR #1 STBY HYD PUMP HOT CAUTION LIGHT. IF IT ILLUMINATES, TURN THE SPU OFF.

6. Ensure that HYD PRESS 2 indicator indicates 0 psi.
7. Select the PTU CNTRL switch to ON.
8. Check that HYD PRESS 2 indicator indicates 2800 to 3000 psi.
9. Select the PTU CNTRL switch to NORM.
10. Shut down engine #1 or disconnect the ground power unit.

Maintenance Procedures

1. Placard PTU CNTRL advisory light at PTU CNTRL switch on HYDRAULIC CONTROL panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-8. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-9 #1 ENG HYD PUMP and #2 ENG HYD PUMP**
Caution Lights

Interval	Installed	Required	Procedure
C	2	1	(M)

May be inoperative provided:

- The associated flight compartment HYD PRESS Indication is verified operative,
- The associated ISOLATION VALVE is verified operative, and
- The associated hydraulic pressure is periodically monitored.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative ENG HYD PUMP caution light in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Apply DC electrical power to aircraft electrical buses.
2. Prior to starting engines, check that the associated HYD PRESS 1 or 2 gauge on the MFD reads 0 psi.
3. Check that associated "HYD ISO VLV" caution light is illuminated.
4. Start the associated engine.
5. Check that associated SPU/PTU switch is selected OFF.
6. Check that the associated HYD PRESS 1 or 2 gauge on the MFD reads 2900 to 3100 psi.
7. Check that associated "HYD ISO VLV" caution light is extinguished.
8. Shut down engine(s).
9. Remove electrical power from aircraft electrical buses.
10. Placard inoperative ENG HYD PUMP caution light on the Caution and Warning Panel in the flight compartment.
11. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-9. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-10 HYD QTY 1 and HYD QTY 2 Indications**

Interval	Installed	Required	Procedure
C	2	1	(M)

May be inoperative provided:

- The quantity is verified adequate prior to each flight,
- The associated ENG HYD PUMP Caution Light and HYD PRESS Indication are verified operative,
- The associated HYD ISO VLV Caution Light is verified operative, and
- The associated Nacelle Hydraulic Quantity Indicator is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative hydraulic quantity indicator in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Access the associated main landing gear wheel well by fully opening the LANDING GEAR ALTERNATE RELEASE door and pulling fully the MAIN L/G RELEASE handle in the flight compartment.
- Ensure the area near the wheel well doors is clear, and install the main landing gear ground locking pin in the stabilizer brace and the main landing gear wheel well door ground locking pin in the aft door mechanism.
- Apply DC power to aircraft electrical buses.
- Ensure that the associated HYD ISO VLV caution light is illuminated.
- Ensure that hydraulic power is not applied, and pull and collar the LDG GEAR WOW2 & CONT circuit breakers on the Left Main 28 VDC bus and the Left Essential 28 VDC bus.
- Ensure that hydraulic fluid level is adequate at the associated remote hydraulic quantity indicator, located in the respective engine nacelle below the hydraulic system reservoir. (Correct hydraulic fluid quantity level is identified by QUANTITY vs. FLUID TEMP graph located adjacent to the remote quantity indicator).

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-10. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

HYDRAULIC POWER

ATA 29

29-30-10 HYD QTY 1 and HYD QTY 2 Indications

7. Start engine associated with inoperative indicator and run to ground idle. Check for the following:
 - a) Associated HYD ISO VLV caution light goes out.
 - b) Associated ENG HYD PUMP caution light goes out at 2400 psi.
 - c) Associated HYD PRESS gauge on MFD reads approximately 3000 psi.
8. Shut down associated engine.
9. Remove the DC power.
10. Remove collars and reset LDG GEAR WOW2 & CONT circuit breakers on the left Main 28 VDC bus and the Left Essential 28 VDC bus.
11. Ensure the area near the wheel well doors is clear, and remove the main landing gear ground locking pin in the stabilizer brace and the main landing gear wheel well door ground locking pin in the aft door mechanism.
12. Placard inoperative hydraulic quantity indicator on the MFD in the flight compartment.
13. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-10. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-11 STBY HYD PRESS ON Advisory Light**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided the HYD PRESS STBY indication is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative STBY HYD PRESS ON advisory light must be placarded in the flight compartment.

Operating Procedures

1. Apply AC power to aircraft buses.
2. Ensure that the HYD PRESS STBY indicator indicates 0 psi.
3. Select the STBY HYD PRESS switch on.
4. Ensure that the HYD PRESS STBY indicator indicates 2800 – 3000 psi.
5. Select the STBY HYD PRESS switch to NORM.

Maintenance Procedures

1. Placard STBY HYD PRESS advisory light at STBY HYD PRESS switch on HYDRAULIC CONTROL panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-11. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-12 #1 HYD FLUID HOT and #2 HYD FLUID HOT**
Caution Lights

Interval	Installed	Required	Procedure
B	2	1	(M#)(O)

May be inoperative provided:

- The associated HYD PRESS Indication is verified operative and is periodically monitored during flight,
- Adequate steps are taken each flight day to ensure that an overheat condition has not occurred, and
- The associated HYD QTY Indication is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative HYD FLUID HOT caution light in the flight compartment.

Operating Procedures

- Confirm that prior to starting engines, the associated HYD PRESS 1 or 2 gauge on the ESID reads 0 psi, and after starting, the associated HYD PRESS reads 2900 to 3100 psi.
- Confirm that the Associated HYD QTY Indication (% x 100) is operative on a MFD.
- During flight, periodically monitor the affected HYD PRESS gauge to ensure pressure indication does not exceed 3100 psi.

Maintenance Procedures

- Access the associated main landing gear wheel well by fully opening the LANDING GEAR ALTERNATE RELEASE door and pulling fully the MAIN L/G RELEASE handle in the flight compartment.
- Ensure the area near the wheel well doors is clear, and install the main landing gear ground locking pin in the stabilizer brace and the main landing gear wheel well door ground locking pin in the aft door mechanism.
- Ensure that hydraulic power is not applied, and pull and collar the LDG GEAR WOW2 & CONT circuit breakers on the Left Main 28 VDC bus and the Left Essential 28 VDC bus.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-12. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-12****#1 HYD FLUID HOT and #2 HYD FLUID HOT
Caution Lights**

4. 15 minutes following engine shutdown, wipe clean the hydraulic tubes connections for the components listed below, in the associated main landing gear wheel well:
 - a) Pressure relief valve and return manifold.
 - b) Case drain tube and return manifold.
5. Wait a further 20 minutes and inspect the same hydraulics connections for signs of leaks.
6. Inspect the hydraulic reservoir overflow ecology bottle in the associated main landing gear wheel well for a significant increase in the amount of fluid from the previous day.
7. Take a small sample of fluid from the reservoir and check the appearance of the fluid for evidence of overheating. (Refer to Dash 8 Series 400 Aircraft Maintenance Manual, Chapter 29.)
8. With no evidence of fluid overheat (leakage, discoloration, ecology bottle contents, etc.), make appropriate entry in the aircraft journey log.
9. With fluid leakage or discoloration present, change hydraulic fluid and carry out HYDRAULIC POWER-- INSPECTION/TEST including corrective action, in accordance with AMM, Chapter 29.
10. Remove collars and reset LDG GEAR WOW2 & CONT circuit breakers on the Left Main 28 VDC bus and the Left Essential 28 VDC bus.
11. Ensure the area near the wheel well doors is clear, and remove the main landing gear ground locking pin in the stabilizer brace and the main landing gear wheel well door ground locking pin in the aft door mechanism.
12. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-12. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****HYDRAULIC POWER******ATA 29*****29-30-13 HYD #3 ISOL VLV OPEN Advisory Light**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided:

- The HYD PRESS 3 indication is operative, and
- The ELEVATOR PRESS caution light is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative HYD #3 ISOL VLV OPEN advisory light must be placarded in the flight compartment.

Operating Procedures

- Start engines 1 and 2, or engine 1 and PTU, or engine 2 and SPU.
- Ensure that the HYD PRESS 1 and 2 indicators indicate 2900 to 3100 psi.
- Select the HYD #3 ISOL VLV switch to OPEN.
- Ensure that the HYD PRESS 3 indicator indicates 2400 to 3100 psi and that the ELEVATOR PRESS caution light is illuminated.
- Select the HYD #3 ISOL VLV switch to NORM.
- Shut down hydraulics and engine(s).

Maintenance Procedures

- Placard HYD #3 ISOL VLV OPEN advisory light at HYD #3 ISOL VLV switch on HYDRAULIC CONTROL panel in the flight compartment.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

29-30-13. 1