

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-1 TAIL De-Ice Boots Advisory Lights**

Interval	Installed	Required	Procedure
C	4	0	NIL

May be inoperative provided the flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Tail Deicer Boots Advisory Lights on the ICE PROTECTION Panel in the flight compartment

Operating Procedures

None required.

Maintenance Procedures

1. Place a placard on the ICE PROTECTION Panel near the faulty advisory lights.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-2 DEICE PRESS Caution Light****30-10-2-1**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided the flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)

NOTE: If "DEICE PRESSURE" Caution Light illuminates in flight, rotate the BOOT AIR switch to ISO position as per AFM. Check for pressure in No. 1 and No. 2 system via DEICE PRESS dual indicators, and check deice boot advisory lights on the Ice Protection Panel. An appropriate entry should be made in the aircraft journey log regarding verification of the Deice Boot Advisory Lights and the DEICE PRESS indicators operative.

Placard

Place a placard on the Caution Panel near the DE-ICE PRESS caution light.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the DE-ICE PRESS caution light on Caution Warning Panel.
2. Make appropriate entry in the aircraft journey log, "DEICE PRESS Caution Light Inoperative".

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-2 DEICE PRESS Caution Light****30-10-2-2**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- All De-Ice Boot Advisory Lights are verified operative, and
- The DEICE PRESS Indicators are verified operative.

Minimum Equipment List Procedures (MELP)

NOTE: If “DEICE PRESSURE” Caution Light illuminates in flight, rotate the BOOT AIR switch to ISO position as per AFM. Check for pressure in No. 1 and No. 2 system via DEICE PRESS dual indicators, and check deice boot advisory lights on the Ice Protection Panel. An appropriate entry should be made in the aircraft journey log regarding verification of the Deice Boot Advisory Lights and the DEICE PRESS indicators operative.

Placard

Place a placard on the Caution Panel near the DE-ICE PRESS caution light.

Operating Procedures

None required.

Maintenance Procedures

1. Ensure all aircraft electrical buses are powered.
2. Start #1 engine and run at ground idle.
3. On the ICE PROTECTION panel, set AIRFRAME MODE SELECT rotary switch to FAST position and verify that the De-Icer boot advisory lights operate normally at the appropriate boot inflation/deflation sequence: Wing advisory lights illuminate and go out sequentially in pairs, commencing with outboard pair and ending with inboard pair, followed by inboard TAIL then outboard TAIL.

NOTE: The sequence of the WING 3rd and 4th advisory lights on the left side is reversed.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-2. 2



DHC-8-402

MINIMUM EQUIPMENT LIST

ICE AND RAIN PROTECTION

ATA 30

30-10-2 DEICE PRESS Caution Light

30-10-2-1

4. Select the BOOT AIR switch to ISO and observe that the DEICE PRESS Indicator reads 15–18 psi on the active side and zero on the other side.
5. Select the BOOT AIR switch to NORM and observe whether the DEICE PRESS Indicator gauge reads 15–18 psi on both sides.
6. Shut down #1 engine.
7. Placard the DE-ICE PRESS caution light on Caution Warning Panel.



ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-2. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-3 DEICE PRESS Indicators****30-10-3-1**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided the flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Place a "Pressure Indicator Inoperative" placard near the faulty de-ice pressure indicator.

Operating Procedures

None required.

Maintenance Procedures

1. Placard De-Ice Pressure Indicator on the co-pilot's side console panel.
2. Make appropriate entry in the aircraft journey log, "Dual Pressure Indicator Inoperative".

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-3 DEICE PRESS Indicators****30-10-3-2**

Interval	Installed	Required	Procedure
C	2	0	(M)

May be inoperative provided:

- All De-Ice Boot Advisory Lights are verified operative, and
- The DEICE PRESS Caution Light is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Place a "Pressure Indicator Inoperative" placard near the faulty de-ice pressure indicator.

Operating Procedures

None required.

Maintenance Procedures

1. Ensure all aircraft electrical buses are powered.
2. Start #1 engine and run at ground idle.
3. On the ICE PROTECTION panel, set AIRFRAME MODE SELECT rotary switch to FAST position and verify that the De-Icer boot advisory lights operate normally at the appropriate boot inflation/deflation sequence: Wing advisory lights illuminate and go out sequentially in pairs, commencing with outboard pair and ending with inboard pair, followed by inboard TAIL then outboard TAIL.

NOTE: The sequence of the WING 3rd and 4th advisory lights on the left side is reversed.

4. Select the BOOT AIR switch to ISO and observe that the DEICE PRESS caution light illuminates.
5. Select the BOOT AIR switch to NORM and observe whether the DEICE PRESS caution light extinguishes.
6. Shut down #1 engine.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-3. 2



DHC-8-402

MINIMUM EQUIPMENT LIST

ICE AND RAIN PROTECTION

ATA 30

30-10-3

DEICE PRESS Indicators

30-10-3-2

7. Placard De-Ice Pressure Indicator on the co-pilot's side console panel.
8. Make appropriate entry in the aircraft journey log, "Dual Pressure Indicator Inoperative".

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-3. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-4 Low Pressure Warning Switches (LPWS)****30-10-4-1**

Interval	Installed	Required	Procedure
C	2	1	(M#)

May be inoperative provided:

- DEICE PRESS Caution Light is verified operative,
- DEICE PRESS Indicator is verified operative,
- All De-ice Advisory Lights are verified operative, and
- Faulty LPWS is disconnected.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Low Pressure Warning Switch(es) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Access the Centralized Diagnostic System (if operational) for the IRPS and confirm/rectify any listed PRESENT FAULTS.
- Start #2 engine and run at ground idle.
- Confirm #2 de-ice system pressure indication on the dual DE-ICE pressure gauge is 18 +1.5/-1 psi.
- On the ICE PROTECTION panel, set AIRFRAME MODE SELECT rotary switch to FAST position and verify that the De-Icer boot advisory lights operate normally at the appropriate boot inflation/deflation sequence: Wing advisory lights illuminate and go out sequentially in pairs, commencing with outboard pair and ending with inboard pair, followed by inboard TAIL then outboard TAIL.

NOTE: The sequence of the WING 3rd and 4th advisory lights on the left side is reversed.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-4 Low Pressure Warning Switches (LPWS)****30-10-4-1**

5. Set the AIRFRAME AUTO selector to OFF position.
6. Shut down engine.
7. Gain access to left Low Pressure Warning Switch, via panel 261CT, on top of the fuselage, immediately adjacent the left inboard leading edge boot.
8. Locate electrical plug 3000-P22 and disconnect from pressure switch.
9. Re-start engine #2 and run at ground idle.
10. Select the BOOTAIR switch to ISO and confirm single side pressure indication for the system on the dual DE- ICE pressure gauge is normal (18 +1.5/-1 psi) and observe whether the DEICE PRESS caution light extinguishes.
11. If Caution light extinguishes, tape and stow 3000-P22 at left Low Pressure Warning Switch, then repeat steps
 - a) (9) and (10). If Caution light does not extinguish, proceed to next step.
12. Shutdown #2 engine and re-connect 3000-P22. Close access panel.
13. Gain access to right Low Pressure Warning Switch, via panel 261LT, on top of the fuselage, immediately adjacent the right inboard leading edge boot.
14. Locate electrical plug 3000-P23 and disconnect from pressure switch.
15. Start engine #1 and run at ground idle.
16. Repeat step (10).
17. If Caution light extinguishes, tape and stow 3000-P23 at right Low Pressure Warning Switch.
18. Select the BOOTAIR switch to NORM.
19. Shutdown #1 engine and close access panel.
20. Placard glareshield with "#DEICE PRESS SWITCH INOP".
21. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-4. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-4 Low Pressure Warning Switches (LPWS)****30-10-4-2**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Low Pressure Warning Switch(es) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard glareshield with "#DEICE PRESS SWITCH INOP".
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-4. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-5****WING De-Ice Boots Advisory Lights**

Interval	Installed	Required	Procedure
C	8	2	(O)

May be inoperative provided:

- The left wing root de-icer boot advisory light and right wing root de-icer boot advisory light are verified operative,
- The associated boot operation is visually monitored when in use, and
- The appropriate wing inspection light(s) operate normally for night operation.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Wing De-Ice Boots Advisory Lights on the ICE PROTECTION control panel in the flight compartment.

Operating Procedures

- Select the AIRFRAME MODE SELECT switch to "FAST".
- Visually confirm the two wing root de-icer boot advisory lights are illuminated in 60 sec.
- Select the AIRFRAME MODE SELECT switch to "OFF".

Maintenance Procedures

- Placard on the ICE PROTECTION control panel in the flight compartment.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST****ICE AND RAIN PROTECTION****ATA 30****30-10-6 Timer Monitor Unit (TMU, Timer Function)**

Interval	Installed	Required	Procedure
C	1	0	(M#)

May be inoperative provided:

- Flight is not conducted in known or forecast icing conditions,
- PITOT HEAT 1, PITOT HEAT 2 and PITOT HEAT STBY are verified operative,
- L AOA VANE HEAT and R AOA VANE HEAT are verified operative, and
- ENGINE INTAKE HEATER 1 and 2 are verified operative.

NOTE: AUTO mode of De-icer boots cycle will be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative airframe de-ice Timer Monitor Unit Timing Function must be placarded in the flight compartment.

Operating Procedures

Should inadvertent icing be encountered, airframe boots will require manual cycling.

Maintenance Procedures

- Start and run both engines at idle.
- Ensure that both AC Generators are selected on.
- At the ICE PROTECTION panel, select both ENGINE INTAKE bypass door switches and observe that the switch-lights' advisory light indications change from CLOSED to OPN and HTR.

NOTE: The engine intake adaptor heaters and resultant HTR indications are switched by the thermostat on the skin panel, beneath the cockpit floor. If outside air temperatures are above a nominal 15 degrees C (59 degrees F), as indicated on the Engine Display SAT indication, spray the skin at the location of the thermostat using Freeze Mist or use other means to lower the temperature and observe the HTR advisory lights illumination.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-6. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

ICE AND RAIN PROTECTION

ATA 30

30-10-6

Timer Monitor Unit (TMU, Timer Function)

4. De-select the ENGINE INTAKE bypass door switches and observe the switch-light advisory lights return to the CLOSED indications.
5. Shut down engines.
6. 6. Placard the ICE PROTECTION panel AIRFRAME MODE SELECT switch with "SLOW/FAST INOP".
7. 7. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-6. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-10-7 Airframe De-Icing System**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided the flight is not conducted in known or forecast icing conditions.

NOTE: Must be operative for Monsoon operations.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Airframe De-Icing System on the ICE PROTECTION control panel.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the ICE PROTECTION control panel with "AIRFRAME DEICE INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-10-7. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-1 Engine Intake Bypass Door OPN and CLOSED Advisory Lights****30-20-1-1**

Interval	Installed	Required	Procedure
C	2	0	(M)

May be inoperative provided:

- Bypass Door operation is verified prior to each flight, and
- The related engine intake heater indicator is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Intake Bypass Door indicator(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Apply DC electrical power to the aircraft busses.
2. Visually check that associated Engine Intake Bypass Door(s) is closed.
3. Press associated ENGINE INTAKE OPN HTR/CLOSED switchlight on the Ice and Rain Protection Panel and visually check that the associated Engine Intake Bypass Door(s) is open. (HTR light illuminates verification only required once prior to first dispatch).
4. Press associated ENGINE INTAKE OPN HTR/CLOSED switchlight on the Ice and Rain Protection Panel and visually check that the effected Engine Intake Bypass Door(s) is closed and associated HTR light goes out.
5. Remove DC electrical power for the aircraft busses.
6. Placard the Engine Intake Bypass Door Advisory Light(s) on ICE PROTECTION panel.
7. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-1 Engine Intake Bypass Door OPN and CLOSED Advisory Lights****30-20-1-2**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided:

- Associated bypass door(s) remains closed, and
- Flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Intake Bypass Door indicator(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard the Engine Intake Bypass Door switchlight(s) on ICE PROTECTION panel.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-2 ENGINE INTAKE HTR Advisory Lights****30-20-2-1**

Interval	Installed	Required	Procedure
C	2	0	(M)(O)

May be inoperative provided:

- The associated Heater(s) is verified operative prior to dispatch, and
- Associated ENG ADPT HEAT Caution Light(s) is verified operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Intake Heater Advisory Light must be placarded on the ICE PROTECTION Control Panel.

Operating Procedures**In Flight Prior to Landing: To Verify Operative the Associated Heater(s)**

- Check that the affected Engine Intake Heater(s) is/are operative:
 - Check that SAT (Static Air Temperature) is below a nominal 15°C (59°F).
 - Ensure all aircraft buses are powered.
 - On the-Electrical Page of the MFD, monitor the electrical load of the B phase of the associated AC generator.

NOTE: If the outside air temperature is above a nominal 15°C (59°F), as indicated on the Engine Display SAT indication, Method A must be used.

- Press the affected ENGINE INTAKE OPN HTR/CLOSED switchlight and observe:
 - The associated OPN light illuminates and CLOSED light is out.
 - The LOAD reading of the B phase of the associated AC generator increases on the Electrical Page of the MFD.
- Press the affected ENGINE INTAKE OPN HTR/CLOSED switchlight and observe:
 - The affected CLOSED switchlight illuminates and OPN light is out.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DAT 00 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-2 ENGINE INTAKE HTR Advisory Lights****30-20-2-1**

- (ii) The LOAD reading of the B phase of the associated AC generator decreases.
- f) Repeat steps (c) through (e) if required for opposite engine intake HTR advisory light.

Maintenance Procedures**To Verify Operative the Associated Heater(s)**

1. Check that the associated heater(s) is/are operative:
 - a) Visually check that associated engine intake bypass door is closed on the affected engine(s).
 - b) Start associated engine(s) and run to Ground Idle.
 - c) Ensure all aircraft buses are powered.
 - d) Monitor the associated AC generator LOAD on ESID-Electrical Page.
 - e) Check that SAT (Static Air Temperature) is below a nominal 15°C (59°F).

NOTE: If outside air temperatures are above a nominal 15°C (59°F), as indicated on the engine Display SAT indication, spray the aircraft skin at the location of the thermostat using Freeze Mist or use other means to lower the temperature.

- f) Press associated ENGINE INTAKE OPN HTR/CLOSED switchlight and check that:
 - (i) The associated OPN light illuminates and CLOSED light is off.
 - (ii) The LOAD reading of the associated AC generator increases.
 - g) Press associated ENGINE INTAKE OPN HTR/CLOSED switchlight and check that:
 - (i) The associated CLOSED light illuminates and OPN light is off.
 - (ii) The LOAD reading of the associated AC generator decreases.
 - h) Repeat steps (e) through (g) if required for opposite engine intake HTR advisory light.
 - i) Shut down engine(s).
2. Check that the associated ENG ADPT HEAT 1 and/or ENG ADPT HEAT 2 caution light(s) operate normally.
 3. Placard ENGINE INTAKE HTR Lights on the Ice Protection Control Panel at pilot's overhead panel.
 4. Make appropriate entry in the aircraft journey log.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-2. 2



DHC-8-402

MINIMUM EQUIPMENT LIST

ICE AND RAIN PROTECTION

ATA 30

30-20-2

ENGINE INTAKE HTR Advisory Lights

30-20-2-1

To Verify Operative the Associated Caution Lights

1. Check that both ENG ADPT HEAT 1 and ENG ADPT HEAT 2 caution lights operate normally.
2. Placard ENGINE INTAKE HTR advisory lights on the Ice Protection Control Panel at pilot's overhead panel.
3. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00

APPROVED BY DAW DELHI, DATED –

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-2. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-2 ENGINE INTAKE HTR Advisory Lights****30-20-2-2**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative provided the flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Intake Heater Advisory Light must be placarded on the ICE PROTECTION Control Panel.

Operating Procedures

None required.

Maintenance Procedures

1. Placard ENGINE INTAKE HTR Lights on the Ice Protection Control Panel at pilot's overhead panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-2. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-3****ENG ADPT HEAT 1 and ENG ADPT HEAT 2
Caution Lights**

Interval	Installed	Required	Procedure
C	2	1	(M)(O)

May be inoperative provided:

- The associated heater is verified operative prior to dispatch, and
- The associated ENGINE INTAKE HTR advisory light is verified operative and is periodically monitored.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative ENGINE ADPT HEAT 1 or ENGINE ADPT HEAT 2 Caution Lights must be placarded on the Caution and Warning Panel.

Operating Procedures**In flight prior to landing:**

- Check that the associated heater is operational:
 - Check that SAT (Static Air Temperature) is below a nominal 15°C (59°F).
 - Ensure all aircraft busses are powered.
 - On the–Electrical Page of the MFD, monitor the electrical load of the B phase of the associated AC generator.

NOTE: If the outside air temperature is above a nominal 15°C (59°F), as indicated on the Engine Display SAT indication, Method A must be used.

- Press the affected ENGINE INTAKE OPN HTR/CLOSED switchlight and observe:
 - The associated HTR light illuminates.
 - The LOAD reading of the B phase of the associated AC generator increases on the Electrical Page of the MFD.
- Press the affected ENGINE INTAKE OPN HTR/CLOSED switchlight and observe:
 - The associated HTR light goes out.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-3****ENG ADPT HEAT 1 and ENG ADPT HEAT 2
Caution Lights**

- (ii) The LOAD reading of the B phase of the associated AC generator decreases.

On ground:

1. Placard ENGINE ADPT HEAT 1 or ENGINE ADPT HEAT 2 Caution Light on the caution and Warning Panel.
2. Make appropriate entry in the aircraft journey log.

Maintenance Procedures

1. Check that the associated heater is operational:
 - a) Visually check that associated engine intake bypass door is closed on the affected engine.
 - b) Start associated engine and run to Ground Idle.
 - c) Ensure all aircraft busses are powered.
 - d) Monitor the associated AC generator LOAD on ESID Electrical Page.
 - e) Check the SAT (Static Aircraft Temperature) is below a nominal 15°C (59 °F).

NOTE: If outside air temperatures are above a nominal 15°C (59°F), as indicated on the Engine Display SAT indication, spray the aircraft skin at the location of the thermostat using Freeze Mist or other means to lower the temperature.

- f) Press the affected ENGINE INTAKE OPN HTR/CLOSED switchlight and observe:
 - (i) The associated HTR light illuminates.
 - (ii) The LOAD reading of the associated AC generator increases.
 - g) Press associated ENGINE INTAKE OPN HTR/CLOSED switchlight and check that:
 - (i) The associated HTR light goes out.
 - (ii) The LOAD reading of the associated AC generator decreases.
 - h) Shut down engine(s).
2. Placard ENGINE ADPT HEAT 1 or ENGINE ADPT HEAT 2 Caution Light on the Caution and Warning Panel.
 3. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-3. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-20-4 Engine Intake Adapter Heater Assemblies**

Interval	Installed	Required	Procedure
C	2	1	(M)

One may be inoperative provided the flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Intake Adapter Heater is placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Pull circuit breaker INTK LIP HTR ENG 1 or INTK LIP HTR ENG 2 associated with the inoperative Engine Intake Adapter Heater.
2. Inoperative Engine Intake Adapter Heater is placarded in the flight compartment.
3. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-20-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-30-1 Pitot/Static Heaters**

Interval	Installed	Required	Procedure
B	3	2	NIL

May be inoperative for DAY VMC provided:

- There is no visible moisture, and
- The flight is not conducted into known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative PITOT/STATIC PORTS switch on the ICE PROTECTION panel.

Operating Procedures

None required.

Maintenance Procedures

- Placard the overhead ICE PROTECTION panel.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-30-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-30-2****PITOT HEAT 1, PITOT HEAT 2 and PITOT
HEAT STBY Caution Lights**

Interval	Installed	Required	Procedure
B	3	0	(M)

May be inoperative provided:

- The flight is not conducted into known or forecast icing conditions, and
- All other elements of the pitot heat systems are verified operative prior to each flight.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative PITOT HEAT Caution Light(s) in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures**System 1 and 2 Pitot Probes**

- Ensure AC External Power is supplied to the aircraft and all AC and DC buses are powered.
- Select PITOT/STATIC PORTS #1 and #2 heat on the ICE PROTECTION panel for a period of five to seven seconds, then switch off.

WARNING: SURFACE MAY BE HOT TO TOUCH.

- Physically confirm that both probes have warmed to temperatures above ambient.
- Placard the caution panel in the Flight Compartment.
- Make appropriate entry in the aircraft journey log.

Standby Pitot Probe

- Select BATTERY MASTER to on, or ensure AC or DC External Power is supplied to the aircraft.
- Select STBY PITOT/STATIC PORTS heat on the ICE PROTECTION panel for a period of five to seven seconds, then switch off.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-30-2. 1



DHC-8-402

MINIMUM EQUIPMENT LIST

ICE AND RAIN PROTECTION

ATA 30

30-30-2

**PITOT HEAT 1, PITOT HEAT 2 and PITOT
HEAT STBY Caution Lights**

WARNING: SURFACE MAY BE HOT TO TOUCH.

3. Physically confirm that probe has warmed to temperature above ambient.
4. Placard the caution panel in the flight compartment.
5. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-30-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-40-1 Windshield Wipers**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided the flight is not conducted in precipitation within five nautical miles of the airport of take-off or intended landing.

NOTE: Both Windshield Wipers should be operative for Low Visibility Operation (LVO) and CAT II operations.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative windshield wiper(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the inoperative windshield wiper(s) switch(es) on the ICE PROTECTION panel.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-40-1. 1



30-40-2-1

Interval	Installed	Required	Procedure
A	3	1	NIL

- The flight is not conducted in known or forecast icing conditions, and
- Repairs are made within three flight days.

NOTE: All three Windshield Heaters must be operative for Low Visibility Takeoff operation.

Placard

Inoperative WINDSHIELD/Heaters must be placarded on the ICE PROTECTION Panel.
Illuminated WSHLD CTRL Caution Light must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard appropriate WINDSHIELD/Heater Switch(es) on the ICE PROTECTION Panel.
2. Make appropriate entry in the aircraft journey log.

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-40-2 Windshield Heaters****30-40-2-2 Co-Pilot Heated Windshield (Right Hand Windshield)**

Interval	Installed	Required	Procedure
A	1	0	(M#)(O)

May be inoperative for one day provided:

- The Pilot's Side Window heating is operative,
- The Pilot Windshield (Left Hand Windshield) heating is verified operative prior to dispatch, and
- The flight is conducted in accordance with AFM Supplement 114, "OPERATION WITH ONE WINDSHIELD HEATING SYSTEM INOPERATIVE".

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative WINDSHIELD/Heaters must be placarded on the ICE PROTECTION Panel. Illuminated WSHLD CTRL Caution Light must be placarded in the flight compartment.

Operating Procedures

The flight is conducted in accordance with AFM supplement 114, "OPERATION WITH ONE WINDSHIELD HEATING SYSTEM INOPERATIVE".

NOTE: "Warm up mode may not be available".

Maintenance Procedures

- Prior to dispatch, interrogate the CDS. If the message displayed on the maintenance screen is "RIGHT WSHLD CTRL FAIL", Step 2 is not required, otherwise do all steps. Aircraft dispatch is possible only if Pilot Side Window Anti-Icing System" is verified operative (pending outside temperature) by either:
 - "Operational Test of the Copilot Windshield and Pilot Side Window Anti-icing System", AMM TASK 30-41-00-710-802.

or

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-40-2. 2



DHC-8-402

MINIMUM EQUIPMENT LIST

ICE AND RAIN PROTECTION

ATA 30

30-40-2 Windshield Heaters

30-40-2-2 Co-Pilot Heated Windshield (Right Hand Windshield)

- b) "Electrical Resistance Check of the Pilot Side Window", AMM TASK 30-41-00-760-802.
- 2. Verify "Left Windshield Anti-Icing System" is operative (pending outside temperature) by either:
 - a) "Operational Test of the Pilot Windshield Anti-icing System", AMM TASK 30-41-00-710-801.
- Or
- b) "Electrical Resistance Check of the Windshield", AMM TASK 30-41-00-760-801.
- 3. If required, pull and collar appropriate circuit breaker for the inoperative heater.
- 4. Placard appropriate Windshield on the ICE PROTECTION Panel.
- 5. Placard the illuminated WSHLD CTRL Caution Light on the Caution Warning Panel.
- 6. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-40-2. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-60-1 Propeller De-icing System**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative propeller de-icing system must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative propeller de-icing system on the ICE PROTECTION panel.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-60-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-60-2 PROPS Heat Advisory Lights****30-60-2-1**

Interval	Installed	Required	Procedure
B	2	0	(O)

May be inoperative provided:

- AC LOAD indication is operating and periodically monitored, and
- The PROP DEICE caution light is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Propeller Heat Advisory light(s) must be placarded in the flight compartment.

Operating Procedures

AC load indication is periodically monitored.

Maintenance Procedures

- Placard inoperative Propeller Head Advisory light(s) on the ICE PROTECTION panel.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-60-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-60-2 PROPS Heat Advisory Lights****30-60-2-2**

Interval	Installed	Required	Procedure
C	2	0	(O)

May be inoperative provided flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Propeller Heat Advisory light(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative Propeller Head Advisory light(s) on the ICE PROTECTION panel.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-60-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-80-1 Ice Detector Spigot Illumination Lights****30-80-1-1**

Interval	Installed	Required	Procedure
C	2	1	NIL

One may be inoperative at either the pilot's or co-pilot's position.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Ice Detector Light(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative W/S WIPER ICE DETECT switches on pilot and co-pilot's side console panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-80-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-80-1 Ice Detector Spigot Illumination Lights****30-80-1-2**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative for day operations.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Ice Detector Light(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative W/S WIPER ICE DETECT switches on pilot and co-pilot's side console panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-80-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-80-1 Ice Detector Spigot Illumination Lights****30-80-1-3**

Interval	Installed	Required	Procedure
A	2	0	(M)

May be inoperative for night operations for one flight day provided:

- Both Ice Detector Probes are operative,
- The flight is not conducted in known or forecast icing conditions, and
- A flashlight of adequate capacity is available and confirmed operable prior to each flight.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Ice Detector Light(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

Interrogate CDS through ARCDU using the following procedure as follows to verify no ICE DETECTOR FAIL message displayed.

- Energize electrical system.
- Put the aircraft in weight on wheels condition.
- Open the access door for the maintenance panel.
- On the maintenance panel, set the CDS GND MAINT switch to the CDS GND MAINT position and make sure the CDS GND MAINT light comes on.
- On the maintenance panel, set the rotary switch to the OFF position. On the ARCDU, set the OFF/ON/BOTH/FMS switch to the ON position.

NOTE: Only one ARCDU can be used for the CDS at a time.

- On the ARCDU, push the MAINT switch.

NOTE: The ARCDU display shows the CDS main menu as follows:

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-80-1. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-80-1 Ice Detector Spigot Illumination Lights****30-80-1-3**

AVIONICS

OTHER SYSTEMS

AVIONIC DATA

7. On the ARCDU, push the key adjacent to the OTHER SYSTEMS legend.

NOTE: The ARCDU display show the OTHER SYSTEMS page 1/2 as follows:

EMU

ANTI SKID

FCS

ICE PROTECTION

ECS

APU

TMCU 1

TMCU 2

8. On the ARCDU, push the key adjacent to the ICE PROTECTION legend to show the IRPS–MAINTENANCE page.

NOTE:

1. The IRPS–MAINTENANCE page can show a maximum of 10 faults at one time. There are 30 possible faults. Refer to Figure 30–80–1–1 below.
2. The faults are prioritized to make sure the most important fault is shown first.
3. If no faults are reported, the IRPS–MAINTENANCE page will show a NO FAULT REPORTED message.
4. The CYCLES COUNTER at the bottom of the ARCDU display shows the number of times the airframe deice system has gone through the deice sequence. This number cannot be reset. After the highest number (99999) is reached the number goes to 00000.
9. To understand the fault messages, use Table 1: IRPS–MAINTENANCE message table.
10. On the ARCDU, push the DIM/RTN key again and again until the ARCDU display shows the first main menu.
11. On the ARCDU, set the OFF/ON/BOTH/FMS switch to the OFF position.
12. On the maintenance panel, set the CDS GND MAINT switch to the down position and make sure the CDS GND MAINT light goes off.
13. Close access door for maintenance panel.
14. De–energize electrical system.
15. Make appropriate entry in the aircraft journey log.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-80-1. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-80-1 Ice Detector Spigot Illumination Lights****30-80-1-3**

FAULT MESSAGE	PRIORITY
LEFT AOA FAIL	1
RIGHT AOA FAIL	2
PILOT 1 FAIL	3
PILOT 2 FAIL	4
PILOT STBY FAIL	5
LEFT WSHLD CTRL FAIL	6
RIGHT WSHLD CTRL FAIL	7
ARINC INPUT FAIL	8
TIMER INPUT FAIL	9
ENG ADAPT SWITCHING	10
MONITOR 1 FAIL	11
MONITOR 2 FAIL	12
TIMER MONITOR 3 FAIL	13
L ENG ADAPTER HEATER 1 FAIL	14
R ENG ADAPTER HEATER 1 FAIL	15
L ICE DETECTOR FAIL	16
R ICE DETECTOR FAIL	17
HEATER DRIVER FAIL	18
LOW PRESSURE 4A FAIL	19
LOW PRESSURE 3A FAIL	20
LOW PRESSURE 1A FAIL	21
LOW PRESSURE 2A FAIL	22
LOW PRESSURE 5B FAIL	23
LOW PRESSURE 6A FAIL	24
LOW PRESSURE 5A FAIL	25
LOW PRESSURE 6B FAIL	26
LOW PRESSURE 3B FAIL	27
LOW PRESSURE 1B FAIL	28
LOW PRESSURE 2B FAIL	29
LOW PRESSURE 4B FAIL	30

Figure 30-80-1-1 CDS IRPS Fault Priority List**■ ■ ■ ■****ISS III R00****APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49**30-80-1. 5**

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-80-2 Ice Detector Probes (Electronic)****30-80-2-1**

Interval	Installed	Required	Procedure
A	2	1	(M)(O)

May be inoperative for thirty days.

Minimum Equipment List Procedures (MELP)**Placard**

Placard any unserviceable ICE DETECTOR PROBE(S) in the flight compartment.

Operating Procedures

Windshield wiper ice detection spigots must be used for ice detection.

Maintenance Procedures

1. As required, open and collar the failed IDP circuit breaker, L ICE DET or R ICE DET, on 115V AC VARIABLE FREQUENCY CB panel.
2. Placard the respective ICE DETECTOR PROBE "INOP" in the flight compartment.
3. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-80-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ICE AND RAIN PROTECTION******ATA 30*****30-80-2 Ice Detector Probes (Electronic)****30-80-2-2**

Interval	Installed	Required	Procedure
B	2	0	(M)(O)

Both may be inoperative provided:

- Windshield wipers are stored in the normal horizontal position,
- Both Ice Detector Spigot illumination lights are confirmed operative prior to night operations,
- Flight will be conducted in accordance with AFM Supplement Number 98, Operation with Both Ice Detector Probes (Electronic) Inoperative (ICE DETECT FAIL Caution Light Illuminated), and
- The flight is not conducted at night into known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Placard any unserviceable ICE DETECTOR PROBE(S) in the flight compartment.

Operating Procedures

- Windshield wipers to be stored in normal horizontal position.
- Both Ice Detector Spigot illumination lights are confirmed operative prior to night operations.
- Flight will be conducted in accordance with AFM Supplement Number 98, Operation With Both Ice Detector Probes (Electronic) Inoperative (Ice Detect Fail Caution Light Illuminated).

Maintenance Procedures

- As required, open and collar the failed IDP circuit breaker, L ICE DET or R ICE DET, on 115V AC VARIABLE FREQUENCY CB panel.
 - Placard the respective ICE DETECTOR PROBE "INOP" in the flight compartment.
 - Make appropriate entry in the aircraft journey log.
- ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

30-80-2. 2