

**DHC-8-402****MINIMUM EQUIPMENT LIST*****LANDING GEAR******ATA 32*****32-20-1 NOSE GEAR LOCK Advisory Light**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided Nose Gear Lock is verified disengaged prior to each departure.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Nose Gear Lock Advisory Light must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the Nose Gear Lock Advisory Light on the pilot's side panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

32-20-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****LANDING GEAR******ATA 32*****32-30-1 Landing Gear Retraction System**

Interval	Installed	Required	Procedure
A	1	0	(O)

Landing gear retraction system may be inoperative for one flight provided operations are conducted in compliance with AFM Supplement 94, OPERATION WITH LANDING GEAR EXTENDED.

Minimum Equipment List Procedures (MELP)**Placard**

Placard the gear retraction system inoperative at the Landing Gear Control Panel.

Operating Procedures

Operations are conducted in accordance with AFM Supplement 94, OPERATION WITH LANDING GEAR EXTENDED.

Maintenance Procedures

None required.

■ ■ ■ ■

ISS III R02

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

32-30-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****LANDING GEAR******ATA 32*****32-40-1 Parking Brake Pressure Indications****32-40-1-1 HYD PRESS PK BRK Indication**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- The Aft Wing Root Fairing Indicator is verified operative, and
- Brake pressure is confirmed adequate prior to engine start.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative HYD PRESS PK BRK in the flight compartment or ACCUMULATOR GAS CHARGE gauge in the right aft wing root fairing must be placarded.

Operating Procedures

None required.

Maintenance Procedures

- Cycle the Park Brake Lever 8 to 10 times to deplete pressure.
- Ensure that the ACCUMULATOR GAS CHARGE gauge located in the right wing root fairing indicates at least 500 psi.
- Placard inoperative HYD PRESS PK BRK Indicator in the flight compartment.
- Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DAT 0 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

32-40-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****LANDING GEAR******ATA 32*****32-40-1 Parking Brake Pressure Indications****32-40-1-2 Aft Wing Root Fairing Indicator**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided:

- The HYD PRESS PK BRAKE Indication is verified operative, and
- Brake pressure is confirmed adequate prior to engine start.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative HYD PRESS PK BRK in the flight compartment or ACCUMULATOR GAS CHARGE gauge in the right aft wing root fairing must be placarded.

Operating Procedures

None required.

Maintenance Procedures

- Ensure that the HYD PRESS PK BRK indicator on the MRD in the flight compartment indicates at least 1500 psi.

NOTE: If aircraft has been sitting for quite some time, the pressure may be depleted. In this case, use the hand pump in right wheel well and pump up the system.

- Placard inoperative ACCUMULATOR GAS CHARGE gauge in the flight compartment and on the gauge in the right aft wing root fairing.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

32-40-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****LANDING GEAR******ATA 32*****32-40-2 Anti-Skid System**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided operations are conducted in compliance with AFM Supplement 7 OPERATION WITH INOPERATIVE ANTI-SKID BRAKE CONTROL SYSTEM.

NOTE: Anti-skid system must be operative for Monsoon and Low Visibility Take-off operations.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Anti-Skid System must be placarded in the flight compartment.

Operating Procedures

1. Operations are conducted in accordance with AFM Supplement 7 OPERATION WITH INOPERATIVE ANTI-SKID BRAKE CONTROL SYSTEM.
2. Select ANTI SKID switch to OFF at co-pilot's glareshield panel.

Maintenance Procedures

1. Placard Anti-Skid System at ANTI SKID TEST switch on glareshield panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

32-40-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****LANDING GEAR******ATA 32*****32-50-1 Nosewheel Steering**

Interval	Installed	Required	Procedure
A	1	0	(M)(O)

May be inoperative for one flight day provided:

- NOSE STEERING caution light is extinguished when the nosewheel STEERING switch is in the OFF position,
- Nosewheel STEERING switch is selected and remains OFF,
- Nosewheel steering system is deactivated, and
- Operations are conducted in compliance with AFM Supplement 8 OPERATION WITH INOPERATIVE NOSEWHEEL STEERING SYSTEM.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Nosewheel Steering system must be placarded in the flight compartment.

Operating Procedures

- Ensure nosewheel STEERING switch is selected OFF and the NOSE STEERING caution light is extinguished.
- Operations are conducted in accordance with AFM Supplement 8 OPERATION WITH INOPERATIVE NOSEWHEEL STEERING SYSTEM.

NOTE: Nosewheel will caster. Take-off or landing in crosswinds exceeding 25 knots is not permitted.

Maintenance Procedures

- Pull and clip circuit breakers NLG STEER CONT on the L MAIN and the R MAIN circuit breaker panels.
- Placard nosewheel steering switch on pilot's left side console in the flight compartment and placard the NOSE STEERING caution light.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATE -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

32-50-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****LANDING GEAR******ATA 32*****32-60-1 Touched Runway Indication System**

Interval	Installed	Required	Procedure
C	1	0	(M)

May be inoperative provided prior to each flight, it is confirmed that the frangible switch has not been contacted.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Touched Runway Indication System must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Prior to flight, inspect the underside of rear fuselage in the vicinity of frangible switch and ensure that:
 - a) there is no evidence that the frangible switch shroud (and switch) has been scraped or broken, and
 - b) there is no visible sign of scrape damage to fuselage.
2. If visual inspection of underside of rear fuselage reveals signs of damage, perform FRANGIBLE SWITCH LIGHT "ON" Inspection as per Dash 8 Series 400 Aircraft Maintenance Manual, Chapter 5, for signs of structural damage. If there is no evidence of structural damage, scraped fuselage/paint abrasion may be temporarily repaired with 3M No. Y434 or equivalent Metal Speed Tape. This taped surface must be thereafter inspected prior to each flight as per Operating Procedures above.
3. If the TOUCHED RUNWAY Warning light has failed in the illuminated condition, at the Caution and Warning Panel, remove the front lens module containing the TOUCHED RUNWAY Warning legend, then remove the respective 4 LEDs. Re-install the lens module.
4. Placard TOUCHED RUNWAY warning light at the Caution and Warning Panel in the flight compartment.
5. Make appropriate entry in the aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

32-60-1. 1