

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-10-1 Altitude Alerting System**

Interval	Installed	Required	Procedure
A	1	0	(O)

May be inoperative provided:

- Autopilot with ALT hold is verified operative, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Altitude Alerting System must be placarded in the flight compartment.

Operating Procedures

With electrical power applied, adequate to support both MAIN busses, at the flight guidance controller, select ALT mode and observe that "ALT" is displayed in the FMA area of both PFDs. Increased awareness of aircraft altitude must be exercised.

Maintenance Procedures

- Placard the Flight Guidance Control Panel with "Altitude Pre-select INOP".
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-10-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-1 Standby Magnetic Compass****34-20-1-1**

Interval	Installed	Required	Procedure
B	1	0	NIL

May be inoperative provided any combination of three gyro (or INS (IRU)) stabilized compass systems are operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Standby Magnetic Compass in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the Standby Compass located below the Caution Lights panel.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-1 Standby Magnetic Compass****34-20-1-2**

Interval	Installed	Required	Procedure
B	1	0	NIL

May be inoperative provided:

- a) Any combination of two gyro (or INS (IRU)) stabilized compass systems are operative, and
- b) Aircraft is operated:
 - i) With dual independent navigation capability, and
 - ii) Under positive radar control by ATC during the enroute flight phase, or one of the navigation systems is a TSO'd GPS which provides track information.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Standby Magnetic Compass in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the Standby Compass located below the Caution Lights panel.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-1 Standby Magnetic Compass****34-20-1-3**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative for flights that are entirely within areas of magnetic unreliability provided at least two stabilized directional gyro systems are installed, are operative, and if necessary, used in conjunction with approved free gyro navigation techniques.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Standby Magnetic Compass in the flight compartment.

Operating Procedures

Operations in areas of magnetic unreliability require that at least two stabilized directional gyro systems operate normally and, if necessary, used in accordance with approved free-gyro navigation techniques.

Maintenance Procedures

1. Placard the Standby Compass located below the Caution Lights panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DAT 00 -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-1. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-2 Standby Attitude Indicator**

Interval	Installed	Required	Procedure
B	1	0	(O)

May be inoperative for day VMC provided:

- The instrument face is covered, and
- Operation is not conducted into known or forecast VFR OTT (Over the Top) conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Standby Attitude Indicator in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard the Standby Attitude Indicator on the Engine Panel.
- Use appropriate means to cover a face of instrument.
- Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-3 IVSI Indications (on PFDs)**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative for day VMC.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Vertical Speed Indication (VSI) in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the relevant glareshield.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-4 AHRS Control Panel Indicators****34-20-4-1 DG Indicators**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative provided switching function is operative for DG Indicator.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Attitude Heading Reference System Control Panel (AHRSCP) indicators must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the AHRS Control Panel with "XXX Indicator INOP".
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-4 AHRS Control Panel Indicators****34-20-4-2 ALIGN Indicators**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative provided switching function is operative for ALIGN Indicator.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Attitude Heading Reference System Control Panel (AHRSCP) indicators must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the AHRS Control Panel with "XXX Indicator INOP".
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-4. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-4 AHRS Control Panel Indicators****34-20-4-3 SLAVE Indicators**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative provided switching function is operative for SLAVE Indicator.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Attitude Heading Reference System Control Panel (AHRSCP) indicators must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the AHRS Control Panel with "XXX Indicator INOP".
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-4. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-4 AHRS Control Panel Indicators****34-20-4-4 BASIC Indicators**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative provided switching function is operative for BASIC Indicator.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Attitude Heading Reference System Control Panel (AHRSCP) indicators must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the AHRS Control Panel with "XXX Indicator INOP".
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-4. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-5 Flux Valves**

Interval	Installed	Required	Procedure
B	2	1	NIL

May be inoperative provided:

- The opposite Attitude Heading Reference Unit is operative,
- The Standby Magnetic Compass is operative,
- The AHRS on the affected side is operated in DG mode,
- Flight is restricted to DAY VMC, and
- DG Slew Mode is confirmed operative.

NOTE: CAT II Operation not permitted.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Flux Valve must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard the glareshield with "AHRS 1/2 DG MODE ONLY".
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-6 Integrated Standby Instrument
(CR839CH00013)****34-20-6-1 Attitude / Slip Skid Function**

Interval	Installed	Required	Procedure
B	1	0	NIL

May be inoperative for day VMC.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Integrated Standby Instrument attitude function and/or inoperative Integrated Standby Instrument STD Button must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard space adjacent to the Integrated Standby Instrument with "ATT Function INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-6. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-20-6 Integrated Standby Instrument
(CR839CH00013)****34-20-6-2 STD (Standard) Button**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Integrated Standby Instrument attitude function and/or inoperative Integrated Standby Instrument STD Button must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard space adjacent to the Integrated Standby Instrument with "STD Button INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-20-6. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-1 Weather Radar System**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided flights are not conducted in known or forecast bad weather conditions. Weather at origin, enroute, destination and alternate airport are reported clear.

NOTE: Monsoon Operations not permitted.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Weather Radar System (WX RDR) in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the EFIS Control Panels in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-2 Traffic Alert and Collision Avoidance System (TCAS)****34-40-2-1 Traffic Alert and Collision Avoidance System (TCAS)**

Interval	Installed	Required	Procedure
A	1	0	(M)

May be inoperative for 36 hours or first visit to the base station whichever is earlier provided system is deactivated and secured.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Traffic Collision Avoidance System in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Pull and clip the TCAS circuit breaker on Avionics Panel.
2. Placard the relevant Glareshield.
3. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-2 Traffic Alert and Collision Avoidance System (TCAS)****34-40-2-2 Combined Traffic Alert (TA) and Resolution Advisory (RA) Dual Displays**

Interval	Installed	Required	Procedure
C	2	1	(O)

May be inoperative on the non-flying pilot side provided TA and RA elements and audio functions are operative on flying pilot side.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Traffic Collision Avoidance System in the flight compartment.

Operating Procedures

1. Verify that Traffic Alerts (TA) and Resolution Advisories (RA) on flying pilot's side operate normally.
2. Verify that TA and RA indications are visible to the non-flying pilot.
3. Verify that audio functions operate normally.

Maintenance Procedures

1. Placard inoperative TA and RA Dual Displays.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-2. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-2 Traffic Alert and Collision Avoidance System (TCAS)****34-40-2-3 RA Display System(s)****34-40-2-3A**

Interval	Installed	Required	Procedure
C	2	1	(O)

May be inoperative on the non-flying pilot side.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Traffic Collision Avoidance System in the flight compartment.

Operating Procedures

Verify that Traffic Alert (TA) and remaining operable Resolution Advisory (RA) on flying pilot's side operate normally.

Maintenance Procedures

1. Placard inoperative RA Display System(s).
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-2. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-2 Traffic Alert and Collision Avoidance System (TCAS)****34-40-2-3 RA Display System(s)****34-40-2-3B**

Interval	Installed	Required	Procedure
C	2	0	(O)

May be inoperative provided:

- All Traffic Alert (TA) display elements and voice command audio functions are operative, and
- TA ONLY mode is selected by the crew.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Traffic Collision Avoidance System in the flight compartment.

Operating Procedures

Use TCAS Mode Selection on the ARCDU to select TA only operation. Verify "TA ONLY" is annunciated on MFDs.

Maintenance Procedures

- Placard inoperative RA Display System(s).
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-2. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-2 Traffic Alert and Collision Avoidance System (TCAS)****34-40-2-4 TA Display System(s)**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided all installed RA display and audio functions are operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Traffic Collision Avoidance System in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative TA Display System(s).
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-2. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-3 RA Height Indications (on PFDs)****34-40-3-1**

Interval	Installed	Required	Procedure
B	2	0	(O)

May be inoperative provided:

- A minimum of one RAD ALT is operative, and
- Approach minimums and operating procedures are not dependent on their use.

NOTE: RNP APCH (LNAV or LNAV/VNAV or LPV) operations not permitted.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Radio Altitude Height Indication(s) must be placarded in the flight compartment.

Operating Procedures

RNP APCH (LNAV or LNAV/VNAV or LPV) procedures which require the use of RA height indication on the PFD are not authorized.

Maintenance Procedures

- Placard the affected PFD(s) with "RAD ALT DISPLAY INOP".
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R05**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-3 RA Height Indications (on PFDs)****34-40-3-2**

Interval	Installed	Required	Procedure
C	2	1	(O)

May be inoperative provided approach minimums and operating procedures are not dependent on its use.

NOTE: RNP APCH (LNAV or LNAV/VNAV or LPV) operations not permitted.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Radio Altitude Height Indication(s) must be placarded in the flight compartment.

Operating Procedures

RNP APCH (LNAV or LNAV/VNAV or LPV) procedures which require the use of RA height indication on the PFD are not authorized.

Maintenance Procedures

1. Placard the affected PFD(s) with "RAD ALT DISPLAY INOP".
2. Make appropriate entry in the aircraft journey log.

— — — —

ISS III R05**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-3. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)**

Interval	Installed	Required	Procedure
A	1	0	(O)

May be inoperative provided:

- Alternate procedures are established and used, and
- Repairs are made within three flight days.

NOTE:

- CAT II, RNP APCH (LNAV or LNAV/VNAV or LPV), and Monsoon operations not permitted.
- LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Ground Proximity Warning System (GPWS) or Enhanced Ground Proximity Warning System (EGPWS), as applicable in the flight compartment.

Operating Procedures

- Ensure other aircraft equipment like VOR, DME and Altimeters fully serviceable and no other instrument failure occurs associated with it.
- Determine and raise Minimum Operating Altitude (MOA) for departure and destination aerodromes and route MORA for different segments of the route and be aware which segment of route contributes to highest MORA.
- Brief First Officer in detail about the procedures to be followed during takeoff cruise and descend approach.
- The flight should be flown by the commander even if cleared to assist First Officer for takeoff and landing.

TAKEOFF: Do not takeoff in wind shear or marginal weather conditions where you will not have terrain in sight. Climb above MSA within 25NM or stated distance from the facility for MSA. If GPWS warning triggers, correlate it with terrain, altitude, ROC and aircraft configuration. Take appropriate action if required.

*(...Continued)***ISS III R05****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 1

34-40-4	Ground Proximity Warning System (GPWS) / Enhanced Ground Proximity Warning System (EGPWS)
----------------	--

DURING CRUISE: If a descent has to be carried out due to loss of engine power or emergency descent requirements, do not descend below MORA.

DESCENT AND APPROACH:

- a) Apart from a thorough briefing the following guidelines should be kept in mind for a safe approach.
- b) Do not descend below MSA if more than the stated distance from the determining facility.
- c) Hold O/H the facility if weather is marginal or wind shear is reported. Proceed and land at alternate if weather continues to be bad.
- d) If any doubt about any condition on approach initiate go around. Review go around action during approach briefing.
- e) Do not descend below MSA till on instrument approach procedure and established on required radials, or unless terrain is visual below 1500 AGL to cater to “terrain” warning.
- f) Meticulously fly correct ILS profile or, if a VOR, DME approach, DME altitude profile.
- g) Ensure gear locked down and landing configuration. Flaps extension by FAF to cater to spurious “too low gear / flaps” warning.
- h) Cross check all three altimeters for altitude and RA.
- i) Recheck at 500 feet correct landing configuration, landing check list, landing lights and landing clearance.

Maintenance Procedures

1. Placard the pilot's / co-pilot's glareshield as applicable.
2. Make appropriate entry in the aircraft journey log.

NOTE: TAWS Enhanced Mode may be inoperative due to an inoperative Global Positioning System (GPS) resulted from FMS1 and FMS2 (if installed) failures. In this case, inoperative GPS procedures on item 34-50-6 must also be applied.

■■■■

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-1 Modes 1 to 4**

Interval	Installed	Required	Procedure
A	1	0	(O)

May be inoperative provided:

- Alternate procedures are established and used, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Ground Proximity Warning System (GPWS) or Enhanced Ground Proximity Warning System (EGPWS), as applicable in the flight compartment.

Operating Procedures

If Modes 1 thru 4 are inoperative:

- Two VHF Navigation Systems must operate normally.
- Perform following for corresponding Mode failure.

MODE 1: Excessive Rate of Descent.

The Pilot Monitoring (PM) will monitor the height indicated on the Radio Altimeter (RADALT) and Rate of Descent (ROD) indicated on the Vertical Speed Indicator (VSI) and:

Call "SINK RATE" when the ROD increases to equal the height on the RADALT. For example, ROD increasing to 1500 feet per minute (fpm) ROD passing 1500 feet RADALT. Call "PULL UP" when the ROD increases to double the height on the RADALT. For example, ROD increasing to 3000 fpm ROD passing 1500 feet RADALT.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 3



34-40-4-1 Modes 1 to 4

34-40-4. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-2 Test Mode**

Interval	Installed	Required	Procedure
A	1	0	NIL

May be inoperative provided:

- The GPWS/EGPWS is considered inoperative, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Ground Proximity Warning System (GPWS) or Enhanced Ground Proximity Warning System (EGPWS), as applicable in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard the pilot's / co-pilot's glareshield as applicable.
- Make appropriate entry in the aircraft journey log.

NOTE: TAWS Enhanced Mode may be inoperative due to an inoperative Global Positioning System (GPS) resulted from FMS1 and FMS2 (if installed) failures. In this case, inoperative GPS procedures on item 34-50-6 must also be applied.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-3 Flap Override Function**

Interval	Installed	Required	Procedure
A	1	0	NIL

May be inoperative provided:

- The GPWS/EGPWS flap aural warning is operative, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Placard on or near the inoperative Flap Override Switch in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Inoperative Flap Override Switch, switch lights and/or switch cover must be placarded near the FLAP OVERRIDE switch in the flight compartment.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-3 Flap Override Function****34-40-4-3A GPWS FLAP OVERRIDE Switch Lights****34-40-4-3A-1**

Interval	Installed	Required	Procedure
A	1	0	NIL

“Cross-hatch” indication may be inoperative provided:

- Switch cover is closed,
- Flap Override function is considered inoperative, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Placard on or near the inoperative Flap Override Switch in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Inoperative Flap Override Switch, switch lights and/or switch cover must be placarded near the FLAP OVERRIDE switch in the flight compartment.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 7

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-3 Flap Override Function****34-40-4-3A GPWS FLAP OVERRIDE Switch Lights****34-40-4-3A-2**

Interval	Installed	Required	Procedure
C	1	0	NIL

“GPWS FLAP OVERRIDE” portion of the indication may be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard on or near the inoperative Flap Override Switch in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Inoperative Flap Override Switch, switch lights and/or switch cover must be placarded near the FLAP OVERRIDE switch in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 8

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-3 Flap Override Function****34-40-4-3B GPWS FLAP OVERRIDE Switch Cover****34-40-4-3B-1**

Interval	Installed	Required	Procedure
A	1	0	NIL

Switch cover may be inoperative in the closed position provided:

- Flap Override function is considered inoperative, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Placard on or near the inoperative Flap Override Switch in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Inoperative Flap Override Switch, switch lights and/or switch cover must be placarded near the FLAP OVERRIDE switch in the flight compartment.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 9

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-3 Flap Override Function****34-40-4-3B GPWS FLAP OVERRIDE Switch Cover****34-40-4-3B-2**

Interval	Installed	Required	Procedure
C	1	0	(O)

Switch cover may be missing or inoperative in the open (Non-return) position provided the GPWS FLAP OVERRIDE switch is monitored for inadvertent switch operation.

Minimum Equipment List Procedures (MELP)**Placard**

Placard on or near the inoperative Flap Override Switch in the flight compartment.

Operating Procedures

Procedures have to be established and used for pilot to monitor prior to approach or takeoff that the Flap Override Switch has not inadvertently been operated into a configuration that contradicts intended flight configuration.

Maintenance Procedures

1. Inoperative Flap Override Switch, switch lights and/or switch cover must be placarded near the FLAP OVERRIDE switch in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 10

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-4 Glidescope Deviation (Mode 5)**

Interval	Installed	Required	Procedure
B	1	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Ground Proximity Warning System (GPWS) or Enhanced Ground Proximity Warning System (EGPWS), as applicable in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the pilot's / co-pilot's glareshield as applicable.
2. Make appropriate entry in the aircraft journey log.

NOTE: TAWS Enhanced Mode may be inoperative due to an inoperative Global Positioning System (GPS) resulted from FMS1 and FMS2 (if installed) failures. In this case, inoperative GPS procedures on item 34-50-6 must also be applied.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATE -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 11



34-40-4-5 Minimums Alert (Mode 6)

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative provided alternate procedures are established and used.

Minimum Equipment List Procedures (MELP)

Placard

Placard inoperative Ground Proximity Warning System (GPWS) or Enhanced Ground Proximity Warning System (EGPWS), as applicable in the flight compartment.

Operating Procedures

The Pilot Monitoring (PM) will monitor the height indicated on the ALTITUDE TAPE and:

Call "MINIMUMS, MINIMUMS" when passing through "DH" setting.

The Pilot Monitoring (PM) will monitor the bank angle and: Call “BANK ANGLE” if bank angle increases above 40 degrees at or above 300 feet AGL AND Call “BANK ANGLE” if bank angle increases above 12 degrees near ground level.

Maintenance Procedures

1. Placard the pilot's / co-pilot's glareshield as applicable.
2. Make appropriate entry in the aircraft journey log.

NOTE: TAWS Enhanced Mode may be inoperative due to an inoperative Global Positioning System (GPS) resulted from FMS1 and FMS2 (if installed) failures. In this case, inoperative GPS procedures on item 34-50-6 must also be applied.

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-6 TAWS Enhanced Mode****34-40-4-6A**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative Ground Proximity Warning System (GPWS) or Enhanced Ground Proximity Warning System (EGPWS), as applicable in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the pilot's / co-pilot's glareshield as applicable.
2. Make appropriate entry in the aircraft journey log.

NOTE: TAWS Enhanced Mode may be inoperative due to an inoperative Global Positioning System (GPS) resulted from FMS1 and FMS2 (if installed) failures. In this case, inoperative GPS procedures on item 34-50-6 must also be applied.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 13

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-7 Ground Proximity Warning System (GPWS) Landing Flap
Selection Switch (LFSS) Indication Lights**

Interval	Installed	Required	Procedure
C	3	-	(O)

May be inoperative provided alternate procedures are established and used.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative GPWS Landing Flap Selection Switch indication light in the flight compartment.

Operating Procedures

Placarding will be done by engineering adjacent to the inoperative lights with Flaps 10, 15, 35 markings.

Pilots to confirm the GPWS Landing Flaps selection switch position with reference to the placard. Confirm the GPWS Landing Flaps switch position with cockpit Lights "ON" in case of night operations.

Maintenance Procedures

1. Placard the inoperative GPWS Landing Flap Selection Switch indication light in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 15

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-40-4 Ground Proximity Warning System (GPWS) /
Enhanced Ground Proximity Warning System
(EGPWS)****34-40-4-8 Steep Approach Mode (803SO90034)****34-40-4-8A**

Interval	Installed	Required	Procedure
D	1	0	(O)

May be inoperative provided:

- "STD" portion of the "STD/STEEP" FLAP 35 APPROACH switch indication lights on the hydraulic/flap override control panel is illuminated,
- Operating procedures are not dependent on its use,
- "STD/STEEP" FLAP 35 APPROACH switch on the hydraulic/flap override control panel is placarded, "INOPERATIVE", and
- Steep Approaches are not to be conducted.

Minimum Equipment List Procedures (MELP)**Placard**

Placard the "STD/STEEP" FLAP 35 APPROACH switch on the hydraulic/flap override control panel "INOPERATIVE" for inoperative Steep Approach Mode.

Operating Procedures

Verify the "STD" indication on the "STD/STEEP" FLAP 35 APPROACH switch illuminates when selected.

Maintenance Procedures

- Placard the "STD/STEEP" FLAP 35 APPROACH switch on the hydraulic/flap override control panel.
- Make appropriate entry in the aircraft journey log.

■■■■**ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 16

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34**

- 34-40-4 Ground Proximity Warning System (GPWS) / Enhanced Ground Proximity Warning System (EGPWS)**
- 34-40-4-8 Steep Approach Mode (803SO90034)**
- 34-40-4-8B “STD/STEEP” FLAP 35 APPROACH switch indication lights (On Hydraulic/flap Override Control Panel)**

Interval	Installed	Required	Procedure
C	1	0	(O)

One indication (STD or STEEP) may be inoperative and Steep Approach may be conducted provided:

- Prior to first flight each day, Standard and Steep Approach Mode selection is verified operative, and
- Placard the appropriate inoperative indication below the “STD/STEEP” FLAP 35 APPROACH switch.

Minimum Equipment List Procedures (MELP)**Placard**

Placard the “STD/STEEP” FLAP 35 APPROACH switch on the hydraulic/flap override control panel for the appropriate inoperative “STD/STEEP” indication lights.

Operating Procedures

Prior to first flight of the day, verify Standard / Steep Approach Mode is operative:

- Set flaps selector handle to 35 degrees.
- Press “STD/STEEP” FLAP 35 APPROACH switch on the hydraulic / flap override control panel. Check whether Case a) or b) is applicable.
 - If aural annunciation is NOT heard, Steep Approach function is considered inoperative.
 - If aural annunciation heard, continue to step 3.

*(...Continued)***ISS III R00****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 17

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34***

34-40-4	Ground Proximity Warning System (GPWS) / Enhanced Ground Proximity Warning System (EGPWS)
34-40-4-8	Steep Approach Mode (803SO90034)
34-40-4-8B	“STD/STEEP” FLAP 35 APPROACH switch indication lights (On Hydraulic/flap Override Control Panel)

3. Press “STD/STEEP” FLAP 35 APPROACH switch on the hydraulic/flap override control panel. If aural annunciation of “STEEP APPROACH NOT SELECTED” is NOT heard, “GPWS/EGPWS” is considered inoperative.

Maintenance Procedures

1. Placard the “STD/STEEP” FLAP 35 APPROACH switch on the hydraulic/flap override control panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-4. 18

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-5 GPWS I/F FAIL Engine Display Message**

Interval	Installed	Required	Procedure
B	1	0	(M)

Message may be displayed provided GPWS is considered inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative GPWS must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. At the Avionics circuit breaker panel, pull and clip breaker GPWS (A1).
2. Placard the pilot's/co-pilot's Glareshield with "GPWS INOP".
3. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-5. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-6 Radio Altimeters****34-40-6-1**

Interval	Installed	Required	Procedure
A	2	0	(M)(O)

May be inoperative for two flight days provided:

- GPWS/EGPWS is considered inoperative,
- TCAS is considered inoperative,
- Weather minimums or operating procedures are not dependent on use of both,
- Operations are conducted in compliance with AFM SUPPLEMENT 11, OPERATION WITH ONE INOPERATIVE STALL WARNING AND/OR STICK PUSHER SYSTEM,
- Operations are conducted in compliance with AFM SUPPLEMENT 37, SUPPLEMENTARY PERFORMANCE INFORMATION FOR OPERATION ON CONTAMINATED RUNWAYS, and
- Operations are conducted in compliance with AFM SUPPLEMENT 39, NOISE ABATEMENT PROCEDURES AND PERFORMANCE (LANDING WITH 850 PROPELLER RPM), if applicable.

NOTE:

- In the absence of both Radio Altimeters, use the Barometric Altimeters for all height indications.
- With RAD ALT #1 disabled, landing gears not down and locked, PLA 1 and PLA 2 below Flight Idle + 12° and CAS below 156 Knots, Landing Gear Warning Horn will enable.
- RNP APCH (LNAV or LNAV/VNAV or LPV) and CAT II operations not permitted.
- LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative radio altimeter(s) must be placarded in the flight compartment.

Operating Procedures

NOTE: For operations where Radio Altimeter #1 is disabled as per the MMEL, the Landing Gear Warning Tone/Horn will sound when the aircraft drops below 156 Knots and either PLA 1 or PLA 2 is less than Flight Idle + 12° with landing gears not down and locked.

(...Continued)

ISS III R05**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-6. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-6 Radio Altimeters****34-40-6-1**

Operation is conducted in accordance with AFM Supplement 11 for Stick Pusher Inoperative, AFM Supplement 37 for Contaminated Runway, and AFM Supplement 39 for Landing with 850 RPM for noise abatement.

NOTE: GPWS/EGPWS and TCAS will be inoperative.

Maintenance Procedures

1. Pull and collar-clip the respective RAD ALT 1 and RAD ALT 2 circuit breaker(s), located on the Avionics Circuit Breaker Panel.
2. Pull and collar-clip the STICK PUSHER circuit breakers, located on the Avionics Circuit Breaker Panel.
3. Placard the glareshield with "RAD ALT #1 and RAD ALT #2 INOP" and "STICK PUSHER INOP".
4. Where applicable, pull and collar-clip the circuit breakers for GPWS/EGPWS, located on the Avionics Circuit Breaker Panel and placard the glareshield with "GPWS INOP".
5. Where applicable, pull and collar-clip the circuit breakers for TCAS located on the Avionics Circuit Breaker Panel and placard the glareshield with "TCAS INOP".
6. Make the appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-6. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-40-6 Radio Altimeters****34-40-6-2**

Interval	Installed	Required	Procedure
C	2	1	(M)(O)

One may be inoperative.

NOTE:

1. If RAD ALT #1 is disabled, landing gears not down and locked, PLA 1 and PLA 2 below Flight Idle + 12° and CAS below 156 Knots, Landing Gear Warning Horn will enable.
2. RNP APCH (LNAV or LNAV/VNAV or LPV) and CAT II operations not permitted.
3. LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative radio altimeter(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the glareshield with "RAD ALT #1 INOP" for inoperative No. 1 Radio Altimeter or "RAD ALT #2 INOP" for inoperative No 2 Radio Altimeter.
2. Pull and collar/clip the appropriate circuit breaker RAD ALT 1 or RAD ALT 2 located on the Avionics circuit breaker panel.
3. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R05**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-40-6. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-1 ATC Transponder / Altitude Reporting System****34-50-1-1 ATC Transponders****34-50-1-1A**

Interval	Installed	Required	Procedure
C	2	1	(O)

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative ATC Transponder/Altitude Reporting System in the flight compartment.

Operating Procedures

NOTE: Same side FMS” is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

If one ATC is operative, at the ARCDU, switch to the operating transponder and ensure TCAS remains operative. If ADS-B Out function is installed and required, ensure function is operative as well.

Maintenance Procedures

1. Placard ATC Transponder/Altitude Reporting system on the glareshield.
2. Make appropriate entries in aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-1. 1

DHC-8-402

MINIMUM EQUIPMENT LIST

NAVIGATION

ATA 34

34-50-1 ATC Transponder / Altitude Reporting System

34-50-1-2 ATC Identifier Switch (on hand-wheels)

34-50-1-2A

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)

Placard

Placard inoperative ATC Identifier Switch (es) on the related Audio and Radio Control Display Unit (ARCDU).

Operating Procedures

NOTE: Same side FMS” is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the relevant ATC Identifier Switch (es) as "INOP" on the related Audio and Radio Control Display Unit (ARCDU).
2. Make appropriate entry in aircraft journey log.

☐ ☐ ☐ ☐

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid
DELHI, DATE -

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-1.3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-1 ATC Transponder / Altitude Reporting System****34-50-1-2 ATC Identifier Switch (on hand-wheels)****34-50-1-2B**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided one ATC ID button (on ARCDU1 or ARCDU2) is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative ATC Identifier Switch (es) on the related Audio and Radio Control Display Unit (ARCDU).

Operating Procedures

NOTE: Same side FMS” is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the relevant ATC Identifier Switch (es) as “INOP” on the related Audio and Radio Control Display Unit (ARCDU).
2. Make appropriate entry in aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-1. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-1 ATC Transponder / Altitude Reporting System****34-50-1-3 ATC ID Button (on ARCDU1 or ARCDU2)****34-50-1-3A**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative ATC ID button (s) on the ARCDU.

Operating Procedures**NOTE:** Same side FMS” is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the relevant ATC ID button (s) as “INOP” on the ARCDU.
2. Make appropriate entry in aircraft journey log.

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49**34-50-1. 5**

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-1 ATC Transponder / Altitude Reporting System****34-50-1-3 ATC ID Button (on ARCDU1 or ARCDU2)****34-50-1-3B**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided one ATC Identifier Switch (on hand-wheels) is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Placard inoperative ATC ID button (s) on the ARCDU.

Operating Procedures

NOTE: Same side FMS” is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the relevant ATC ID button (s) as “INOP” on the ARCDU.
2. Make appropriate entry in aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED –****Signature valid**

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-1. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-2 VHF Navigation Systems**

Interval	Installed	Required	Procedure
C	2	1	NIL

One not powered by an essential electrical bus may be inoperative provided VHF NAV is not the sole means of navigation and both ADF system operates normally and weather conditions allow use of ADFs.

NOTE:

1. #1 VHF NAV should be serviceable.
2. CAT II operations not permitted.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative VHF Navigation System must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the center glareshield panel with "VHF NAV #X INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-3****Distance Measuring Equipment (DME) System**

Interval	Installed	Required	Procedure
C	2	1	NIL

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Distance Measuring Equipment (DME) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the center glareshield indicating the inoperative DME system.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-3. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-3 Distance Measuring Equipment (DME) System****34-50-3-1 DME HOLD Function****34-50-3-2A**

Interval	Installed	Required	Procedure
A	2	0	(O)

May be in operative provide:

- Associated DME is operative,
- Alternate means are established and used to provide position and distance, and
- Repairs are made within three flight days.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DME HOLD key must be placarded.

Operating Procedures

Utilize DME in normal VOR/ILS mode.

Maintenance Procedures

- Placard inoperative DME HOLD key on adjacent affected ARCDU.
- Make appropriate entry in the aircraft journey log.

— — — —

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-3. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-3 Distance Measuring Equipment (DME) System****34-50-3-2 DME HOLD Function****34-50-3-2B**

Interval	Installed	Required	Procedure
C	2	1	NIL

May be inoperative provided the associated DME is operative.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative DME HOLD key must be placarded.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative DME HOLD key on adjacent affected ARCDU.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-3. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-4 Automatic Direction Finding (ADF) Systems**

Interval	Installed	Required	Procedure
C	2	1	NIL

One may be inoperative provided ADF is not the sole means of navigation and both VHF NAV system operates normally.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Automatic Direction Finding (ADF) Systems must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard the glareshield with "ADF #X INOP".
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R00**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-4. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-5 Marker Beacon****34-50-5-1 If used routinely**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative provided alternate procedures are established and used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Marker Beacon System(s) must be placarded in the flight compartment.

Operating Procedures

Provided no instrument approach that requires its use is carried out. For ILS approach (only) DME may be used in lieu of outer marker if authorized.

Maintenance Procedures

1. Placard the glareshield with "Marker 1 / 2 INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-5. 1



34-50-6-1A

Interval	Installed	Required	Procedure
C	2	0	(O)

Except where required by operations, may be inoperative provided alternate procedures are established and used.

NOTE:

- i. TAWS enhanced mode is considered inoperative (if installed), and
- ii. ATC ADS-B function is considered inoperative (if installed).
- iii. One GPS must be operative for RNAV1, RNAV2, RNP1, RNP 2, RNAV5 (if adequate VOR/DME coverage is not available) and RNP APCH (LNAV or LNAV/VNAV or LPV) operations.
- iv. LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)

Placard

Inoperative Global Position System (GPS) must be placarded in the flight compartment.

Operating Procedures

Normal flight can be carried out by utilizing other navigation sensors such as Non-Directional Beacon, DME-DME or VOR-DME.

Maintenance Procedures

1. Placard the FMS CDU with "GPS INOP".
2. Make appropriate entry in the aircraft journey log.

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-50-6 Global Positioning System (GPS)****34-50-6-1 If used routinely****34-50-6-1B**

Interval	Installed	Required	Procedure
C	2	1	NIL

Where required by operations, one GPS must be operative.

NOTE: This relief is applicable for aircraft with:

- TAWS Enhanced Mode installed and required by regulation, and/or
- ATC ADS-B function installed and required by regulation.
- One GPS must be operative for RNAV1, RNAV2, RNP1, RNP 2, RNAV5 (if adequate VOR/DME coverage is not available) and RNP APCH (LNAV or LNAV/VNAV or LPV) operations.
- LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Global Position System (GPS) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

- Placard the FMS CDU with "GPS INOP".
- Make appropriate entry in the aircraft journey log.

■ ■ ■ ■

ISS III R05**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-50-6. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-60-1 Flight Directors**

Interval	Installed	Required	Procedure
C	2	0	NIL

Except where enroute operations require their use, may be inoperative provided:

- Approach procedures are not dependent on their use, and
- Autopilot is considered inoperative.

NOTE:

- RNAV 1, RNAV 2, RNAV 5, RNP 1, RNP 2, RNP APCH (LNAV or LNAV/VNAV or LPV) and CAT II operations not permitted.
- LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Flight Director(s) must be placarded on the flight guidance control panel.

Operating Procedures

None required.

Maintenance Procedures

- Placard inoperative Flight Director(s) on the flight guidance control panel.
- Make appropriate entry in the aircraft journey log.

■■■■

ISS III R05**APPROVED BY DAW DELHI, DATED –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-60-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-60-2 Flight Management System (FMS)****34-60-2-1 If used routinely****34-60-2-1A**

Interval	Installed	Required	Procedure
C	2	0	(O)

Except where required by operations, may be inoperative provided alternate procedures are established and used.

NOTE:

1. TAWS enhanced mode is considered inoperative (if installed), and
2. ATC ADS-B function is considered inoperative (if installed).
3. RNP2 Enroute (Oceanic) operation not permitted.
4. One must be operative for RNAV 1, RNAV 2, RNAV 5, RNP 1, RNP2 (Enroute Domestic) and RNP APCH#.
5. LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

For RNP APCH (APV / Baro VNAV or LPV) in the event of FMS failure on approach, there must be a conventional missed approach procedure (such as VOR/NDB raw data and/or radar). There must be a conventional approach available at the alternate.

Minimum Equipment List Procedures (MELP)**Placard**

1. Inoperative Flight Management System (FMS) must be placarded on the FMS Control Display Unit in the flight compartment.
2. Out of currency (Outdated) FMS Database must be placarded on the associated FMS Control Display Unit in the flight compartment.
3. Inoperative LOS Annunciator lights must be placarded on the LOS Annunciator in the flight compartment.

Operating Procedures

NOTE: "Same side FMS" is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

For dual FMS failure, PBN Operation is not authorized.

Maintenance Procedures

1. Placard the appropriate inoperative FMS Control Display Unit with "FMS INOP".
2. Make appropriate entry in the aircraft journey log.

ISS III R05

APPROVED BY DAW DELHI, DATE -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-60-2. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-60-2 Flight Management System (FMS)****34-60-2-3 FMS Database****34-60-2-3A**

Interval	Installed	Required	Procedure
C	2	0	(O)

May be out of currency (outdated) provided:

- Current aeronautical charts are used to verify navigation fixes prior to dispatch,
- Procedures are established and used to verify status and suitability of navigation facilities used to define route of flight,
- Approach navigation radios are manually tuned and identified, and
- Approaches are not conducted using system(s) with out of currency (outdated) database.

NOTE:

- Navigation Database must be current for RNAV1, RNAV 2, RNAV 5, RNP1, RNP2 and RNP APCH (LNAV or LNAV/VNAV or LPV) operations.
- LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

- Inoperative Flight Management System (FMS) must be placarded on the FMS Control Display Unit in the flight compartment.
- Out of currency (Outdated) FMS Database must be placarded on the associated FMS Control Display Unit in the flight compartment.
- Inoperative LOS Annunciator lights must be placarded on the LOS Annunciator in the flight compartment.

Operating Procedures

NOTE: "Same side FMS" is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

PBN operations are not authorised. Jeppessen charts are used to verify if the navigation facilities for the planned route are adequate. Monitor NOTAMS to ensure all navigation aids for the planned routes are serviceable.

Maintenance Procedures

- Placard the appropriate FMS Control Display Unit with "FMS DATABASE OUTDATED".
- Make appropriate entry in the aircraft journey log.

ISS III R05

APPROVED BY DAW DELHI, DAT 0 -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-60-2. 4



34-60-2-3B

Interval	Installed	Required	Procedure
C	2	1	NIL

En-route/approach navigation is conducted using a current (up to date) FMS database.

1. Navigation Database must be current for RNAV1, RNAV 2, RNAV 5, RNP1, RNP2 and RNP APCH (LNAV or LNAV/VNAV or LPV) operations.
2. LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)

Placard

1. Inoperative Flight Management System (FMS) must be placarded on the FMS Control Display Unit in the flight compartment.
2. Out of currency (Outdated) FMS Database must be placarded on the associated FMS Control Display Unit in the flight compartment.
3. Inoperative LOS Annunciator lights must be placarded on the LOS Annunciator in the flight compartment.

Operating Procedures

NOTE: “Same side FMS” is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the appropriate FMS Control Display Unit with "FMS DATABASE OUTDATED".
2. Make appropriate entry in the aircraft journey log.

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-60-2 Flight Management System (FMS)****34-60-2-4 SBAS (Satellite Based Augmentation System) Level of Service (LOS) Annunciator****34-60-2-4A-i**

Interval	Installed	Required	Procedure
C	-	1	NIL

May be inoperative provided that the LPV approach must be conducted from the side with the functioning LPV Light.

NOTE: LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

1. Inoperative Flight Management System (FMS) must be placarded on the FMS Control Display Unit in the flight compartment.
2. Out of currency (Outdated) FMS Database must be placarded on the associated FMS Control Display Unit in the flight compartment.
3. Inoperative LOS Annunciator lights must be placarded on the LOS Annunciator in the flight compartment.

Operating Procedures

NOTE: "Same side FMS" is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the appropriate inoperative LOS annunciator with "Light name" + "INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R05**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-60-2. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST****NAVIGATION****ATA 34****34-60-2 Flight Management System (FMS)****34-60-2-4 SBAS (Satellite Based Augmentation System) Level of Service (LOS) Annunciator****34-60-2-4A LPV LOS Light****34-60-2-4A-ii**

Interval	Installed	Required	Procedure
C	-	0	NIL

May be inoperative provided LPV approaches are not conducted.

NOTE: LPV operations are approved only for VT-SQ series tails (MSN starting from 4583).

Minimum Equipment List Procedures (MELP)**Placard**

1. Inoperative Flight Management System (FMS) must be placarded on the FMS Control Display Unit in the flight compartment.
2. Out of currency (Outdated) FMS Database must be placarded on the associated FMS Control Display Unit in the flight compartment.
3. Inoperative LOS Annunciator lights must be placarded on the LOS Annunciator in the flight compartment.

Operating Procedures

NOTE: "Same side FMS" is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the appropriate inoperative LOS annunciator with "Light name" + "INOP".
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R05

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

34-60-2. 7



34-60-2. 8

**DHC-8-402****MINIMUM EQUIPMENT LIST*****NAVIGATION******ATA 34*****34-60-2 Flight Management System (FMS)****34-60-2-4 SBAS (Satellite Based Augmentation System) Level of Service (LOS) Annunciator****34-60-2-4C LAV/VNAV LOS Light**

Interval	Installed	Required	Procedure
C	-	0	NIL

May be inoperative.

Minimum Equipment List Procedures (MELP)**Placard**

1. Inoperative Flight Management System (FMS) must be placarded on the FMS Control Display Unit in the flight compartment.
2. Out of currency (Outdated) FMS Database must be placarded on the associated FMS Control Display Unit in the flight compartment.
3. Inoperative LOS Annunciator lights must be placarded on the LOS Annunciator in the flight compartment.

Operating Procedures

NOTE: "Same side FMS" is required to maintain minor function of the ADS-B Out broadcast as each FMS is only connected to its own side ATC transponder.

None required.

Maintenance Procedures

1. Placard the appropriate inoperative LOS annunciator with "Light name" + "INOP".
2. Make appropriate entry in the aircraft journey log.

■ ■ ■ ■**ISS III R05****APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49**34-60-2. 9**