

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUXILIARY POWER UNIT******ATA 49*****49-00-1 Auxiliary Power Unit (APU)**

Interval	Installed	Required	Procedure
D	1	0	(M)

May be inoperative provided APU Airframe Fuel Shutoff Valve is verified closed.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative APU must be placarded on the APU Control Panel near the START switch.

Operating Procedures

None required.

Maintenance Procedures

1. Apply DC power to aircraft buses.
2. Ensure APU PWR switchlight is selected off at overhead APU Control Panel.
3. Verify that the APU Fuel Shut-Off Valve is closed as indicated by the white advisory light "APU FUEL VALVE CLOSED" on the fire protection panel and that the green advisory "APU FUEL VALVE OPEN" light is extinguished.
4. If the "APU FUEL VALVE OPEN" light is on, or if the "APU FUEL VALVE CLOSED" light is extinguished, verify that the APU Fuel Shut-Off Valve is closed as follows:

Method A

- a) Pull and collar L ESS BUS circuit breaker APU FUEL SOV/IND.
- b) Attempt to start APU. If APU fails to start, then APU FUEL VALVE is closed.

NOTE: The APU may spin up momentarily, until residual fuel in the manifold is consumed. Also, the APU FADEC may log a fault for the uncommanded shutdown/unsuccessful start.

Method B

- a) Open center wing dry bay access panel 521BT.
- b) Verify that the position indicator arm on the APU Fuel Shut-Off Valve is in the CLOSED position.

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

49-00-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUXILIARY POWER UNIT******ATA 49*****49-00-1****Auxiliary Power Unit (APU)**

- c) Reinstall access panel 521BT.

NOTE: For instructions on removal and installation of the access panel, refer to the Aircraft Maintenance Manual, PSM 1-84-2, Chapter 57.

Method C

- a) Feed a borescope through the aft dry bay drain port in the LH armpit to access the dry bay area.
 - b) Locate the APU Fuel Feed Shut-off Valve.
 - c) Verify that the INDICATOR ARM on the APU Fuel Feed Shut-off Valve is in CLOSED position.
5. Pull and collar the circuit breaker “APU FUEL SOV/IND” on the left Essential 28 VDC Circuit Breaker Panel.
 6. Placard the “APU FUEL VALVE CLOSED” and “APU FUEL VALVE OPEN” advisory lights on the Fire Control Panel in the flight compartment.
 7. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

49-00-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST*****AUXILIARY POWER UNIT******ATA 49*****49-50-1 APU Bleed Air System**

Interval	Installed	Required	Procedure
D	1	0	(M#)

May be inoperative provided APU Bleed Valve is verified closed.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative APU Bleed Air System must be placarded on the APU Control Panel near the APU BL AIR button in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. At the APU compartment, open the clamshell access doors.
2. On the bottom of the APU bleed valve (RHS on bleed duct), note the position of the valves as indicated by pointer. Confirm the valve is closed.
3. Visually confirm integrity of APU connections.
4. Close the APU access doors.
5. Placard the APU BL AIR button on the APU Control Panel.
6. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

49-50-1. 1