

**DHC-8-402****MINIMUM EQUIPMENT LIST*****POWER PLANT******ATA 71*****71-60-1 Engine Intake Bypass Doors****71-60-1-1**

Interval	Installed	Required	Procedure
C	2	0	NIL

May be inoperative in closed position provided the flight is not conducted in known or forecast icing conditions.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Intake Bypass Door(s) must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard ENGINE INTAKE bypass door(s) on the ICE PROTECTION panel in the flight compartment.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

71-60-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST*****POWER PLANT******ATA 71*****71-60-1 Engine Intake Bypass Doors****71-60-1-2**

Interval	Installed	Required	Procedure
C	2	0	(M#)(O)

May be inoperative in the open position provided:

- The OAT along the route flown is less than ISA +25 degrees C.,
- The related engine oil temperature indicator operates normally and is monitored, and
- The associated Engine Intake Adapter Heater is confirmed operative every flight day.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Intake Bypass Door(s) must be placarded in the flight compartment.

Operating Procedures

Flight planning is established and used to ensure OAT enroute does not exceed ISA+25°C and the affected engine oil temperature indication is periodically monitored.

Maintenance Procedures

1. Start and run the associated engine(s) at ground idle.

NOTE: “ENG Adapt Heat (1)” and/or “ENG Adapt Heat (2)” MAY ILLUMINATE ON THE CAUTION AND WARNING PANEL.

2. Ensure that both AC Generators are selected on.

NOTE: ENSURE THAT THE ASSOCIATED “ENG Adapt Heat (1)” and/or “ENG Adapt Heat (2)” ARE EXTINGUISHED.

3. At the ICE PROTECTION panel, select the associated ENGINE INTAKE bypass door switch(es) to OPN/HTR. Observe that the HTR and OPN light(s) illuminate(s).

(...Continued)

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

71-60-1. 2



DHC-8-402

MINIMUM EQUIPMENT LIST

POWER PLANT

ATA 71

71-60-1 Engine Intake Bypass Doors

71-60-1-2

NOTE: The engine intake adaptor heaters and resultant HTR indications are switched by the thermostat on the skin panel beneath the cockpit floor. If outside air temperatures are above a nominal 15°C (59°F), as indicated on the Engine Display SAT indication, spray the skin at the location of the thermostat with Freeze Mist or use other means to lower the temperature and observe the HTR advisory lights illumination.

4. Shut down engine(s).
5. Placard ENGINE INTAKE bypass door(s) on the ICE PROTECTION panel in the flight compartment.
6. Make appropriate entry in the aircraft journey log.



ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

71-60-1. 3