

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ENGINE CONTROL******ATA 76*****76-10-1 ENGINE CONTROL Panel Switches****76-10-1-1 RDC Np LDG Switch**

Interval	Installed	Required	Procedure
C	1	0	NIL

May be inoperative provided the RDC Np LDG function is not used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Control switch must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative switch on the Engine Control Panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DAT 00 –**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

76-10-1. 1

**DHC-8-402****MINIMUM EQUIPMENT LIST****ENGINE CONTROL****ATA 76****76-10-1 ENGINE CONTROL Panel Switches****76-10-1-2 MTOP Switch****76-10-1-2A**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be inoperative in the ON (selected) position provided:

- #1 and #2 ENG FADEC caution lights are extinguished,
- MTOP is annunciated on ED when condition levers are at MAX/1020, and
- Flight is conducted in accordance with the AFM Supplement 46, TAKE-OFF WITH MAXIMUM POWER AND UPTRIM DISABLED.

NOTE:

- Do not press (select) MTOP switch during Pre-Take-off Checks.
- Do not press (deselect) MTOP switch during In-flight procedures after Take-off. NTOP will not appear on ED.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Control switch must be placarded in the flight compartment.

Operating Procedures

- Conduct flights in accordance with AFM Supplement 46 "TAKE-OFF WITH MAXIMUM TAKE-OFF POWER AND UPTRIM DISABLED" with the following exceptions:
 - In the Pre-take-off Checks, section 6.46.4.1.1. of the AFM Supplement, do not press (select) MTOP switch in step 1.
 - In the In-Flight Procedures - After-Take-off, section 6.46.4.1.3 of the AFM Supplement, do not press (deselect) MTOP in step 2. NTOP will not appear on ED.

Maintenance Procedures

- Placard inoperative switch on the Engine Control Panel.
- Make appropriate entry in the aircraft journey log.

ISS III R00

APPROVED BY DAW DELHI, DATED -

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

76-10-1. 2

**DHC-8-402****MINIMUM EQUIPMENT LIST****ENGINE CONTROL****ATA 76****76-10-1 ENGINE CONTROL Panel Switches****76-10-1-2 MTOP Switch****76-10-1-2B**

Interval	Installed	Required	Procedure
C	1	0	(O)

May be failed in the OFF (deselected) position provided:

- a) #1 and #2 ENG FADEC caution lights are extinguished,
- b) NTOP is annunciated on ED when condition levers are at MAX/1020, and
- c) MTOP is not used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Control switch must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative switch on the Engine Control Panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

76-10-1. 3

**DHC-8-402****MINIMUM EQUIPMENT LIST****ENGINE CONTROL****ATA 76****76-10-1 ENGINE CONTROL Panel Switches****76-10-1-3 MCR Switch**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided condition levers are used to set power rating.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Control switch must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative switch on the Engine Control Panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

76-10-1. 4

**DHC-8-402****MINIMUM EQUIPMENT LIST****ENGINE CONTROL****ATA 76****76-10-1 ENGINE CONTROL Panel Switches****76-10-1-4 MCL Switch**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided condition levers are used to set power rating.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Control switch must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative switch on the Engine Control Panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

76-10-1. 5

**DHC-8-402****MINIMUM EQUIPMENT LIST****ENGINE CONTROL****ATA 76****76-10-1 ENGINE CONTROL Panel Switches****76-10-1-5 RDC TOP TRQ DEC Switch**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided RDC TOP TRQ DEC is not used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Control switch must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative switch on the Engine Control Panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

76-10-1. 6

**DHC-8-402****MINIMUM EQUIPMENT LIST*****ENGINE CONTROL******ATA 76*****76-10-1 ENGINE CONTROL Panel Switches****76-10-1-6 RDC TOP TRQ RESET Switch**

Interval	Installed	Required	Procedure
D	1	0	NIL

May be inoperative provided RDC TOP TRQ DEC is not used.

Minimum Equipment List Procedures (MELP)**Placard**

Inoperative Engine Control switch must be placarded in the flight compartment.

Operating Procedures

None required.

Maintenance Procedures

1. Placard inoperative switch on the Engine Control Panel.
2. Make appropriate entry in the aircraft journey log.

■■■■

ISS III R00**APPROVED BY DAW DELHI, DATED -**

Signature valid

Signed by: Manoj
Kumar Bajpai
Director
(Airworthiness)
Date: 07-Jun-
2024 13:52:49

76-10-1. 7