

	De-Havilland DHC-8-400 B1 & B2 TRAINING MANUAL		COURSE CODE		DGM12CBXX3Q4PW	
			ISSUE	02	DATE	20 Sep 2024
			REVISION		DATE	



CHAPTER

ATA 33

LIGHTS

THIS MANUAL IS INTENDED FOR TRAINING PURPOSE ONLY

THIS PAGE IS INTENTIONALLY LEFT BLANK

CONTENTS

CONTENTS	3
FLIGHT COMPARTMENT LIGHTS	4
PASSENGER COMPARTMENT LIGHTS	25
CARGO AND SERVICE COMPARTMENT LIGHTS	66
EXTERIOR LIGHTS	72
LANDING AND TAXI LIGHTS	91
NAVIGATION LIGHTS	100
INSPECTION LIGHTS	109
ANTI-COLLISION LIGHTS	120
LOGO LIGHTS	133
EMERGENCY LIGHTS SYSTEM	138

FLIGHT COMPARTMENT LIGHTS

Introduction

The flight compartment lights supply lighting requirements for the flight compartment area. They supply the lighting required by the pilot and copilot for the operation of the aircraft.



General Description

Light control panels in the cockpit control the flight compartment lights.

Refer Figure - FLIGHT COMPARTMENT LIGHT LOCATOR

The flight compartment lights include the following:

- Dome Lights
- Circuit Breaker Panel Lights
- Map Lights
- Panel and Instrument Lights
- Thunderstorm Lights
- Reading Lights
- Observer Reading Light
- Ice Detection Lights



LEGEND

1. Reading light
2. Dome light.
3. Panel and instrument light.
4. Map light.
5. Thunderstorm light.
6. Circuit breaker light.
7. Observer reading light.
8. Ice detection light.

3a01.dg, kb, apr19/2019

Figure - FLIGHT COMPARTMENT LIGHT LOCATOR

Detailed Description

The flight compartment lights are protected by the circuit breakers that follow:

Left DC Circuit Breaker Panel:

- A3– PANEL LIGHTS O/H CONS
- B3– PANEL LIGHTS GLARESHIELD
- C3– PANEL LIGHTS PLT FLT
- D3– PLT MAP LIGHTS
- L1– STORM/PLT CB PNL LIGHTS
- N2– FLT COMP DOME LIGHTS

Right DC Circuit Breaker Panel:

- P3– COPLT MAP LIGHTS
- Q3– PANEL LIGHTS COPLT FLT
- R3– PANEL LIGHTS AFT CTR CONS
- S3– PANEL LIGHTS FWD CTR CONS
- L4– COPLT CB PNL LIGHTS
- J1– FLT COMP DOME LIGHTS

Reading Lights

Refer Figure - READING LIGHTS

Refer Figure - FLIGHT COMPARTMENT LIGHTS CONTROL PANELS

Refer Figure - MAP AND UTILITY LIGHTING – BLOCK DIAGRAM

There are two reading lights, one for the pilot and one for the copilot. They are mounted in the overhead ceiling, one above each pilot. They are directionally adjustable on fixed mountings.

Each light is controlled from an adjacent dimmer switch, which incorporates an on-off switch at the extreme dim position.

The dimmer controls are installed on the aft side of the avionics rack.

The reading lights are powered from the 28 volts dc main bus through the PLT MAP LIGHTS (D3) circuit breaker on the left dc circuit breaker panel and the main bus through the COPLT MAP LIGHTS (P3) circuit breaker on the right dc circuit breaker panel.






Figure - READING LIGHTS



ap229a01.dg, kb, apr17/2019

Figure - FLIGHT COMPARTMENT LIGHTS CONTROL PANELS



1/2019


Figure - MAP AND UTILITY LIGHTING – BLOCK DIAGRAM

Dome Lights

Refer Figure - DOME LIGHTS

Refer Error! Reference source not found.

There are two dome lights. The dome lights are in the ceiling on the left and right side forward of the entrance door to the flight compartment. The STORM – OFF – STORM/DOME switch and the OFF – DOME switch on the PANEL LIGHTING panel in the overhead console control the dome lights. The dome lights are powered from the 28 volts dc secondary bus through the FLT COMP DOME LIGHTS (N2) circuit breaker on the left dc circuit breaker panel and the battery bus through the FLT COMP DOME LIGHTS (J1) circuit breaker on the right dc circuit breaker panel. The dome lights are used for flight compartment lighting for short times before external dc power is switched on or before engine and dc generator start-up.



ap025a01.cgm

Figure - DOME LIGHTS




Figure - Observer, Storm/Dome Lights Wiring Schematic

The dome lights are controlled by the STORM/ DOME or DOME switches. The thunderstorm lights are controlled by the STORM/DOME switch.

Power to the dome lights is supplied from the left secondary DC bus or from the right battery bus. The source of power is determined by a relay.


When the switch is set to the STORM/DOME position, power is supplied from the Left Secondary Bus to the dome lights. When the other switch is set to the DOME position, power is supplied from the battery bus to the dome lights.

The thunderstorm lights can come on independently or with the dome lights. Power to the thunderstorm lights is supplied from the left battery.

Thunderstorm Lights


Figure - THUNDERSTORM LIGHTS

There are eight thunderstorm lights. Six of the thunderstorm lights are installed along the lower edge of the glare shield panel and one at each end of the glare shield panel. The STORM – OFF – STORM/DOME switch on the PANEL LIGHTING panel in the overhead console controls the thunderstorm lights. The thunderstorm lights are powered from the 28 volts dc battery bus through the STORM/PLT CB PNL LIGHTS (L1) circuit breaker on the left dc circuit breaker panel.



LEGEND

1. Housing.
2. Clip.
3. Boot.
4. Lamp.



THUNDERSTORM LIGHT DETAIL

Figure - THUNDERSTORM LIGHTS

Floodlights

Figure - PANEL AND INSTRUMENT LIGHTS

The floodlights have these parts: a mounting bracket, a retaining clip, a hood and a lamp holder. The floodlights are used for the circuit breaker panel lights, map lights, panel and instrument lights and ice detection lights.




Figure - PANEL AND INSTRUMENT LIGHTS




Figure - Circuit Breaker Panel and Ice Detector Lights Schematic

Circuit Breaker Panel Lights


Refer Figure - Circuit Breaker Panel and Ice Detector Lights Schematic

Refer Figure - Left DC and Right DC Circuit Breaker Panel Lights – Block Diagram

There are four circuit breaker lights, two on each side of the flight compartment, above the left and right dc circuit breaker panel. The CIR BKR LIGHT switch on the pilot's side panel and the CIRCUIT BREAKER PNL LIGHTS switch on the copilot's side control the lights. The circuit breaker lights are powered from the 28 volts dc battery bus through the STORM/PLT CB PNL LIGHTS (L1) circuit breaker on the left dc circuit breaker panel and essential bus through the COPLT CB PNL LIGHTS (L4) circuit breaker on the right dc circuit breaker panel.

Ice Detection Lights

There are two ice detection lights installed on the glare shield panel in the flight compartment. The windshield wiper ice detection switch on the pilot's side panel and the co-pilot's side panel controls the lights. The ice detection lights is powered from the 28 volts dc battery bus through the STORM/PLT CB PNL LIGHTS (L1) ice detection on the left side dc ice detection panel and essential bus through the COPLT CB PNL LIGHTS (L4) ice detection on the right dc ice detection panel.



ap232a01.dg, cg/kb, apr25/2019

Figure - Left DC and Right DC Circuit Breaker Panel Lights – Block Diagram




Figure - Map and Utilities Lights Wiring Schematic

Map Lights


Refer Figure - PANEL AND INSTRUMENT LIGHTS

Refer Figure - FLIGHT COMPARTMENT LIGHTS CONTROL PANELS

Refer Figure - MAP AND UTILITY LIGHTING – BLOCK DIAGRAM

Refer Figure - Map and Utilities Lights Wiring Schematic

There are two map lights, one for the pilot and one for the copilot. They are located below the side windows. The two map lights are directionally adjustable on fixed mountings. Each light is controlled from an adjacent dimmer switch, which incorporates an on-off switch at the extreme dim position. The dimmer controls are installed on the aft side of the avionics rack. The map lights are powered from the 28 volts dc main bus through the PLT MAP LIGHTS (D3) circuit breaker on the left dc circuit breaker panel and the main bus through the COPLT MAP LIGHTS (P3) circuit breaker on the right dc circuit breaker panel. Variable resistance is supplied from a potentiometer on either side panel to the power supply to change the output voltage.



ap233a01.dg, cg/kb, apr25/2019

Figure - Panel and Instrument Lights – Block Diagram

Panel and Instrument Lights

Refer Figure - Panel and Instrument Lights – Block Diagram

There are four floodlights used for panel lighting. They are located at each end of the glare shield panel and above the left and right side windows.

The pilot side is controlled by the dimmer potentiometer labelled PILOTS FLT PNL, located on the pilot's side panel. It is powered from the 28 volts dc main bus through the PANEL LIGHTS PLT FLT (C3) circuit breaker on the left dc circuit breaker panel.

The copilot side is controlled by the dimmer potentiometer labelled COPILOTS FLT PNL, located on the copilot's side panel. It is powered from the 28 volts dc main bus through the PANEL LIGHTS COPLT FLT (Q3) circuit breaker on the right dc circuit breaker panel.

Variable intensity 5 volts dc lighting circuits for integrally lit panels and instruments supply the panels and instruments lighting in the flight compartment. 5 volts dc miniature lamp assemblies embedded in Plexiglas facing panels give light to panel marking. The disc-shaped lamp assemblies are attached in the back of the panel by screws and covered with black insulation tape.

There are six variable 5 volts dc power supplies. The power supply units are installed on the electrical panel No. 1, on the left sidewall behind the avionics rack. Each power supply has a 5 volts dc unit (PS1 through PS6) that operates from 28 volts dc and is controlled from a dimmer potentiometer to supply power to the lighting circuits. The operational position of the dimmer potentiometers, OFF – BRT is identified on the panel adjacent to each dimmer potentiometer.

PS1 – energizes the overhead console dimmer and observer console, panels and instrument lights. Controlled by the dimmer potentiometer labelled OVERHEAD CONS, located on the PANEL LIGHTING panel. Powered from the 28 volts dc main bus through the PANEL LIGHTS O/H CONSOLE (A3) circuit breaker on the left dc circuit breaker panel.

PS2 – energizes the glare shield panel lights. Controlled by the dimmer potentiometer labelled GLARESHIELD, located on the PANEL LIGHTING panel. Powered from the 28 volts dc main bus through the PANEL LIGHTS GLARESHIELD (B3) circuit breaker on the left dc circuit breaker panel.

PS3 – energizes the pilot's flight instrument and panel lights, pilot's pitot static source selector panel and pilot's side panel lights. Controlled by the dimmer potentiometer labelled PILOTS FLT PNL, located on the pilot's side panel. Powered from the 28 volts dc main bus through the PANEL LIGHTS PLT FLT (C3) circuit breaker on the left dc circuit breaker panel.

PS4 – energizes the copilot's flight instrument panel lights and indicator lights. Controlled by the dimmer potentiometer labelled COPILOTS FLT PNL, located on the copilot's side panel. Powered from the 28 volts dc main bus through the PANEL LIGHTS COPLT FLT (Q3) circuit breaker on the right dc circuit breaker panel.



PS5 – energizes the center console flight instruments panel lights and indicator lights. Controlled by the dimmer potentiometer labelled AFT CTR CONS PANEL, located on the PANEL LIGHTING panel. Powered from the 28 volts dc main bus through the PANEL LIGHTS AFT CTR CONS (R3) circuit breaker on the right dc circuit breaker panel.

PS6 – energizes the center (radio) console instruments and panel lights. Controlled by the dimmer potentiometer labelled FWD CTR CONSOLE, located on the PANEL LIGHTING panel. Powered from the 28 volts dc main bus through the PANEL LIGHTS FWD CTR CONS (S3) circuit breaker on the right dc circuit breaker panel.

Observer Reading Light

Refer Figure - OBSERVER READING LIGHT

There is one observer reading light mounted in the threshold–ceiling panel, approximately at Sta. X–39.00. The light is directionally adjustable on a fixed mounting. The light is controlled from an adjacent dimmer switch, which incorporates an on–off switch at the extreme dim position. The observer reading light is powered from the 28 volts dc secondary bus through the FLT COMP DOME LIGHTS (N2) circuit breaker on the left dc circuit breaker panel.



LEGEND

1. Observer Reading Light.
2. Light Dimmer.

ap228a01.cgm, eg, 30/08/04

Figure - OBSERVER READING LIGHT

PASSENGER COMPARTMENT LIGHTS

Introduction

The passenger compartment lights supply the general lighting requirements of the passengers and crew in the passenger compartment area. They supply adequate lighting to help the passengers and the crew in boarding and deplaning the aircraft. They also illuminate the aircraft interior and supply reading lights, and information signs, for the passengers.

General Description

Passenger compartment lighting include the systems that follow:

- Boarding Lights
- Aft Entry Airstair Boarding Light
- Overhead Lights
- Accent Lights
- Sidewall Lights
- Reading Lights and Information Signs
- Lavatory Lights
- Galley Lights.

Detailed Description

Figure - FLIGHT ATTENDANT CONTROL PANEL

Pushbutton switches (referred herein as “pushbutton”), located on the forward-flight-attendant control panel, control the passenger compartment lights. The pushbuttons are identified as follows:

- CABIN OVERHD
- DIM OVERHD (Modsum 4-422000 or NextGen interior)

- CABIN SIDEWALL
- DIM SIDEWALL (Modsum 4-422000 or NextGen interior)
- BOARDING
- PSU TEST
- PSU ON/OFF
- AIRSTAIR DOOR
- LAVATORY.

When a pushbutton is pressed and released, a red indicator light comes on the pushbutton itself to verify system operation.

There are two types of flight attendant panels:

- Flight attendant panels without sleep mode (Wessex Advanced Switching Products)
- Flight attendant panels with sleep mode (EMTEQ)


The flight attendant panel with the sleep mode has a power-saving feature to conserve the battery power when the aircraft is not in use. When only aircraft battery power is available, the flight attendant panel will monitor the status of the boarding lights only. The boarding lights are the only system controlled from the flight attendant panel that gets electrical power directly from the aircraft batteries. If the boarding lights are in the off position, the panel will go into the sleep mode. In the sleep mode the panel minimizes power consumption and appears de-energized.

When the boarding lights pushbutton is pushed, the boarding lights will come on and the panel comes out of the sleep mode. The panel will also come out of the sleep mode when the electrical busses that supply the other systems controlled from the flight attendant panel are energized. The cabin temperature, the NVS, and the lights other than the boarding lights, get their electrical power from the 28 VDC main, essential or secondary busses.

When power is applied, these functions will remember their last condition (on or off).

Passenger compartment lighting protection is supplied by the circuit breakers that follow:

- READING LTS R (R1) on the R MAIN dc bus (20A).
- READING LTS R (Q1) on the LMAIN dc bus (20A).
- ATT RDG LTS (Q1) on the L SECONDARY dc bus (5A).
- PASS WARN SIGNS (H3) on the L ESSENTIAL dc bus (7.5A)
- CABIN LTS / PWR 1 (S2) and CABIN LTS PWR 2 (S1) on the R MAIN dc bus (20 A)
- CABIN LTS / CONT (R2) on the R MAIN dc bus (5A)
- CABIN SIDEWALL LTS / PWR 1 (P2) on the L SECONDARY dc bus (20A) and CABIN SIDEWALL LTS PWR 2 (A1) on the R SECONDARY dc bus (20 A)
- CABIN SIDEWALL LTS / CONT (Q2) on the L SECONDARY dc bus (5A).
- BOARD'G LTS (H1) on the BATTERY PWR bus (5A)
- EXT LIGHTS / AIRSTAIR (E2) on the L MAIN dc bus (7.5A)
- LAVATORY (R2) on the L SECONDARY dc bus (7.5A).




A FLIGHT ATTENDANT PANEL WITH SLEEP MODE

fsd06a03.dg, sw/gv, apr/29/2010

NOTE

1 On aircraft with modsum 4-422000 or NextGen interior.



A FLIGHT ATTENDANT PANEL WITHOUT SLEEP MODE

LEGEND

1. Cabin overhead lighting pushbutton switch.
2. Cabin sidewall lighting pushbutton switch.
3. Cabin overhead lighting dim pushbutton switch.
4. Cabin sidewall lighting dim pushbutton switch.
5. PSU test pushbutton switch.
6. PSU power pushbutton switch.
7. Boarding light pushbutton switch.
8. Lavatory light pushbutton switch.
9. Airstair steps light pushbutton switch.
10. Accent lights pushbutton switch (NextGen interior only).

Figure - FLIGHT ATTENDANT CONTROL PANEL

Boarding Lights

The boarding lights supply adequate lighting to help the passengers and crew in boarding and deplaning. They consist of the threshold, ceiling panel and airstair boarding lights.

Refer Figure - Threshold and Ceiling-Panel Boarding-Lights

The threshold boarding light illuminates the entrance floor and, when the passenger door is lowered, it illuminates the top step of the door. The light is located in the wing bulkhead assembly, just above floor level, on the forward side of the passenger airstair-door entrance. The ceiling-panel boarding light illuminates the general area between the flight compartment and the passenger door. It is located in the ceiling, aft of the flight compartment door, on the aircraft center line.

Refer Figure - Airstair Boarding-Lights

The four airstair boarding lights illuminate the threads of the airstairs. They are each installed in the top center part of the airstair risers.

On pre ModSums 4-457787 AND 4-126450 *Figure - Threshold and Ceiling-Panel Boarding-Lights Wiring-Schematic.*

On Post ModSums 4-457787 OR 4-126450 *Figure - Threshold and Ceiling Panel Boarding Lights – Wiring Schematic.*

A pushbutton labelled BOARDING controls the threshold and the ceiling-panel boarding lights. The threshold and ceiling-panel boarding lights are powered through the BOARD'G LTS circuit breaker (5A) at location H1 on the BATTERY PWR bus, on the right dc circuit breaker panel.

On aircraft with ModSums 4-457787 OR 4-126450 incorporated, the ceiling panel and the threshold boarding lights are replaced from the fluorescent lamps to the LED lights.

Refer Figure - Airstair-Boarding-Lights Wiring Schematic

A pushbutton labelled AIRSTAIR DOOR controls the airstair lights. The airstair lights are powered through the EXT LIGHTS / AIRSTAIR circuit breaker (7.5A) at location E2 on the L MAIN dc bus, on the left dc circuit breaker panel.




Figure - Threshold and Ceiling-Panel Boarding-Lights




Figure - Airstair Boarding-Lights




Figure - Threshold and Ceiling-Panel Boarding-Lights Wiring-Schematic




Figure - Threshold and Ceiling Panel Boarding Lights – Wiring Schematic




Figure - Airstair-Boarding-Lights Wiring Schematic

Aft Entry Airstair Boarding Light

Refer Figure - Aft Entry Airstair Boarding Light

Refer Figure - Aft Entry Airstair Boarding Light – Wiring Schematic

On aircraft with ModSum 4-302200 incorporated, an aft passenger entry airstair boarding light is located below the aft entry airstair door. The light is controlled by the AIRSTAIR LIGHT annunciator pushbutton. This pushbutton is located on the aft airstair storage close-up panel and is operated by the flight attendant. When pushed, the pushbutton illuminates to indicate that the light is selected ON and the light illuminates the aft entry airstairs. The aft passenger entry airstair boarding light is powered through the AIRSTAIR LTS circuit breaker (7.5A) at location E2 on the left main dc bus, on the left dc circuit breaker panel.




Figure - Aft Entry Airstair Boarding Light




Figure - Aft Entry Airstair Boarding Light – Wiring Schematic

Overhead Ceiling Lights

Refer Figure - Overhead Lights

Refer Figure - Cabin Overhead Lights Electrical Schematic (Sheet 1 of 2)

Refer Figure - Cabin Overhead Lights Electrical Schematic (Sheet 2 of 2)

The overhead ceiling lights supply general overhead lighting to the passengers and crew. They consist of 10 lighting units located on the right side of the passenger compartment ceiling and 11 lighting units located on the left side. Each lighting unit has a ballast inverter and a lamp fixture with one fluorescent light tube.

On pre ModSums 4-457787 AND 4-126450 Refer **Figure - Overhead-Ceiling-Lights Wiring Schematic**

On Post ModSums 4-457787 OR 4-126450 Refer **Figure - Overhead Ceiling Lights – Wiring Schematic**

A pushbutton labelled CABIN OVERHD, on the forward-flight-attendant control panel, controls the overhead lights. When this pushbutton is pressed and released, relay K1 is energized and supplies 28 Vdc to the two groups of ballast inverters.

On pre ModSums 4-457787 AND 4-126450, the left-side overhead lights are powered through the CABIN LTS / PWR 1 circuit breaker (20A) at location S2 on the R MAIN dc bus, on the right dc circuit breaker panel. The right-side overhead lights are powered through the CABIN LTS PWR 2 circuit breaker (20A) at location S1 on the R MAIN dc bus, on the right dc circuit breaker panel. The control of the ceiling lights (necessary to energize relay K1) is supplied through the CABIN LTS / CONT circuit breaker (5A) at location R2 on the R MAIN dc bus, on the right dc circuit breaker panel.

On Post ModSums 4-457787 OR 4-126450, the left-side overhead lights are powered through the CABIN LTS / PWR 1 circuit breaker (15A) at location S2 on the R MAIN dc bus, on the right dc circuit breaker panel. The right-side overhead lights are powered through the CABIN LTS PWR 2 circuit breaker (15A) at location S1 on the R MAIN dc bus, on the right dc circuit breaker panel. The control of the ceiling lights (necessary to energize relay K1) is supplied through the CABIN LTS / CONT circuit breaker (5A) at location R2 on the R MAIN dc bus, on the right dc circuit breaker panel. The overhead ceiling lights are replaced from the fluorescent type lamps to the LED type lights.

Aircraft with Modsum 4-422000 or the NextGen interior have a pushbutton labelled DIM OVERHD on the forward-flight-attendant control panel. The DIM OVERHD pushbutton lets the flight attendant dim all the cabin overhead lights.





Figure - Overhead Lights



fsr12a01.dg,sw,02/11/05

Figure - Overhead-Ceiling-Lights Wiring Schematic




Figure - Overhead Ceiling Lights – Wiring Schematic




Figure - Cabin Overhead Lights Electrical Schematic (Sheet 1 of 2)





Figure - Cabin Overhead Lights Electrical Schematic (Sheet 2 of 2)



cg1098a01.dg, bm, jul27/2011

Figure - Accent Light – Wiring Schematic

Accent Lights

Refer Figure - Accent Light – Wiring Schematic

Accent lighting is provided by the accent light assemblies and the underwing ceiling panel accent lights. Accent light assemblies are located along the center aisle of the passenger cabin except for under the wing box where they are replaced by the underwing accent lights.

There are 11 accent lighting assemblies and four individual underwing accent lights. The accent light assemblies are installed above the overhead bins in a way that one light assembly points towards a right overhead bin. Each accent light illuminates the handle of its respective storage bin when closed, and the interior of the bin when opened. In the wing box area, the underwing accent lights replace this function.

Accent lights are controlled by the accent light pushbutton switch on the flight attendant panel. This provides 28V DC power from the CABIN ACCENT LTS CONT circuit breaker (5A) to the relay K2. The relay when energized, supplies power from CABIN ACCENT LTS PWR1 (5A) to the accent lights.

Sidewall Lights

Refer Figure - Overhead Lights

The passenger-compartment sidewall lights supply wash lighting to the sidewall/window reveal area. They consist of lighting units located in the lower part of the Passenger Service Units (PSUs), adjacent to the cabin sidewall.

On pre ModSums 4-457787 AND 4-126450 *Figure - Sidewall-Lights Wiring Schematic*

On Post ModSums 4-457787 OR 4-126450 *Figure - Sidewall Lights – Wiring Schematic*

A pushbutton labelled CABIN SIDEWALL, on the forward-flight-attendant control panel, controls the sidewall lights. When this pushbutton is pressed and released, relay K1 is energized and supplies 28 Vdc to the lights.

On pre ModSums 4-457787 AND 4-126450, the left-side sidewall lights are powered through the CABIN SIDEWALL LTS / PWR 1 circuit breaker (20A) at location P2 on the L SECONDARY dc bus, on the left dc circuit breaker panel. The right-side sidewall lights are powered through the CABIN SIDEWALL LTS PWR 2 circuit breaker (20A) at location A1 on the R SECONDARY dc bus, on the right dc circuit breaker panel. The control of the cabin sidewall lights (necessary to energize relay K1) is supplied through the CABIN SIDEWALL LTS / CONT circuit breaker (5A) at location Q2 on the L SECONDARY dc bus, on the left dc circuit breaker panel.

On Post ModSums 4-457787 OR 4-126450, the left-side sidewall lights are powered through the CABIN SIDEWALL LTS / PWR 1 circuit breaker (15A) at location P2 on the L SECONDARY dc bus, on the left dc circuit breaker panel.

The right-side sidewall lights are powered through the CABIN SIDEWALL LTS PWR 2 circuit breaker (15A) at location A1 on the R SECONDARY dc bus, on the right dc circuit breaker panel.

The control of the cabin sidewall lights (necessary to energize relay K1) is supplied through the CABIN SIDEWALL LTS / CONT circuit breaker (5A) at location Q2 on the L SECONDARY dc bus, on the left dc circuit breaker panel. The sidewall lights are replaced from the fluorescent type lamps to the LED type lights.

Aircraft with Modsum 4-422000 or the NextGen interior have a pushbutton labelled DIM SIDEWALL on the forward-flight-attendant control panel. The DIM SIDEWALL pushbutton lets the flight attendant dim all the cabin sidewall lights.




Figure - Sidewall-Lights Wiring Schematic




Figure - Sidewall Lights – Wiring Schematic

Reading Lights and Information Signs

Refer Figure - PCU

Reading lights supply overhead lights for each passenger seat, forward and aft flight attendant. The passenger reading lights are installed in the Passenger Service Unit (PSU), at each seat location. The forward and aft flight-attendant reading lights are installed on the ceiling panels, above each flight-attendant seat location.

The PSUs are located at the bottom of the overhead storage bins. Two switchlights, each located next to its reading light, control the lights. The outboard reading light is provided for the window seat passenger and the inboard reading light for the aisle seat passenger. A flight-attendant call button is also installed in the PSU to service call.

The PSU ON/OFF pushbutton, on the forward-flight-attendant control panel, controls the passenger reading lights. When the pushbutton is pushed to the ON position, a red indicator light, on the pushbutton itself, comes on to indicate that the reading lights are operative. Each reading light can then be controlled by its individual switchlight on the PSU, at each seat location. When the pushbutton is pushed to the OFF position, the red indicator light goes off to indicate that the reading light system is inoperative.

The PSU TEST pushbutton, on the forward-flight-attendant control panel, is used to test all of the passenger reading lights and the flight-attendant call system. When the pushbutton is pushed, a red indicator light, on the pushbutton itself, comes on to indicate that the system is operative. All of the passenger reading lights come on momentarily and any unserviceable reading light can be identified. The red indicator light, on the PSU ON/OFF pushbutton, also comes on to indicate that the reading lights are operative and that they can be controlled by their individual switchlights on the PSU, at each seat location.

When the PSU TEST pushbutton is pushed again, the red indicator light, on the pushbutton itself, goes off.

The red indicator light on the PSU ON/OFF pushbutton stays on to indicate that the system is still operative.

On Pre ModSums 4-457787 AND 4-126450 *Figure - Passenger-Reading-Lights Wiring Schematic*

The passenger left-side reading lights are powered through the READING LTS L circuit breaker (20A) at location Q1 on the R MAIN dc bus, on the right dc circuit breaker panel. The passenger right-side reading lights are powered through the READING LTS R circuit breaker (20A) at location R1 on the R MAIN dc bus, on the right dc circuit breaker panel.

On Post ModSums 4-457787 OR 4-126450 *Figure - Passenger Reading Lights - Wiring Schematic*

The ceiling panel and the threshold boarding lights are replaced from the fluorescent lamps to the LED lights.

The passenger left-side reading lights are powered through the READING LTS L circuit breaker (7.5A) at location Q1 on the R MAIN dc bus, on the right dc circuit breaker panel. The passenger right-side reading lights are powered through the READING LTS R circuit breaker (7.5A) at location R1 on the R MAIN dc bus, on the right dc circuit breaker panel.

On Pre ModSums 4-457787 AND 4-126450 *Figure - Flight-Attendant Reading-Lights Wiring-Schematic.*

On Post ModSums 4-457787 OR 4-126450 *Figure - Flight Attendant Reading Lights - Wiring Schematic.*

The forward and aft flight-attendant reading lights are powered through the ATT RDG LTS circuit breaker (5A) at location Q1 on the L SECONDARY dc bus, on the left dc circuit breaker panel.

Refer Figure - PASSENGER INFORMATION SIGNS I

Refer Figure - Passenger Information Signs II

There are several passenger information signs located throughout the aircraft. Four individual information signs are installed in the combination sign unit located on the forward ceiling panel, above the flight compartment door as follows:

- Exit sign
- No smoking sign
- Fasten seat belt sign
- Lavatory occupied sign

Three individual information signs installed in the two advisory light panels located on the center ceiling panels, along the center aisle as follows:

- No smoking sign
- Fasten seat belt sign
- Occupied lavatory sign.

One individual information sign installed in the advisory light panel located on the aft ceiling panel, at the rear of the cabin as follows:

- Exit sign

Two individual information signs installed in a combination sign unit located on the forward-flight-attendant control panel, on the end cap assembly, aft of the passenger door as follows:

- No smoking sign
- Fasten seat belt sign

A single return-to-seat sign installed in the PSU located in the lavatory.

Refer Figure - Passenger-Warning Control Panel

The passenger information signs are controlled from the passenger-warning control panel, on the overhead console, in the flight compartment. Power to the fasten seat belt and no smoking signs is supplied through the PASS WARN SIGNS circuit breaker (7.5A) at location H3 on the L ESSENTIAL dc bus

The PSU ON/OFF pushbutton also controls the operation of the lavatory sign. When the LAVATORY pushbutton is pressed to the ON position, 28 vdc power is supplied to the lavatory PSU. The circuit for the PSU sign is powered through the PASS WARN SIGNS circuit breaker (7.5A) at location H3 on the L ESSENTIAL dc bus. When the LAVATORY pushbutton is pushed to the OFF position, the lavatory sign off.

Refer Figure - Passenger Warning Lights Wiring Schematic

On aircraft without Modsum 4-428400, when the NO SMOKING – OFF toggle switch SW-S1 is set to the NO SMOKING position or when the LANDING GEAR selector lever, in the flight compartment, is in the DN position (landing configuration), all of the no smoking signs come on and a low tone chime is heard. When the NO SMOKING – OFF toggle switch SW-S1 is set to the OFF


position or when the LANDING GEAR selector lever is in the UP position, the no smoking signs go off and the low tone chime is heard again.

On aircraft with Modsum 4-428400 and without Modsum 4-457027, the no smoking signs are on at all time and the low tone chime system is deactivated.

On aircraft with Modsum 4-428400 and Modsum 4-457027, the no smoking signs are on at all time and a low tone chime is heard when the NO SMOKIN – OFF toggle switch SW-S1 is set to the NO SMOKING or OFF position.


Refer Figure - Passenger Warning Lights – Wiring Schematic

On aircraft with ModSums 4-457787 OR 4-126450 incorporated, the passenger warning lights are replaced from the fluorescent lamps to the LED lights.



fs955a01.dg.sw,03/11/05

Figure - PCU



fsm59a01.dg. bm. jul27/2011

Figure - Passenger-Reading-Lights Wiring Schematic




Figure - Passenger Reading Lights – Wiring Schematic






Figure - Flight-Attendant Reading-Lights Wiring-Schematic



dg, bm, aug30/2010

Figure - Flight Attendant Reading Lights – Wiring Schematic




LEGEND

1. NO SMOKING/FASTEN SEAT BELT Sign
On Bin End Cap.
2. Combination Sign:
EXIT
NO SMOKING
FASTEN SEAT BELT
LAVATORY OCCUPIED

NOTE

View looking forward from
passenger compartment.

Figure - PASSENGER INFORMATION SIGNS I



LEGEND

1. EXIT lighted sign (mounted on aft ceiling panel).

NOTE

View looking aft in passenger compartment.

Figure - Passenger Information Signs II




Figure - Passenger Warning Control Panel





Figure - Passenger Warning Lights Wiring Schematic



cg1095a01.dg, bm, jul27/2011

Figure - Passenger Warning Lights – Wiring Schematic

Lavatory Lights

On Pre ModSums 4-457787 AND 4-126450 *Figure - Lavatory – Lights Wiring Schematic*

On Post ModSums 4-457787 OR 4-126450 *Figure - Lavatory Lights – Wiring Schematic*

On aircraft without ModSums 4-457787 AND 4-126450 incorporated, fluorescent lights supply either full or dim illumination to the forward lavatory.

On aircraft with ModSums 4-457787 OR 4-126450 incorporated, LED lights supply either full or dim illumination to the forward lavatory.

The lavatory lights are either on or dim when the aircraft is powered. The lavatory door latch micro-switch control the operation of the lights. When the lavatory door latch is in the unlocked position, power is supplied to the lavatory lights for continuous dim illumination. When the lavatory door latch is in the locked position, the micro-switch is activated and the lights provide full illumination (bright).

On the forward-flight-attendant control panel when the LAVATORY push-button is pushed, a red indicator light and the LAVATORY sign comes on.

A flight-attendant call button is supplied in the PSU for service call (Refer to AMM 25-41-02).

The lavatory lights are powered through the LAVATORY LTS circuit breaker (7.5A) at location R2 on the L SECONDARY dc bus.

On aircraft with MS 4-309208 incorporated, the aft lavatory has a LED lights unit to supply full or dim illumination to the aft lavatory.

A push switch is located on the high-up on the aft face of the lavatory and when the switch is pushed the inter lighting and the lavatory available indication light illuminates. The lavatory door latch micro-switch control the operation of the lights. When the lavatory door latch is in the unlocked position, power is supplied to the lavatory lights for continuous dim illumination.

When the door latch micro switch is locked position, the lavatory LED lights goes to bright illumination and at the same time the red diagonal bar (lavatory occupied) in the oval sign illuminates on the forward face of the lavatory.

The two LED lights are installed at the forward and aft lavatory. One additional LED ceiling light is installed adjacent to the aft lavatory. This additional LED light provides sufficient intensity to charge the floor mounted photo luminescent emergency escape path lighting feature installed along the center aisle.




Figure - Lavatory – Lights Wiring Schematic




Figure - Lavatory Lights – Wiring Schematic

Galley Lights

On aircraft without ModSums 4-457787 AND 4-126450 AND 4-201580 AND 4-459451 incorporated, *Figure - Galley - Lights Wiring Schematic*

On aircraft with ModSums 4-457787 AND 4-126450 AND 4-201580 AND 4-459451 incorporated *Figure - Galley Lights - Wiring Schematic*


Two lights supply overhead illumination to the galley. The lights are installed in the aft-flight attendant area, on the left and right ceiling panel. Each lighting unit has a lamp fixture with two fluorescent lamps and a dual ballast inverter.

On aircraft with ModSum 4-201580 OR 4-459451 incorporated, the two fluorescent lamps are replaced with the LED lights.

Push-buttons, located on the galley control panel, near the top of the galley, control the operation of these lights. The galley has also a work light to supply illumination to its countertop area. Power is supplied through the GALLEY PWR circuit breaker (20A) at location B1 on the R SECONDARY dc bus.


Training Information Points

To avoid loss of battery power, the boarding lights must not be left on unless external DC power is available.



fsm63a01.dg, btm, jul27/2011

Figure - Galley – Lights Wiring Schematic



cg1096a01.dg, bm, jul27/2011

Figure - Galley Lights – Wiring Schematic

CARGO AND SERVICE COMPARTMENT LIGHTS

Introduction

Baggage and service compartment lights supply general lighting for the baggage and service compartment areas.

General Description

The baggage compartment lights are controlled automatically by the baggage doors.

The baggage and service compartment lights system has the sub-systems that follow:

- Baggage Compartment Lights
- Refuel Panel Service Lights.

Detailed Description

The baggage compartment lights supply light for loading and unloading baggage and to aid in maintenance related work. Lights in both compartments are controlled automatically by the related door mechanism.

The refuel/defuel panel light supplies light for easier operation of the refuel/defuel panel and comes on automatically when the access door is unlocked.

The baggage and service compartment lights are protected by the circuit breaker that follows:

- WRB & BAGGAGE (K2) on the L Essential DC Bus (5A)

Baggage Compartment Lights

Refer Figure - AFT BAGGAGE COMPARTMENT LIGHTS LOCATION

Refer Figure - BAGGAGE COMPARTMENT LIGHTS

The aircraft has three lights for the baggage areas. One dome light is located in the forward baggage compartment and two lights are located in the aft baggage compartment. These three lights are controlled by the operation of the related door. When a baggage door is unlocked, the light of the associated compartment will come on. The forward and aft baggage compartment lights are powered from the Left Essential DC Bus through a 5 A circuit breaker labeled WRB & BAGGAGE.


Refuel Panel Service Light

Refer Figure - REFUEL PANEL SERVICE LIGHT

The aircraft has a fixed refuel panel service light, installed on the right nacelle, refuel/defuel access panel to illuminate this area.


The light comes on automatically whenever the access door is opened.

The service light has a rectangular lens, with simple housing and a reflector light, operated from a 28 Vdc power source.



ts637a01.cgm

Figure - AFT BAGGAGE COMPARTMENT LIGHTS LOCATION




LEGEND

- 1. Overhead Service Light.
- 2. Doorway Service Light.
- 3. Aft Baggage Door.

NOTE

View looks aft into the baggage compartment.

Figure - BAGGAGE COMPARTMENT LIGHTS



ts644a01.com

Figure - REFUEL PANEL SERVICE LIGHT




Figure - Baggage Compartment Lights Schematic

Refer Figure - Baggage Compartment Lights Schematic

The aft baggage compartment lights are controlled by relay 2-K4 in Relay Junction Box (RJB) No.2. When the PSEU senses the aft baggage door is closed and locked, a ground discrete is supplied to the relay to remove power to the light assemblies.

The forward baggage compartment light is controlled by relay 2-K4 in RJB No.1. When the PSEU senses the forward baggage door is closed and locked, a ground discrete is supplied to the relay to remove power to the light assembly.

The forward baggage compartment light will also illuminate through the setting of an internal baggage door controlled micro-switch.



EXTERIOR LIGHTS

Introduction

The aircraft is equipped with a series of external lights installed at various locations on the fuselage, wings, empennage, engine cowlings, and landing gear. The lights provide adequate illumination during normal operation for the crew, passengers, ground personnel, and aircraft identification.

General Description

The exterior lights are controlled by switches in the flight compartment.

The exterior lights system has the components that follow:

- Landing and Taxi Lights
- Navigation Lights
- Inspection Lights
- Anti-Collision Lights
- Logo Lights.

Detailed Description

Refer Figure - EXTERIOR LIGHTS PANEL LOCATION PAGE 1

Refer Figure - EXTERIOR LIGHTS PANEL LOCATION PAGE 2

The exterior lights are controlled by toggle switches on two EXTERIOR LIGHTS panels in the flight compartment. They are labeled as follows:

- LANDING-APPROACH/OFF
- LANDING-FLARE/OFF
- TAXI/OFF

- WING INSP/OFF
- RED/OFF/WHITE A/COL
- POSN/OFF
- TAIL LOGO/OFF.

The exterior lights system is protected by the circuit breakers that follow:

- EXT LIGHTS TAXI PWR (A2) on the L Main DC Bus (10 A)
- EXT LTS APPR L PWR (N1) on the L Secondary DC Bus (30 A)
- EXT LIGHTS L FLARE (D2) on the L Main DC Bus (30 A)
- EXT LTS L WING INSP (P1) on the L Secondary DC Bus (5 A)
- LOGO LIGHTS LEFT (B7) & LOGO LIGHTS RIGHT (C7) on the R Secondary DC Bus (7.5 A)
- EXT LTS APPR R PWR (N2) on the R Secondary DC Bus (30 A)
- EXT LTS R FLARE (C1) on the R Secondary DC Bus (30 A)
- EXT LTS R WING INSP (D1) on the R Secondary DC Bus (5 A)
- EXT LTS ANTI COLL (Q2) on the R Main DC Bus (7.5 A).




Figure - EXTERIOR LIGHTS PANEL LOCATION PAGE 1




Figure - EXTERIOR LIGHTS PANEL LOCATION PAGE 2


Landing and Taxi Lights

Refer Figure - LANDING LIGHTS LOCATION

Refer Figure - TAXI LIGHT LOCATION


Two approach and two flare quartz–halogen lights are installed on the wing leading edges. One approach light and one flare light are located outboard of each nacelle. The landing lights are controlled by independent switches labeled APPROACH and FLARE located on the overhead EXTERIOR LIGHTS control panel.

One fixed, forward–facing, Taxi Light is installed on the rotating section of the nose landing gear. The light is controlled by a switch, labeled OFF–TAXI, located on the overhead EXTERIOR LIGHTS control panel.



ts046a01.cgm

Figure - LANDING LIGHTS LOCATION



D49a01.cgm

Figure - TAXI LIGHT LOCATION

Navigation Lights

Refer Figure - WING POSITION LIGHTS LOCATION

Refer Figure -TAIL POSITION LIGHT LOCATION

The navigation lights are standard dual red and green wing position lights, with a single white tail position light. Optional dual white tail position lights are available. The navigation lights are controlled by a switch labeled POSN-OFF on the overhead EXTERIOR LIGHTS control panel.





Figure - WING POSITION LIGHTS LOCATION



ts58da01.cgm


Figure -TAIL POSITION LIGHT LOCATION

Inspection Lights

Refer Figure - ENGINE AND WING INSPECTION LIGHTS LOCATION

Refer Figure - INSPECTION LIGHT

One incandescent engine inspection light is located on each side of the fuselage. The engine inspection lights are used for lighting the propeller spinners, engine intakes, and the wing leading edges between the nacelle and fuselage. One halogen wing inspection light is located on the outboard side of each nacelle, for lighting the outboard wing leading edges. All inspection lights are controlled by a switch labeled WING INSP-OFF located on the overhead EXTERIOR LIGHTS control panel.



LEGEND


- 1. Engine Inspection Light.
- 2. Wing Inspection Light.

NOTE

Left equipment shown.
Right side similar.

ts050a01.egm

Figure - ENGINE AND WING INSPECTION LIGHTS LOCATION



LEGEND

- 1. Lamp Housing.
- 2. Lamp Assembly.
- 3. Lamp.
- 4. Lens Assembly.

ts013a01.cgm

Figure - INSPECTION LIGHT

Anti-Collision Lights

Refer Figure - UPPER ANTI-COLLISION LIGHT LOCATION

Refer Figure - LOWER ANTI-COLLISION LIGHT LOCATION

Refer Figure - RECOGNITION LIGHT LOCATION

Refer Figure - RECOGNITION LIGHT DETAIL

Two white anti-collision light assemblies and a flashing red recognition light assembly are installed on the aircraft.

The upper anti-collision light assembly is located on the top of the vertical stabilizer. The lower anti-collision light is located on the lower center line of the fuselage. A red recognition light is located on the upper forward fuselage.

The anti-collision and red recognition lights are controlled by the overhead A/COL-RED/OFF/WHITE switch located on the EXTERIOR LIGHTS control panel.





Figure - UPPER ANTI-COLLISION LIGHT LOCATION



ts035a01.cgm

Figure - LOWER ANTI-COLLISION LIGHT LOCATION




Figure - RECOGNITION LIGHT LOCATION






Figure - RECOGNITION LIGHT DETAIL

Logo Lights

Refer Figure - LOGO LIGHTS LOCATION

Two optional tail logo lights supply lighting for the airline logo on the vertical tail surface. If installed, one light is located on either side of the horizontal stabilizer.

Logo lights are controlled using a two-position switch labeled TAIL LOGO/OFF located on the overhead EXTERIOR LIGHTS control panel, in the flight compartment.



NOTE
Left Component Shown.
Right Component Similar.

ts683a01.cgm

Figure - LOGO LIGHTS LOCATION

LANDING AND TAXI LIGHTS

Introduction

One approach and one flare landing light are installed on the leading edge of each wing, outboard of the nacelles, to supply landing surface illumination during landing approach.

A single fixed taxi light is installed on the nose landing gear for runway and taxi-way lighting during ground maneuvers.

General Description

The landing and taxi lights are controlled by switches in the flight compartment.

The landing and taxi lights system have the components that follow:

- Lights, Landing
- Lights, Taxi
- Landing and Taxi Light Switch Control Panel.

Detailed Description

The aircraft is equipped with four fixed landing lights. Each landing light assembly has a flare light and an approach light.

The outboard, or approach landing lights, are aimed forward in the horizontal plane with a toe-in of 1.3 degrees relative to the aircraft centerline. They supply runway illumination during approach. The inboard, or flare landing lights, aim directly forward parallel to the aircraft centerline. They are aimed downward from the horizontal at an angle of 4 degrees so that, during the aircraft pitch up flare maneuver, the illumination stays on the runway.

The Taxi Light is installed on the nose landing gear. It comes on when the nose landing gear is down and locked, and the Taxi Light switch is set to TAXI.

The landing and taxi lights are controlled by switches on the EXTERIOR LIGHTS panel in the flight compartment.

The landing and taxi light systems are protected by the circuit breakers that follow:

- EXT LIGHTS TAXI CONT (B2) on the L Main DC Bus (5 A)
- EXT LIGHTS TAXI PWR (A2) on the L Main DC Bus (10 A)
- EXT LIGHTS L FLARE (D2) on the L Main DC Bus (30 A)
- EXT LTS APPR L PWR (N1) on the Left Secondary DC Bus (30 A)
- EXT LTS R FLARE (C1) on the R Secondary DC Bus (30 A)
- EXT LTS APPR R PWR (N2) on the R Main DC Bus (30 A)


Lights, Landing

Refer Figure - LANDING LIGHTS LOCATION

Refer Figure - APPROACH AND FLARE LIGHT


Four landing lights are installed on the aircraft. Two 600 W quartz-halogen sealed beam lights are installed on the leading edge of each wing adjacent to and outboard of the engine nacelles. The outboard set of lights supply lighting during the approach. The inboard set of lights supply lighting during the flare.

The approach and flare lights are controlled by overhead switches located in the flight compartment. The flare lights are powered from the left main DC bus through a 30 A circuit breaker labeled EXT LIGHTS L FLARE. The approach lights are powered from the left secondary DC bus through a 30 A circuit breaker labeled EXT LTS APPR L PWR.



ts046a01.cgm

Figure - LANDING LIGHTS LOCATION



LEGEND

- 1. Flare Light.
- 2. Approach Light.

t2047a01.cgm

Figure - APPROACH AND FLARE LIGHT





Figure - Approach Lights and Flare Schematic

Lights, Taxi

Figure - TAXI LIGHT LOCATION

The aircraft has a single 250 W taxi light installed on the lower nose gear strut. The taxi light is controlled by an overhead TAXI switch located in the flight compartment. Electrical power to the taxi light is supplied by the left main DC bus through a 10 A circuit breaker labeled EXT LIGHTS TAXI PWR. Electrical power for the functional control of the light is through a 5 A circuit breaker labeled EXT LIGHTS TAXI CONT on the left main DC bus circuit breaker panel.

The nose landing gear must be down and locked for the taxi light to come on. A signal is supplied from the Proximity Sensor Electronic Unit (PSEU) to complete the control circuit.



048a01.cgm

Figure - TAXI LIGHT LOCATION

Switches, Landing and Taxi

Refer Figure - LANDING AND TAXI LIGHT SWITCH CONTROL PANEL LOCATION


Refer Figure - LANDING AND TAXI LIGHT SWITCHES

The landing lights and taxi light are controlled by switches on the overhead EXTERIOR LIGHTS control panel. Approach lights are controlled by a switch labeled APPROACH-OFF located in the flight compartment on the overhead EXTERIOR LIGHTS control panel. When selected to APPROACH, the switch closes the dedicated dual contactor that carries the heavy current to the approach lights. Flare lights are controlled by a switch labeled FLARE-OFF on the same panel. When selected to FLARE, the switch closes the dedicated dual contractor that carries the heavy current to the flare lights.

The taxi light is manually controlled by a single switch labeled TAXI-OFF located in the flight compartment on the overhead EXTERIOR LIGHTS control panel. When set to TAXI, the control relay is powered. This relay is further controlled with a signal from the Proximity Sensor Electronic Unit (PSEU), to make sure that the taxi light will not stay on during flight.


Training Information Points

Refer to caution number C33-1C-0: DO NOT KEEP THE LANDING LIGHTS ON FOR MORE THAN ONE MINUTE WHILE THE AIRCRAFT IS ON THE GROUND. IF YOU DO, THEY CAN GET TOO HOT AND CAUSE DAMAGE.




ts019a01.cgm

Figure - LANDING AND TAXI LIGHT SWITCH CONTROL PANEL LOCATION



LEGEND

1. Approach Lights Toggle Switch.
2. Flare Lights Toggle Switch.
3. Taxi Light Toggle Switch.



ts000a01.cgm

Figure - LANDING AND TAXI LIGHT SWITCHES

NAVIGATION LIGHTS

Introduction

The navigation lights show the orientation of the aircraft in the direction of flight.

General Description

Dual The navigation lights are standard dual red and green wing position lights, and a single white tail position light.

The two wingtip position lights have primary and secondary bulbs that automatically switch in the event of a failure. Two discrete electronic current sensing switches, installed to the outboard forward wing spars, supplies current sensing to the lights and switch the ground path to the secondary light when a failure is sensed.

The navigation lights system has the components that follow:

- Lights, Forward Position
- Light, Tail Position
- Module, Switch
- Switch, Position Light.

Detailed Description

Standard dual wing position lights and a single tail position light indicate aircraft orientation in respect to direction of travel. Dual wing position light sets on each wing are designated primary and secondary. An electronic switch module senses reduced current flow when the primary bulb fails, and automatically switches the secondary bulb on.

The wing and tail position lights are controlled by the same switch, labeled OFF-POSN on the overhead EXTERIOR LIGHTS control panel. When the switch is selected to POSN, all position lights come on. After a time delay, the secondary light on each wing tip will go out if the primary light stays on. If the primary light on the wing tip fails, the secondary light will come on automatically.

All three position lights are powered from the Right Essential DC Bus through a common circuit breaker. Protection of the navigation lights system is supplied by the EXT LTS POSN (M2) on the R Essential DC Bus (7.5 A) circuit breaker.

Lights, Forward Position

Refer Figure - FORWARD POSITION LIGHTS LOCATION

Each wing position light installation has dual lights and an electronic switch module. The forward light is referred to as primary and the aft light is referred to as secondary. When the primary bulb fails, the electronic switch module automatically turns the secondary bulb on. Lights installed on the left wing are red and lights installed on the right wing are green.




Figure - FORWARD POSITION LIGHTS LOCATION

Light, Tail Position

One rear upper tail position white light is installed on the trailing edge of the bullet fairing at aircraft station X=1114.557. An option is available for a dual bulb tail position light installation. In a dual bulb configuration, the secondary light automatically comes on in the event of a primary bulb failure. The second bulb, in a dual tail position light installation, is installed below the first bulb on the trailing edge fairing.


Module, Switch

The forward position lights have primary and secondary elements with an electronic switch. When the overhead switch is set to POSN, all of the position lights come on. After 0.7 seconds, the secondary elements, controlled through an electronic switch unit, go out and remain armed, ready to come on in the event of primary element failure.

The switch module senses the reduced current when there is a failure with the primary bulb. When a failure is sensed, the secondary bulb is automatically switched on by the switch module.

There are two switch modules internally installed on each wing tip. The switch modules work together with the forward position lights and are controlled by the same POSN – OFF switch.

The switch modules are operated by a 28 VDC power source.



ts595a01.egm

Figure - TAIL POSITION LIGHT LOCATION

Switch, Position Light

Refer Figure - EXTERIOR LIGHTS PANEL LOCATION

Refer Figure - POSITION LIGHT SWITCH

The position lights are controlled by a single switch, labeled POSN – OFF on the overhead EXTERIOR LIGHTS control panel. When selected to POSN, both primary and secondary position lights come on. After 0.7 seconds, the secondary light goes out if the primary light stays on. The secondary light will stay armed ready to come on if the primary light fails.





Figure - EXTERIOR LIGHTS PANEL LOCATION



OVERHEAD CONSOLE

LEGEND

1. Position Toggle Lights Switch.




Figure - POSITION LIGHT SWITCH




Figure - Position Light Schematic

Refer Figure - Position Light Schematic

When the switch is set to POSN, all position lights come on for 1 seconds to check the secondary lights. After 1 seconds, the secondary lights will go off.

If a primary light fails, the electronic switch will automatically cause the secondary light to come on.

INSPECTION LIGHTS

Introduction

The inspection lights allow for visual inspection of the wing leading edges and engine intakes for ice formation.

General Description

Refer Figure - INSPECTION LIGHTS LOCATION

Two incandescent engine inspection lights are installed on the fuselage to illuminate the left and right propeller spinners, engine intakes, and the wing leading edges between the nacelle and fuselage. Two halogen wing inspection lights are installed, one on each outboard side of the left and right nacelle, to shine on the wing leading edges. The inspection lights are controlled by a switch in the flight compartment.

The inspection light system has the components that follow:

- Lights, Engine Inspection
- Lights, Wing Inspection
- Switch, Wing and Engine Inspection Lights.


Detailed Description

The wing and engine inspection lights supply illumination to the wing and engine intake areas to let the pilots or ground personnel visually detect ice formation.

The inspection lights are controlled by a switch on the EXTERIOR LIGHTS control panel in the flight compartment. The switch is identified as WING INSP/OFF.

The engine and wing inspection lights are protected by the circuit breakers that follow:

- EXT LTS L WING INSP (P1) on the L Secondary DC Bus (5 A)
- EXT LTS R WING INSP (D1) on the R Secondary DC Bus (5 A).



LEGEND

1. Engine Inspection Light.
2. Wing Inspection Light.

NOTE

Left equipment shown.
Right side similar.

ts000a01.cgm

Figure - INSPECTION LIGHTS LOCATION

Lights, Engine Inspection

Refer Figure - ENGINE INSPECTION LIGHTS LOCATION

Refer Figure - INSPECTION LIGHT

The aircraft has two engine inspection lights located on the left and right sides of the centre fuselage. These lights, when selected on, illuminate the critical surfaces. This will let pilots or ground personnel to visually inspect the surfaces for ice formation.

The engine inspection lights are a single bulb assembly located at stations X192.100/Z160.458, on the centre fuselage.

The engine and wing inspection lights are controlled by a single overhead switch located in the flight compartment labeled WING INSP/OFF.





Figure - ENGINE INSPECTION LIGHTS LOCATION



LEGEND

- 1. Lamp Housing.
- 2. Lamp Assembly.
- 3. Lamp.
- 4. Lens Assembly.

Figure - INSPECTION LIGHT

Lights, Wing Inspection

Refer Figure - INSPECTION LIGHT

Refer Figure - WING INSPECTION LIGHTS LOCATION

Two wing inspection lights are located on the outer side of each nacelle cowl (left and right). These lights, when selected on, will shine on the critical surfaces. This allows for visual inspection of the surfaces for ice formation. The wing and engine inspection lights are controlled by a single overhead switch located in the flight compartment labeled WING INSP/OFF.

The wing inspection lights are a single bulb assembly located at stations X608D53.000/Z608D-35.800, on the outer side of the engine nacelles.




Figure - WING INSPECTION LIGHTS LOCATION

Switch, Wing and Engine Inspection Lights

Refer Figure - OVERHEAD EXTERIOR LIGHTS CONTROL PANEL LOCATION

Refer Figure - INSPECTION LIGHTS SWITCH

The wing and engine inspection lights are controlled by a single, two-position, switch labeled WING INSP/OFF located on the overhead EXTERIOR LIGHTS control panel.

When selected to the WING INSP position, both the engine and wing inspection lights come on to illuminate the critical surfaces for ice formation.





Figure - OVERHEAD EXTERIOR LIGHTS CONTROL PANEL LOCATION



OVERHEAD CONSOLE

LEGEND

1. Wing Inspection Toggle Lights Switch.




Figure - INSPECTION LIGHTS SWITCH




Figure - Wing Inspection Light Schematic

ANTI-COLLISION LIGHTS

Introduction

Two white anti-collision lights, that are located on the fuselage, flash to make the aircraft more visible on the ground and in flight. When the aircraft is on the ground, a red recognition light is turned on to show that the engines are about to start and are operating.

General Description

White anti-collision lights are used for visibility while airborne. One anti-collision light is located on the vertical stabilizer bullet fairing and the other is located on the bottom of the fuselage.

A red recognition light is used for ground operation only. It is installed on top of the fuselage.

The anti-collision lights system has the components that follow:

- Lights, Anti-Collision
- Switch, Anti-Collision Lights.

Detailed Description

The white anti-collision lights have two elements. A secondary element selection is made using a toggle switch located in the aft fuselage equipment bay in the event of a malfunction of the other element. It allows selection of the secondary element for the upper anti-collision light, lower anti-collision light, both anti-collision lights, or OFF (for normal use). Control stays the same when the secondary element is selected.

The white anti-collision lights and the recognition light operate at 45 flashes per minute.


The white anti-collision lights and the recognition light are controlled by one switch located in the flight compartment on the EXTERIOR LIGHTS panel. The anti-collision light switch is set to the WHITE A/COL position to operate the white anti-collision lights. It is set to the RED position to operate the red recognition light. When the anti-collision light switch is set to OFF, the white anti-collision lights and the red recognition light go off.

The Right Main Bus supplies the white anti-collision lights and the recognition light with 28 VDC through a 7.5 A circuit breaker. The circuit breaker is found on the right side 28 VDC circuit breaker panel at position Q2 and is labelled EXT LTS ANTI COLL.

Lights, Anti-Collision

Refer Figure - ANTI-COLLISION LIGHT

Each white anti-collision light assembly has dual anti-collision strobe-type light elements. The lower element of the white anti-collision light assembly is identified as the primary and the upper element is identified as the secondary.



ts036a01.cgm

Figure - ANTI-COLLISION LIGHT

Figure - RED RECOGNITION LIGHT

The red recognition light assembly is made up of a single element.

Refer Figure - UPPER ANTI-COLLISION LIGHTS LOCATION

Refer Figure - LOWER ANTI-COLLISION LIGHTS LOCATION

One white anti-collision light assembly is installed on top of the vertical stabilizer fairing at station X1030.000. The other is installed on the lower centre line of the fuselage between stations X341.000 and X361.000.




Figure - RED RECOGNITION LIGHT




Figure - UPPER ANTI-COLLISION LIGHTS LOCATION





Figure - LOWER ANTI-COLLISION LIGHTS LOCATION

Refer Figure - RED RECOGNITION LIGHT LOCATION

The red recognition light is located on the upper fuselage between stations X216.000 and X236.000.



ts907a01.com

Figure - RED RECOGNITION LIGHT LOCATION

Switch, Anti-Collision Lights

Refer Figure - OVERHEAD EXTERIOR LIGHTS CONTROL PANEL LOCATION

The overhead anti-collision light switch, located on the EXTERIOR LIGHTS control panel, operates the white anti-collision lights or the red recognition light.

Figure - ANTI-COLLISION LIGHTS SWITCH

The anti-collision light switch is a three position toggle switch with the positions that follow:

- WHITE A/COL
- OFF
- RED





Figure - OVERHEAD EXTERIOR LIGHTS CONTROL PANEL LOCATION



OVERHEAD CONSOLE

LEGEND

1. Anti-Collision Toggle Lights Switch.




Figure - ANTI-COLLISON LIGHTS SWITCH




Figure - Anti-Collision Light Schematic

Refer Figure - Anti-Collision Light Schematic

The right main bus supplies electrical power through a toggle switch to the lights.

The toggle switch also controls the operation of the flight data recorder (FDR).

Refer Figure - Anti-Collision Light Selector

The white anti-collision lights and the recognition light operate at 45 flashes per minute.

The white anti-collision light assembly have two anti-collision strobe type light elements.

If the primary element has malfunctioned, a secondary element selection is made using a toggle switch located in the aft fuselage equipment bay.




Figure - Anti-Collision Light Selector

LOGO LIGHTS

Introduction

The logo lights supply prominent aircraft tail and company logo visibility during the night.

General Description

Refer Figure - LOGO LIGHTS LOCATION

The optional logo lights are installed on the lower left and right hand horizontal stabilizers to illuminate the airline logo on the vertical tail surface.

Detailed Description

The optional logo lights are installed flush with the underside of the horizontal stabilizer. There is one logo light on the lower left side of the horizontal stabilizer, and one logo light on the lower right side.

Refer Figure - LOGO LIGHTS, EXTERIOR LIGHTS PANEL LOCATION

Refer Figure - LOGO LIGHTS SWITCH

The logo lights are controlled by an overhead switch labeled TAIL LOGO–OFF on the EXTERIOR LIGHTS panel. When the switch is selected to LOGO, the switch closes the dedicated dual pole relay that carries the heavy currents to the 75 W logo lights.

↓ switch

The logo lights are powered by 28 VDC through the R Secondary Bus through 7.5 A circuit breakers labeled LOGO LIGHTS LEFT (B7) and LOGO LIGHTS RIGHT (C7).




Figure - LOGO LIGHTS LOCATION





Figure - LOGO LIGHTS, EXTERIOR LIGHTS PANEL LOCATION



OVERHEAD CONSOLE

LEGEND

1. Tail Logo Toggle Lights Switch.




Figure - LOGO LIGHTS SWITCH




Figure - Logo Light Schematic

EMERGENCY LIGHTS SYSTEM

Introduction

The emergency lights system supplies interior and exterior lighting for emergency evacuation of the aircraft, or if there is a failure of the essential DC power.

General Description

Fixed exterior emergency egress lights are located at the left and right aft emergency exits, the front right emergency exit and the forward passenger door. Emergency lights in the passenger compartment ceiling supply emergency lighting inside the aircraft. The emergency lights are powered by four 6.4 V Ni-Cad battery packs.

The system is operated by an overhead-panel toggle switch located in the flight compartment or by a push button light switch located on the main passenger entrance bulkhead.

The emergency lights system has the components that follow:

- Unit, Power Supply-Emergency Light
- Lights, Emergency-Cabin
- Lights, Emergency-Egress
- Lights, Emergency-Floor Path.

Detailed Description

Four egress lights, one located adjacent to each emergency exit, supply external emergency lighting. The forward passenger door egress light is powered by a battery pack which also powers the related EXIT signs.

The front right emergency exit egress light and EXIT signs are powered by a separate battery pack. The egress lights and EXIT signs for the two aft exits are powered by the same battery pack. The battery pack for the aft exits is located in the ceiling between the two exits.

Emergency ceiling lights in the passenger compartment supply internal emergency lighting. The ceiling lights are powered by three of the four battery packs.

Refer Figure - EMERGENCY LIGHTS CONTROL PANEL LOCATION

All of the emergency lights are controlled by one of two switches:

- EMER LIGHTS-OFF/ARM/ON switch in the flight compartment
- EMERGENCY LIGHTING-NORMAL/ON switch on the main passenger entrance bulkhead.




Figure - EMERGENCY LIGHTS CONTROL PANEL LOCATION

When the EMER LIGHTS switch, in the flight compartment, is set to the ON position, the emergency lights come on. When the EMER LIGHTS switch is set to the OFF position, the emergency lights go off. When the EMER LIGHTS switch is set to the ARM position, the emergency lights automatically come on if there is a 28 VDC left main bus power failure. The emergency power supply units receive charging power from the 28 VDC left essential bus with:

- the EMER LIGHTS switch in either the ARM or OFF position
- the EMERGENCY LIGHTING switch is set to NORMAL
- Power is available to the 28 VDC left main bus.

When the EMERGENCY LIGHTING switch, on the main passenger entrance bulkhead, is set to ON, the emergency lights come on. When the EMERGENCY LIGHTING switch is set to NORMAL, the emergency lights go off, but will come on if there is a 28 VDC left main bus power failure. For this to occur, the EMER LIGHTS switch, in the flight compartment, must be in the ARM position.

The emergency lighting system is protected by the circuit breakers that follow:

- EMER LTS (G3) on the L ESSENTIAL DC Bus (5A)
- EMERGENCY LIGHTS RELAY (E3) on the L MAIN DC Bus (5A).

An EMER LTS DISARMED caution light on the caution and warning panel comes on when the EMER LIGHTS–OFF/ARM/ON switch is not in the armed position.

If the emergency lights come on by the automatic function, they are turned off by the EMER LIGHTS–OFF/ARM/ON switch first set to the ON and then the OFF position.

Units, Power Supply–Emergency Light

Refer Figure - EMERGENCY LIGHTS POWER SUPPLY LOCATIONS

Refer Figure - Emergency Lights Power Supply Unit Electrical Schematic

The emergency lights are powered by four self-contained 6.4 V Ni–Cad battery packs found above the passenger compartment ceiling, near each emergency exit at stations X10.250, X83.000, X654.500 and X690.525.

RESET




Figure - EMERGENCY LIGHTS POWER SUPPLY LOCATIONS




Figure - Emergency Lights Power Supply Unit Electrical Schematic

Lights, Emergency–Cabin

Refer Figure - FORWARD PASSENGER COMPARTMENT EXIT SIGN LOCATIONS

Refer Figure - FORWARD PASSENGER INFORMATION SIGN LOCATION

Refer Figure - AFT SERVICE DOOR EXIT SIGN LOCATION

Refer Figure - Passenger Information Signs II

Emergency lights installed on the ceiling centerline supply emergency lighting for the passenger aisle. Emergency EXIT signs are located near each of the four emergency exits. The emergency lights and EXIT signs are controlled by the EMER LIGHTS–OFF/ARM/ON switch located in the flight compartment or the EMERGENCY LIGHTING–NORMAL/ON switch on the main passenger entrance bulkhead.






Figure - FORWARD PASSENGER COMPARTMENT EXIT SIGN LOCATIONS




EMERGENCY LIGHTING

A

NOTE

View looking forward from
FWD Passenger Compartment.

Figure - FORWARD PASSENGER INFORMATION SIGN LOCATION




LEGEND

1. Aft Service Door Lighted Sign.
2. Aft Service Door Lower Lighted Sign.

NOTE

Aft Service Door lighted signs shown
Aft Passenger Door signs similar.

Figure - AFT SERVICE DOOR EXIT SIGN LOCATION



LEGEND

1. EXIT lighted sign (mounted on aft ceiling panel).

NOTE

View looking aft in passenger compartment.

Figure - Passenger Information Signs II


Lights, Emergency–Egress

Refer Figure - Emergency Egress Lights

On aircraft without ModSum 4–458983 incorporated, the fixed exterior emergency egress lights are located at the left and right aft emergency exits, the front right emergency exit (Type II/III) and the forward passenger door. They are controlled by the EMER LIGHTS–OFF/ARM/ON switch located in the flight compartment or the EMERGENCY LIGHTING–NORMAL/ON switch on the main passenger entrance bulkhead.


Refer Figure - Emergency Egress Light

On aircraft with ModSum 4–458983 incorporated, the fixed exterior emergency egress lights are located at the left and right aft emergency exits, the front right emergency exit (Type 1) and the forward passenger door. They are controlled by the EMER LIGHTS–OFF/ARM/ON switch located in the flight compartment or the EMERGENCY LIGHTING–NORMAL/ON switch on the main passenger entrance bulkhead.



s780a01.dg, nn, may18/2014

Figure - Emergency Egress Lights



cg3299a01.dg, nn, may16/2014

POST MODSUM 4-458983

Figure - Emergency Egress Lights




Figure - Emergency Egress Lights Electrical Schematic

Refer Figure - Emergency Floor Path Light Assembly

Emergency floor-path-lighting is installed on the passenger compartment floor with silicone adhesive and double sided tape, to direct persons to the emergency exits. Each light assembly consists of a light cover, a photoluminescent tape, a light base and end caps, where applicable.

The light strips are continuously charged by operation of the aircraft lighting system and available light. The system is considered to be sufficiently charged after 15 minutes of exposure to aircraft lighting. This is to meet the escape path lighting requirements for the longest permitted flight.

NOTE

Each light shows an expiry date on its mating side.




Figure - Emergency Floor Path Light Assembly