Table of Contents

Purpose/Policy:..... 1

Scope:..... 2

Definitions/Acronyms:..... 2

Authorities/Responsibilities:..... 2

Resources and Materials:..... 2

PPE Required:..... 3

Procedures:..... 3

Operations of the External Washer (EW):..... 3

Changeover Guide:..... 3

Basic Cleaning of the External Washer (EW):..... 3

Deep Cleaning:..... 4

Forms:..... 4

Reference Documents:..... 4

Common Issues:..... 4

Document History and Approval:..... 4

Purpose/Policy:

“This “EW Operations” standard operating procedure has been created to assist operators with setup, operations, changeover, cleaning, and troubleshooting.

Scope:

When packaging product on the Racker, the EW or External Washer is used to clean the outside of the kegs. “

Definitions/Acronyms:

- SOP – Standard Operating Procedure
- PPE – Personal Protective Equipment
- EW – External Washer
- F400 – Caustic cleaning solution (Rochester Midland)

Authorities/Responsibilities:

“This SOP can be completed by an entry level packaging operator after proper training from a senior member of the Keg line packaging team. The objective of this SOP is to gain the knowledge needed to perform “EW Operations” and trouble shoot any issues that may arise.”

Resources and Materials:

Operations:

- Empty Kegs.
- Rubber Gloves.

Changeovers:

- N/A

Basic Cleaning:

- Trash Barrel.
- F400 Foaming Unit.
- Power Washer.
- Steam Trap Bucket.

Troubleshooting:

- Inspection of empty kegs for wear, format, brand, and damage.
- See troubleshooting guide for Keg Jam removal.

PPE Required:

- During the foaming operation in the cleaning section of this SOP document, rubber gloves, a face shield, and safety glasses must be worn.

Procedures:

Operations of the External Washer (EW):

1. Verify what keg size is being packaged.
    1.1 If packaging 20L logs, the rails need to be in the “down position.”
    1.2 If packaging 30/50L barrels, the rails need to be in the “up position.”
2. Ensure the EW is clear, and the nozzles are facing towards the keg stand station.
3. Place the EW door on the EW and lock it in place.
4. Press the green “Program Start” button to begin operations.

Changeover Guide:

1. If switching sizes from 20L logs to 30L/50L barrels, place the rails in “up position.”
2. If switching sizes from 30L/50L barrels to 20L Logs, place the rails in the “down position.”

Basic Cleaning of the External Washer (EW):

1. Unlock and remove the door from the EW.
2. Using proper PPE as outlined in the SOP, prepare the foamer unit as listed below.
    2.1 Using a mixture of hot and cold water, fill the F400 foaming unit with 5 gallons of water. Water should be no hotter than 160 degrees.
    2.2 Add 6oz of F400 per gallon of water to the foaming unit.
    2.3 Plug in the air line.
3. From the outside of the EW, foam inwards towards the center of the machine ensuring foam comes into contact will all parts.
    3.1 Repeat the step above from the other end of the machine.
4. Foam from the middle of the machine, through the doorway to hit the center of the machine.
5. Spray foam onto the EW door and around the EW on the floor.
6. After the EW has been foamed, rinse with a hot hose.
    6.1 If deep cleaning, the power washer can be used to help facilitate cleaning.
7. In the back of the EW, there is a steam trap. Follow the steps below to clean.
    7.1 Remove the little screen and brush off all the waste into the waste bucket.
    7.2 Replace the little screen and remove the larger screen.
    7.3 Brush off all the waste from the large scree into the waste bucket.
    7.4 Replace the large screen with the steam trap.
    7.5 Verify the trap area is clean around the outside.

Deep Cleaning:

1. Refer to Racking Zone Cleaning, Zone #5 for more information.

Forms:

Not Applicable

Reference Documents:

Not Applicable

Common Issues:

1. In the event of “keg jam” follow the steps below:
    - 1.1 Press the red button “Program Stop” to stop the EW.
    - 1.2 Open the door using the key.
    - 1.3 Remove all kegs from inside the EW.
    - 1.4 Simultanesly press and hold “Program start” (Green Button) and “Cycle Starting” (Yellow Button).
    - 1.5 The machine will go into “Auto” once this has been completed.
    - 1.6 Replace the door and lock it with the key.

Document History and Approval:

Revise document history as described in the table and key below.

(Reference to following document: B1C.SOP.P001: Document Control and Approval Procedure Template)

VERSION NO.	VERSION DATE	DESCRIPTION OF CHANGE	AUTHOR NAME/PROJECT MANAGER
001	2024/07/11		Kyle Szymanski
002	2026/10/26	Updated SOP to Newest Layout Version	Kyle Szymanski

Version Approval Number: 002

Approved by: Kyle Szymanski

Position Title: OSCI Manager

Date: 10/26/26