Table of Contents

Purpose/Policy:.....1

Scope:.....2

Definitions/Acronyms:.....2

Authorities/Responsibilities:.....2

Resources and Materials:.....2

PPE Required:.....2

Procedures:.....3

Setting up the Stretch Wrapper:.....3

Operation of the Stretch Wrapper:.....3

Changeover Guide:.....3

Shutting Down the Stretch Wrapper:.....3

Basic Cleaning of the Stretch Wrapper:.....3

Deep Cleaning:.....4

Forms:.....4

Reference Documents:.....4

Common Issues:.....4

Document History and Approval:.....4

Purpose/Policy:

The purpose of this SOP is to operate and troubleshoot the Keg Line Stretch Wrapper. The Stretch Wrapper is used to wrap pallets of kegs to make them safer and more stable to ship and move around.

Scope:

Keg Line operators setting up, operating, troubleshooting, and cleaning the Keg Line Stretch Wrapper used to wrap pallets of kegs.

Definitions/Acronyms:

- SOP – Standard Operating Procedure
- PPE – Personal Protective Equipment
- HMI – Human Machine Interface (the touch screen used to control a machine)
- E-Stop – Emergency Stop button
- Stretch Wrapper – Machine that wraps pallets of kegs in stretch film

Authorities/Responsibilities:

When finishing a pallet of kegs, it is the operator's responsibility to make sure the kegs are fully wrapped. When filling kegs with product, it is also the operator's responsibility to keep track of the number of finished kegs.

Resources and Materials:

Operations:

- Wooden Pallet
- Plastic Shrink Wrap

Basic Cleaning:

- Broom and dustpan

Deep Clean:

- Refer to SOP for Zone Cleaning 4

Troubleshooting:

- No Equipment required.

PPE Required:

Include formal PPE required. Include suggested PPE is no formal is required.

- No formal PPE required, suggested nitrate gloves for cleaning.

Procedures:

Setting up the Stretch Wrapper:

1. Make sure stretch wrap is loaded onto the wrapping arm in the correct orientation.
2. Make sure stretch is loaded into metal holding clamp.
   2.1 If stretch wrap isn't loaded into the metal clamp press the white "Film Clamp Open/Close" button to open the metal clamp and insert plastic stretch wrap. Then press the button again to close the clamp.
3. Ensure that the stretch wrapper arm reflector is in the outlined area of the rollers.
4. Make sure you have an empty pallet in the first position and not too far advanced on the rollers where it is blocking the wrong eyes.
5. Acknowledge any faults on the HMI.
6. Press the black "Reset" button and then press the green "Start/Stop" button.

Operation of the Stretch Wrapper:

1. After setting up the Stretch Wrapper operates in an automatic way.
2. Once a pallet of kegs is built press the "Load Release" button to move a pallet into the wrap position.
3. After a pallet is wrapped, it will move to the third position where it will need to be removed by a forklift.

Changeover Guide:

1. The only time this machine is changed over is when going from 13.2 or 5.17 to 30L kegs.
2. While on automatic mode screen press the "Next Pattern" option.
3. Type the number for the pattern that you will be using.
   3.1 "2" is used for 13.2 and 5.17 kegs.
   3.2 "3" is used for 30L kegs.
4. Nex press "Enter". The next time a pallet is released the new pattern will be loaded.

Shutting Down the Stretch Wrapper:

1. Make sure the stretch wrapper arm has finished its cycle and there are no pallets left on the rollers.
2. Press the "E-Stop" on the main cabinet.

Basic Cleaning of the Stretch Wrapper:

1. Make sure any pieces of wood are removed from the rollers.
2. Sweep up the surrounding area with a broom and dust pan.

Deep Cleaning:

1. Refer to SOP Zone cleaning 4.

Forms:

Not Applicable

Reference Documents:

Not Applicable

Common Issues:

1. If a pallet isn't moving from the first position into the wrapped position, make sure it isn't too far advanced and blocking the eyes.
   1.1 Pallets can be jogged manually by selecting the "Manual Menu" on the HMI and then jogging the conveyors with the switch.
2. If the stretch wrap breaks wait for the arm to finish moving before fixing the stretch wrap.
   2.1 Once the wrapper arm has stopped press the white "Film Clamp Open/Close" button to open the metal clamp and insert plastic stretch wrap. Then press the button again to close the clamp.
   2.2 Reset the stretch wrapper and press the "Start/Stop" button.
3. If the wrapper arm isn't wrapping make sure the sensor lines up reflector on the bottom of the wrapper arm.

Document History and Approval:

Revise document history as described in the table and key below.

(Reference to following document: B1C.SOP.P001: Document Control and Approval Procedure Template)

VERSION NO.	VERSION DATE	DESCRIPTION OF CHANGE	AUTHOR NAME/PROJECT MANAGER
001	2024/08/13		Kyle Szymanski
002	2026/10/26	Updated SOP to Newest Layout Version	Kyle Szymanski

Version Approval Number: 002

Approved by: Kyle Szymanski

Position Title: OSCI Manager

Date: 10/26/26