Commands cheat sheet

On the Jetson, in `~/GrappStar/jetson`. Full lists: `firmware/base/PROTOCOL.md`, `firmware/dart/API.md`, `jetson/README.md`. If a command here and those files disagree, those files win.

Jetson

Command	What it does
`python3 -m grappstar serve`	operator page at http://<jetson>:8080 (`--sim` for no hardware)
`python3 -m grappstar base ping` / `status` / `monitor`	talk to the base; `monitor` shows live telemetry (Ctrl+C stops)
`python3 -m grappstar base cmd '<json>'`	send one base command (below)
`python3 -m grappstar dart status`	one dart status reading
`python3 -m grappstar dart key 2 --hold 1.0`	hold a dart key for 1 s (quote `'!'`, `'#'`, `'$'`)
`python3 -m grappstar dart auto` / `release` / `flightlog`	anchor, release, download the flight log
`python3 -m grappstar cameras`	list the cameras
`sudo shutdown now`	before unplugging the battery

Base commands (JSON, for `base cmd`)

Command	What it does
`{"cmd":"estop"}`	wiper off, drum to NEUTRAL when safe. Always safe to send
`{"cmd":"stop"}`	wiper off, drum stays
`{"cmd":"clear"}`	clear a fault once its cause is gone
`{"cmd":"mode","to":"LAUNCH"}`	drum to LAUNCH, NEUTRAL or REEL
`{"cmd":"aim","deg":30}`	rail to 30 degrees (only with the carriage home)
`{"cmd":"arm"}` then `{"cmd":"fire","token":123456}`	fire within 3 s of arm. Tether on, area clear
`{"cmd":"cal","what":"decock"}`	unload a cocked carriage slowly
`{"cmd":"wrap"}` / `{"cmd":"unwrap"}`	lay / remove the capstan wraps (order: PROTOCOL.md)
`{"cmd":"reel","duty":0.5,"until":"seated"}`	wind in until the dart seats (`until`: stop, seated, tension)
`{"cmd":"jog","motor":"wiper","dir":1,"ms":300}`	short move; `motor` wiper or drum, `dir` 1 or -1, up to 1500 ms
`{"cmd":"set","key":"limit_n","val":50}`	set a stored value (tow limit 50 N)
`{"cmd":"get","key":"limit_n"}`	read a stored value

Dart keys (WiFi KEDGE, password grappstar, http://192.168.4.1, or Serial 115200)

Key	Motor
1 / !	deploy pods down / up
2 / @	kick out / back
3 / #	drills in / out
4 / $	foot in / out
space	STOP everything
a / A	auto anchor now / arm auto-anchor on landing
i / b / z	current / attitude / I2C scan