WildBeat Bluetooth Speaker

1. W	'elcome to WildSound	3	
	1.1 Introducing the WildBeat Bluetooth Speaker	3	
	1.2 Package Contents	3	
2. G	etting Started	dBeat Bluetooth Speaker 3 4 er 4 oth Devices 4 5 nd Playback Controls 5 ures 5 5 5 5	
	2.1: Charging the Speaker	4	
	2.2: Powering On/Off	4	
	2.3: Pairing with Bluetooth Devices	4	
3. U	sing Your WildBeat		
	3.1: Adjusting Volume and Playback Controls	5	
	3.2: Weatherproof Features	5	
	3.3: 360-Degree Sound	5	
4. Tr	Troubleshooting		
	4.1 Device not powering on	7	
	4.2 Bluetooth connectivity issues	7	
	4.3 Poor sound quality	7	
	4.4 LED indicator not functioning	8	
5. Te	chnical Specifications	9	
	5.1 Dimensions and Weight	9	
	5.2 Battery	9	
	5.3 Connectivity	9	
	5.4 Sound	9	
	5.5 Construction	9	
	5.6 Controls	9	
	5.7 Additional Features	10	

1. Welcome to WildSound

1.1 Introducing the WildBeat Bluetooth Speaker

Welcome to the WildSound family! We are thrilled to introduce you to our WildBeat Bluetooth Speaker, the perfect companion for all your outdoor adventures. Whether you're camping, hiking, or just hanging out in the backyard, the WildBeat Speaker is designed to bring the party wherever you go. With its portable and weatherproof design, you can enjoy your favorite tunes rain or shine. And with its 360-degree sound, you'll never miss a beat, no matter where you are. Get ready to experience music like never before with the WildBeat Bluetooth Speaker from WildSound!

1.2 Package Contents

When you open the box, you will find the following items included with your WildBeat Bluetooth Speaker:

- 1. WildBeat Bluetooth Speaker
- 2. USB charging cable
- 3. User manual
- 4. Carabiner clip

With these items, you'll have everything you need to start enjoying your music wherever your adventures take you!

2. Getting Started

2.1: Charging the Speaker

To charge your WildBeat Bluetooth Speaker, use the included USB-C cable to connect the speaker to a power source. The LED indicator light on the back of the speaker will glow red while charging and turn off when fully charged. It takes approximately 3 hours to fully charge the speaker. Please ensure you use the original charging cable provided to avoid any damage to the speaker.

2.2: Powering On/Off

To power on the WildBeat Bluetooth Speaker, press and hold the power button located on the top of the speaker for 3 seconds. The LED indicator will flash blue, indicating that the speaker is turned on. To power off the speaker, press and hold the same power button for 3 seconds. The LED indicator will turn off, indicating that the speaker is powered off.

2.3: Pairing with Bluetooth Devices

To pair the WildBeat Bluetooth Speaker with your Bluetooth device, ensure that the speaker is turned on. Then, activate the Bluetooth function on your device and select "WildBeat" from the list of available devices. Once connected, the LED indicator on the speaker will turn solid blue. You are now ready to play your favorite tunes through the WildBeat Bluetooth Speaker.

3. Using Your WildBeat

3.1: Adjusting Volume and Playback Controls

Welcome to using your WildBeat Bluetooth speaker! Adjusting the volume and controlling your music is easy. Simply locate the control buttons on the top of the speaker:

- Volume Up/Down: Press the "+" button to increase the volume, and the "-" button to decrease it. You can also hold down these buttons to quickly adjust the volume.
- **Play/Pause**: Press the center button to play or pause your music. You can also use this button to answer or end phone calls when connected to your smartphone.

To skip to the next track, simply press the ">" button, and to go back to the previous track, press the "<" button.

Keep the party going and the music flowing with these easy playback controls!

3.2: Weatherproof Features

The WildBeat Bluetooth speaker is built to withstand the elements, so you can take your music anywhere. With its weatherproof features, you can enjoy your favorite tunes by the pool, at the beach, or even during a light rain shower.

The speaker's durable construction and protective covering ensure that it can handle splashes, dust, and light water exposure. While we don't recommend submerging the speaker in water, you can feel confident using it outdoors without worrying about damage from unexpected weather conditions.

So, go ahead and bring the WildBeat along on your outdoor adventures—rain or shine!

3.3: 360-Degree Sound

Experience immersive, 360-degree sound with the WildBeat Bluetooth speaker. Unlike traditional speakers that project sound in one direction, the WildBeat fills the entire space with high-quality audio, ensuring that everyone at your campsite or outdoor gathering can enjoy the music.

Thanks to its innovative design, you can place the speaker anywhere and still enjoy the same exceptional sound quality. Whether you're sitting around a campfire, lounging on the beach, or hosting a backyard BBQ, the WildBeat delivers clear and balanced sound from every angle.

Get ready to surround yourself with music and create lasting memories with the WildBeat's impressive 360-degree sound!

4. Troubleshooting

4.1 Device not powering on

If your WildBeat Bluetooth Speaker is not powering on, try the following steps:

- 1. Make sure the speaker is fully charged by connecting it to a power source using the included USB cable. The battery indicator light should turn on when it's charging.
- 2. If the battery indicator light does not turn on, try using a different power outlet or USB cable.
- 3. Press and hold the power button for 5 seconds to reset the speaker.

If the issue persists, please contact our customer support for further assistance.

4.2 Bluetooth connectivity issues

If you're having trouble connecting your device to the WildBeat Bluetooth Speaker, follow these steps:

- 1. Make sure the speaker is in Bluetooth pairing mode by pressing and holding the Bluetooth button until the indicator light flashes.
- 2. On your device, go to the Bluetooth settings and select "WildBeat" from the list of available devices.
- 3. If prompted, enter the pin 0000 to complete the pairing process.

If you're still unable to connect, try turning off Bluetooth on your device and then turning it back on. If the issue persists, try restarting your device.

4.3 Poor sound quality

If you're experiencing poor sound quality from the WildBeat Bluetooth Speaker, try the following solutions:

- 1. Make sure the speaker is placed on a stable surface and not near any obstructions that could interfere with the sound.
- 2. Check the volume level on both the speaker and your device to ensure they are not set too low.
- 3. If you're using the speaker outdoors, try moving it to a different location to see if the sound quality improves.

If none of these solutions work, try resetting the speaker by pressing and holding the power button for 5 seconds.

4.4 LED indicator not functioning

If the LED indicator on your WildBeat Bluetooth Speaker is not functioning as expected, please try the following:

- 1. Ensure that the speaker is fully charged and powered on.
- 2. Check if there are any obstructions blocking the LED indicator.
- 3. Try resetting the speaker by pressing and holding the power button for 5 seconds.

If the LED indicator still does not work, please contact our customer support for further assistance.

5. Technical Specifications

5.1 Dimensions and Weight

Length: 7 inchesWidth: 3.5 inchesHeight: 3 inchesWeight: 1.5 lbs

5.2 Battery

• Type: Rechargeable lithium-ion

• Capacity: 3000 mAh

Playtime: Up to 12 hours

5.3 Connectivity

• Bluetooth version: 5.0

Bluetooth range: Up to 50 feet

• Audio input: Bluetooth, 3.5mm auxiliary

5.4 Sound

Power output: 20W

• Frequency response: 60Hz - 20kHz

• 360-degree sound dispersion

5.5 Construction

Material: Weatherproof and shock-resistant

• Color options: Black, Blue, Red

• IP rating: IPX5

5.6 Controls

Power button

Volume up/down buttons

Bluetooth pairing button

- Play/pause button
- LED indicator

5.7 Additional Features

- Built-in microphone for hands-free calls
- USB charging port for external devices
- Carabiner clip for easy attachment
- LED battery indicator