Frame	TTC Lidar	Manual Calculation TTC Lidar	Error
1	12.97	13.18	0.21
2	12.26	13.08	0.82
3	16.96	12.98	3.98
4	14.62	6.98	7.64
5	10.66	19.10	8.44
6	9.5	12.63	3.13
7	17.57	25.17	7.60
8	18.79	9.34	9.45
9	15.89	18.58	2.68
10	13.73	18.48	4.74
11	11.48	7.29	4.19
12	9.32	36.35	27.03
13	9.22	8.99	0.23
14	10.97	11.88	0.91
15	8.09	7.82	0.27
16	8.81	6.94	1.87
17	10.29	17.25	6.96
18	9.89	7.57	2.32