AuraTemp T200 Smart Thermostat - User Manual

1. Package Contents and Specifications

The AuraTemp T200 package includes the thermostat display, a mounting plate, two M3 screws, a wire label sheet, and a quick-start card. A C-wire adapter is included for homes without a common wire.

Specification	Value
Display	3.5-inch color touchscreen
Connectivity	Wi-Fi 2.4 GHz and Bluetooth 5.0
Power	24V AC (C-wire required)
Backup battery	Rechargeable, lasts up to 8 hours
Temperature range	45F to 95F (7C to 35C)
Warranty	3 years from date of purchase

2. Installation

Before installing, switch off power to your HVAC system at the circuit breaker. Take a photo of your existing wiring and label each wire using the supplied stickers. Remove the old thermostat, attach the mounting plate with the two M3 screws, and connect the labeled wires to the matching terminals. Snap the display onto the plate and restore power.

If your system has no C-wire, connect the included adapter to the R and Y terminals as shown in the diagram. Installation typically takes 20 to 30 minutes. If you are unsure about wiring, hire a licensed HVAC technician.

3. Connecting to Wi-Fi and the App

Download the Aura Home app from the App Store or Google Play and create an account. Tap 'Add device' and hold the thermostat ring for 5 seconds until the screen shows a pairing code. Enter the code in the app and select your 2.4 GHz Wi-Fi network. The T200 does not support 5 GHz networks.

4. Scheduling and Eco Mode

The T200 supports up to 6 schedule periods per day. By default, the thermostat uses Comfort mode during the day at 72F and lowers to 66F overnight. In Eco mode, the thermostat widens the temperature range by 4 degrees to save energy; Aura estimates that Eco mode reduces heating and cooling costs by about 12 percent.

Geofencing can automatically switch to Away mode when the last registered phone leaves a 1-mile radius around your home. Away mode sets the temperature to 62F in winter and 82F in summer.

5. Troubleshooting

If the screen is blank, check that the circuit breaker is on and that the wires are firmly seated. If the screen shows error E04, the thermostat has lost its Wi-Fi connection: restart your router, then hold the ring for 10 seconds to reconnect. Error E12 indicates a wiring fault, usually a missing C-wire, and power should be switched off before checking connections.

To factory reset, hold the ring for 20 seconds until the screen shows the Aura logo. A factory reset erases all schedules and Wi-Fi settings but does not delete your account. Firmware updates install automatically between 2:00 and 4:00 AM when the thermostat is connected to Wi-Fi.

6. Warranty and Support

The three-year warranty covers manufacturing defects but not damage from incorrect wiring or power surges. To claim, contact support at support@auratemp.example with your order number. Replacement units ship within 5 business days after approval. Phone support is available Monday to Friday, 9:00 to 18:00.