Go2 SDK Development Guide

Search article titles

About Go2
Remote Controller
SDK Concepts 3
Application Development 7
Software Interface Services 19
Motion Services Interface V2.0
DDS Services Interface
Avoidance Services Interface
VuiClient Interface
RobotStateClient Interface
Motion Switcher Service Interface
Sports Services Interface
AI motion Services interface
Basic Services Interface
LiDAR Services Interface
Multimedia Services Interface
UWB Services Interface
Fault Services Interface
SLAM and Navigation Services Interfa
Aruco Recharge Service Interface
Odometer Services Interface
D1 Mechanical Arm Services Interface
ROS2 Services Interface
Python Services Interface
Case reference 8
Debugging Specification
FAQ

VuiClient Interface

Last Updated On：2025-11-21 11:19:42

Volume and Lighting Service Interface

VuiClient Class

`VuiClient` is the Client provided by the voice and lighting service status service. Through `VuiClient`, you can use RPC to control and retrieve information about Go2's volume and lighting (some functional interfaces are not yet open).

Interface Error Code List:

Error Code	Meaning
100	The parameter passed in is incorrect

Class and Interface Description:

Class Name	Construction and Destruction
VuiClient	explicit VuiClient(); ~VuiClient();

Function Name	SetBrightness
Function Prototype	`int32_t SetBrightness(int level)`
Function Overview	Sets the lighting brightness.
Parameters	**level**: Lighting brightness, value range 0~10.
Return Value	Returns 0 on successful call, otherwise returns the relevant error code.
Notes	

Function Name	GetBrightness
Function Prototype	`int32_t GetBrightness(int& level);`
Function Overview	Gets the lighting brightness.
Parameters	**level**: The returned lighting brightness.
Return Value	Returns 0 on successful call, otherwise returns the relevant error code.
Notes	

Function Name	SetVolume
Function Prototype	`int32_t SetVolume(int level);`
Function Overview	Sets the volume level.
Parameters	**level**: Volume level, value range 0~10.
Return Value	Returns 0 on successful call, otherwise returns the relevant error code.
Notes	

Function Name	GetVolume
Function Prototype	`int32_t GetVolume(int& level);`
Function Overview	Gets the volume level.
Parameters	**level**: The returned volume level.
Return Value	Returns 0 on successful call, otherwise returns the relevant error code.
Notes	

This page contains content

Volume and Lighting Servi...
VuiClient Class

Helpful
Feedback

The PDF has been downloaded. Rate us: