YAMAHA

Quick Reference Guide



Welcome

This quick reference guide provides an easy way to locate any (and all) parameters and jobs available in the DX7 II fd/d.

It is comprised of two basic sections:

The Edit Button Quick Reference Guide provides a chart of all the parameters/jobs for each button.

The Individual Button LCD Displays show all of the possible LCD Displays that can be called up with each of the buttons. To the right of the displays, the range of the parameters or the available options are provided.

At the end of the booklet, a blank voice data chart and a blank performance data chart are provided. Please feel free to photocopy these two pages so that you can document any edits you make for your own custom voice library.

For continuing information concerning the DX7 II fd/d, consult AfterTouch, the official publication of the Yamaha Users Group. Many advanced functions will be discussed in its pages in the coming months. There will also be information concerning the availability of other materials concerning more advanced applications. To receive a free copy of AfterTouch every month, send your request to AfterTouch, P.O. Box 2338, Northridge, CA 91323-2338. On your letter or postcard, be sure to indicate that you are the owner of a DX7 II fd/d.

Contents

2 Edit Button Quick Reference Guide

Voice Buttons

- 5 Button 7 LCD Display
- 5 Button 8 LCD Display
- 5 Button 9 LCD Display
- 6 Button 10 LCD Displays
- 6 Button 11 LCD Display
- 7 Button 12 LCD Display
- 7 Button 13 LCD Display

Utility Buttons

- 8 Button 14 LCD Display
- 9 Button 15 LCD Display
- 10 Button 16 LCD Display

Voice Edit Buttons

- 11 Button 23 LCD Displays
- 12 Button 24 LCD Displays
- 12 Button 25 LCD Displays
- 13 Button 26 LCD Displays

Performance Edit Buttons


- 14 Button 27 LCD Displays
- 15 Button 28 LCD Displays
- 16 Button 29 LCD Displays
- 16 Button 30 LCD Displays

MIDI Buttons


- 17 Button 31 LCD Displays
- 18 Button 32 LCD Displays

Edit Button Quick Reference Guide

Voice parameters



Utility parameters



Voice Edit parameters

KEY MODE	PITCH BEND PORTAMENTO	BC MW AT	FC1 FC2
23 55	24 56	25 57	26 58
	Pitch Bend	Breath Control	Foot Control 1
>Key Mode >Unison Detune	>Range >Step Range >Mode	>Pitch Mod >Amplitude Mod >EG Bias >Pitch Bias	>Control Slider 1 >Pitch Mod >Amplitude Mod >EG Bias >Volume
	Portamento	Modulation Wheel	Foot Control 2
	>Mode >Step Range >Time	>Pitch Mod >Amplitude Mod >EG Bias	>Pitch Mod >Amplitude Mod >EG Bias >Volume
	Random Pitch	Aftertouch	MIDI IN Control
	>Depth	>Pitch Mod >Amplitude Mod >EG Bias >Pitch Bias	>Pitch Mod >Amplitude Mod >EG Bias >Volume

Performance parameters


FS CS 59	VOICE MODE	MICRO TUNE	PAN 62
	[28]	[29]	[30]
Sustain Ft. Sw.			
>Bank A >Bank B	>Voice mode	>Tuning Select >Bank A	<i>Pan</i> >Mode
		>Bank B	>Range
Foot Switch			>Select
>Select >Bank A	>Total volume	>EG Forced	
>Bank B	>Balance	Damping	
>Soft Range			Pan Envelope
>Select		Note Shift	>Rates 1~4
CS 1 >Bank A	>Dual detune	>Bank A	>Level 1~4
>Bank B	- or - >Split point	>Bank B	
>Select	z op po	>Performance	
CS 2 >Bank A		Name	
>Bank B			

MIDI parameters


MIDI 1 MIDI 31 63	>Note Selection >Program Change Transmit Mode >Local Mode		Device number Receive block
Program Change	>Program Number to Send	MIDI OUT Voice	>Edit buf >1-32 >33-64
Channel Messages	>Transmit Channel >Receive Channel A >Receive Channel B >Omni Mode	Performance	
	2 Giiiii 10000	MicroTuning	>Edit buf
Control Number	>MIDI In Controller A >MIDI In Controller B >MIDI In Slider 1	7	>INT >CRT
	>MIDI in Slider 2	System Setup	>System setup

Voice Buttons


Button 7 LCD Display




Button 8 LCD Display




Button 9 LCD Display




Button 10 LCD Displays



Button 11 LCD Display




Button 12 LCD Display



>Sync


LFO Sync (off, on)

Button 13 LCD Display




Utility Buttons

Button 14 LCD Displays



Button 15 LCD Displays




>Format Format Disk >Back u∍ Back Up Disk >Free bytes Free Files On Disk (1 - 44) >Dir Internal Files Directory

>Save

>Load

Save Internal File

Button 16 LCD Displays




Load Internal File >Del Delete Internal File >Rename Rename Internal File >Dir Cartridge Files Directory Save Cartridge File >Load Load Cartridge File >Del Delete Cartridge File >Rename Rename Cartridge File Cartridge Bank (1 - 4)


MDR File In >Out MDR File Out >Del Delete MDR File >Rename Rename MDR File

Voice Edit Buttons


Button 23 LCD Displays




Button 24 LCD Displays



Button 25 LCD Displays




Button 26 LCD Displays




Performance Edit Buttons


Button 27 LCD Displays




Button 28 LCD Displays



Button 29 LCD Displays




Button 30 LCD Displays




MIDI Buttons

Button 31 LCD Displays



Button 32 LCD Displays





Voice name:

Date

/

ALGORIT	НМ	OSCILLATOR	ОР	ı	2	3	4	5	6	Key mode	Foot control I
ALG		Mode	1							Key assign mode	P. MOD
FBL		Coarse•Fine								Unison detune	A. MOD
OSC.Sync		Detune								Pitch Bend	EG. B
Transpose		E G	ОР	ı	2	3	4	5	6	Range	P. Bias
L F	0	RS								Step	Foot control 2
Wave		RI								Mode	P. MOD
Speed		R2								Portamento	A. MOD
Delay		R3								Mode	EG. B
Mode		R4								Step	P. Bias
PMS		LI								Time	MIDI IN control
PMD		L2								Random pitch S.	P.MOD
AMD		L3								Modulation Wheel	A. MOD
Sync		L4								P. MOD	EG. B
Pitch E	E G	Output Level	ΟР	ı	2	3	4	5	6	A. MOD	P. Bias
Range		Cline	_ ا							EG. B	
Velocity		Scaling mode								Breath Control	
RS		Output Lev	el							P. MOD	
RI		LD								A. MOD	
R2		LC								EG. B	
R3		BP								P. Bias	
R4		RC								After Touch	
LI		RD								P. MOD	
L2		Sensitivity	ОР	l	2	3	4	5	6	A. MOD	
L3		Velocity								EG. B	
L4		AMS								P. Bias	
					1	1	1	1	I	.4	U

Blank Performance Data Chart

7

Performance name:

		Α		В
Voice mode				
Voice No(name)				
Total volume		,		
Balance				
Dual detune				
Split point			,	
Sustain foot switch			· 2 · · · ·	-
Foot switch				
()RNG				
Continuous slider I				
()				
Continuous slider 2				
(
Micro tuning table select		•		
(
Key=				
EG forced damping				
Note shift				
PAN mode				
PAN range				
PAN select				
PAN EG	RI	R2	R3	R4
FAIN EU	LI	L2	L3	L4