DualSense Wireless Adapter

USER GUIDE / EN

01 / First connection

Plug the adapter directly into USB. Hold PS + Create on the controller until its light flashes to pair. If discovery has stopped, click the adapter button once while no controller is connected. Then click Connect adapter in the panel.

02 / Connect again

Press PS on a previously paired controller. If it was forgotten, repeat PS + Create pairing. The adapter may not expose its gamepad USB interface until a controller connects.

03 / Adapter button

One click: disconnect the current controller, or start discovery when none is connected. Two clicks: restart the adapter firmware. Three clicks: enter firmware flashing mode; normal operation stops. Hold for about 1.5 seconds: disconnect and forget all pairings. This is destructive. Six LED flashes confirm clearing. Clicks are detected after a short pause (about 500 ms between clicks).

04 / LED signals

The LED indicates connection activity. With a connected controller it is normally on, unless disabled. Battery at or below the reported 10% level while discharging triggers a 1 Hz blink, even if the LED is disabled (unless the firmware build omits battery LED support). During discovery, the LED toggles about every 200 ms. After a watchdog restart, it flashes three times (in builds without ENABLE_SERIAL).

Settings & information

05 / Saving settings

Edit settings, then click Save changes. The panel checks current values and reads them back after sending the commands. Firmware does not return flash-write success. To verify persistence, physically unplug power and reconnect the same adapter, then use Compare after power cycle. USB reconnect alone does not restart firmware.

06 / Troubleshooting

Use desktop Chrome or Edge with WebHID over HTTPS or localhost. If the adapter is missing, pair the controller first, try another USB port and close Steam, DSX or other tools that may hold the device. Denied access: review site permissions and retry using Connect adapter. Unknown firmware: writing is disabled. Audio volume is also managed by the operating system. For unreliable wake, check USB wake support in BIOS/UEFI and Windows; the panel does not modify system settings.

Licenses and product information

Independent product, not affiliated with or authorized by Sony Interactive Entertainment. DualSense and PlayStation are trademarks of their owners. The panel uses its own interface and protocol implementation. Firmware is not included with the web panel.

DS5Dongle: MIT, copyright awalol (2026); audio.cpp: MPL-2.0. Firmware dependencies have separate terms, including WDL, Opus, Pico SDK, TinyUSB, BTstack and libcyw43. Raspberry Pi supplemental commercial licensing depends on the hardware. The exact firmware build and product hardware must be checked before commercial distribution.

React, React DOM, Vite, Tailwind CSS, Vitest: MIT. TypeScript: Apache-2.0. Lucide: ISC; Feather-derived icons: MIT. Full installed-package notices are available under About & licenses in the panel and in THIRD_PARTY_NOTICES.md.

DS5Dongle source

MPL 2.0

BTstack supplemental license

Profile based on source analysis; physical adapter acceptance testing is required.