the end of symbols. E.g. 50 m and not as 50 m.

5. The symbols of the units are not expressed in plural form. E.g. 10 kg not as 10 kgs.
6. When temperature is expressed in kelvin, the degree sign is omitted. E.g. 283 K not as 283° K (If expressed in celsius scale, degree sign should be included e.g. 100°C not as 100 C, 108° F not as 108 F).
7. Use of solidus (/) is recommended for indicating a division of one unit symbol by another unit symbol. Not more than one solidus is used. E.g. ms^{-1} or m/s. J/K/mol should be $JK^{-1}mol^{-1.}$
8. The number and units should be separated by a space. E.g. 15 $kgms^{-1}$ not as 15 $kgms^{-1}$.
9. Accepted symbols alone should be used. E.g. ampere should not be written as amp and second should not be written as sec.
10. The numerical values of physical quantities should be written in scientific form. E.g. the density of mercury should be written as 1.36×10^4 kgm^{-3} not as 13600 kgm^{-3}.

1.6 Vernier Caliper and Screw Gauge

In our daily life, we use metre scale for measuring lengths. They are calibrated in cm and mm. The smallest length which can be measured by metre scale is called least count. Usually the least count of a scale is 1 mm. We can measure the length of objects upto 1 mm accuracy with this scale. By using vernier caliper we can have an accuracy of 0.1 mm and with screw gauge we can have an accuracy of 0.01 mm.

1.6.1 Description of Vernier caliper

The Vernier caliper consists of a thin long steel scale graduated in cm and mm called main scale. To the left end of the main scale an upper and a lower jaw are fixed perpendicular to the bar. These are named as fixed jaws. To the right of the fixed jaws, a slider with an upper and a lower moveable jaw is fixed. The slider can be moved or fixed to any position using a screw. The Vernier scale is marked on the slider and it moves along with the movable jaws and the slider. The lower jaws are used to measure the external dimensions and the upper jaws are used to measure the internal dimensions of the objects. The thin bar attached to the right side of the Vernier scale is used to measure the depth of hollow objects.




Figure 1.2 Vernier Caliper

1.6.2 Usage of Vernier caliper

The first step in using the Vernier caliper is to find out its least count, range and zero error.

a) Least count

Least count of the instrument (L.C)

$$= \frac{\text{Value of one main scale division}}{\text{Total number of vernier scale division}}$$

The main scale division will be in centimeter, further divided into millimetre. The value of the smallest main scale division is 1 mm. In the Vernier scale there will be 10 divisions.

$$\therefore \quad \text{L.C} = \frac{1\text{mm}}{10} = 0.1\text{mm} = 0.01\text{cm}$$

b) Zero error

Unscrew the slider and move it to the left, such that both the jaws touch each other.

IX_SCI_EM_Unit-01_PHY.indd 5 12-02-2020 14:09:42