10.4.3 PETROL ENGINE

Indicating and warning of rectification of engine parts

1. Speedo meter needle always shows zero

Causes	Remedies
1. Speedo meter spindle shafts does not connected	To be repaired
2. Driving key may be wear or broken	To be changed
3. Driver gear may be wear	To be changed
4. Speedo meter may be repaired	To be changed
5. Speedo meter cable may be broken	To be changed

2. Fuel gauge pointer always shows E

Causes	Remedies
1. The wire of ignition switch to gauge or gauge to tank unit may be disconnected	To be checked and rectified
2. Does not earthing of tank unit	To be earthed
3. The float may be punchered	To be changed
4. Gauge may be damaged	To be changed

3. Fuel gauge pointer always shows F

Causes	Remedies
1. Does not earthing of gauge casing	To be proper earthed
2. The tank unit terminal may be earthed	To be insulated
3. Float arm may be checked	To be checked and rectified
4. Gauge may be damaged	To be changed

AM_Unit_10.indd 210 31-01-2019 18:04:27