Dismantling

1. Remove the Carburettor top lid with a proper tool.
2. Remove the hinge plate pin in the float chamber and place in a tray.
3. Float need to be taken out and cleaned and to be kept in a jar with weight over it and immersed with spirit to see if there is any damage in the float.
4. Float need to be kept in the same position for some time. Place the sprit sensor paper on the circumference of the float for checking the crack.
5. Check and replace the float with new one if there is any damage.
6. Starting circuit need to be removed with proper tools and lever, starting valve, washer to be kept in a tray after removing separately.
7. Distributor passage to be removed with proper tools and its gasket to be removed and to be kept in a tray separately.
8. Take the Main jet out.
9. Remove the valve in the outlet separately.
10. Idling speed adjusting Screw spring to be kept in a tray without damage to its tip.
11. Remove the Pilot jet adjusting screw using proper tools and keep in the tray. Check for any damages without opening the throttle valve.

Servicing

1. Clean all the dismantled parts with petrol.
2. Wipe all the parts with fine cloth.
3. Clean the Small passages with fine brush.
4. Clean all the parts using low pressure air.

Inspection

1. Check the Carburettor for damages with magnifying glass
2. Replace with the new one if there is any crack or damage found
3. Check the Throttle valve for any damage.
4. Check the Main Jet with Go No Go gauge.
5. Check the Idling adjusting Screw with needle. Reject and replace with a new spare if not in good condition.

Re-Assembling

1. Assemble in the reverse process of dismantling in order.
2. While assembling gasket, replace the washer with new spares.

Conclusion

The given carburetor is examined, serviced and fixed in the engine.

AM_English_Practicals.indd 251 12/20/2019 5:50:02 PM