Materials Required

1. Waste Cotton
2. Kerosence
3. Degreaser
4. Lubricating Oil SAE 30
5. Emery sheet

Reasons for Dismantling

1. Low oil pressure
2. Block in oil filter
3. Loose connection in suction of oil filter
4. Hole in Oil filter
5. Company recommended period of inspection and servicing lapses

Dismantling

1. Start and run the engine up to the working temperature reaches 70^0 C.
2. Stop the engine and drain the oil from the sump after some time.
3. Remove the connections of inlet and outlet of the oil pump.
4. After removing the distributor remove the oil pump from the crankcase.
5. Dismantle Driving gear, Driven gear and all other parts and clean them by degreaser and kerosene.

Inspection

a) Gear Type Oil Pump

1. To check the damages of the gears and clean the surface by using emery sheet.
2. Check the gap between pump shafts and pump body. (Pump shaft to body clearance).
3. Check the gap between drive Gear and Pump Shaft. (Drive gear to spindle clearance).
4. Check the gap between Gear and Pump body (gear to body clearance).
5. Measure the gap between pump shaft guide to guide push clearances.

AM_English_Practicals.indd 253 12/20/2019 5:50:02 PM