- If pressure relief valve is joined with the pump cover, then spring, adjusting screws need to be removed and cleaned and refitted in the correct manner.
- Start the engine after the oil sump is filled with lubricating oil. The pressure of the lubricating oil is measured by pressure gauge by increasing the engine speed and compared with recommended quantity by the company.

Precaution

- Compare the actual clearances with the recommended clearances by the manufacturer. If it exceeds the limit, pumps will not be allowed to use.
- If the gear or rotor has any breakage or crack, the pump will be rejected and new one should be replaced.

Conclusion

Fuel pump from the given engine is dismantled,examined and reassembledafter servicing.

AM_English_Practicals.indd 255 12/20/2019 5:50:03 PM