3. While removing, the diaphragm may stick to the upper chamber. So required caution to be taken.
4. Remove the Grub screw joining the Rocker arm and keep separately.

Inspection and Servicing

1. Check if the filter element is damaged
2. Check if the diaphragm is damaged and if so replace it with new one.
3. Check if the inlet valve and outlet valve in the valve retainer are working well.
4. All the removed particles are cleaned with petrol using brush.
5. Check if the spring and Valve seats are damaged and if so they are replaced by new ones.

Reassembling

1. Fix the valve retainer in the right place and screw with bolt and nut.
2. By pressing the Diaphragm assemble rocker arm in the lower chamber
3. Tightly screw Rocker arm with bolt to avoid disconnection
4. Bring the holes on the Lower chamber, diaphragm and upper chamber in a straight manner. Then, join them with screws.

Conclusion

The serviced petrol pump is tested for correct measurement and pressure of pumping petrol and fixed in the engine.

AM_English_Practicals.indd 258 12/20/2019 5:50:03 PM