Reasons for Dismantling

1. RPM of the engine is decreased
2. BHP of the engine is decreased
3. Over Fuel Consumption
4. Reduced Compression Level in the3 cylinder
5. Outlet of Black Smoke through the Silencer
6. Consumption of Excess Lubrication Oil
7. Noisy Operation of the Engine
8. Company recommended period of inspection and servicing lapses



Fig 2. Piston and Connecting Rod Assembly

Dismantling

1. With all precautions dismantle the cylinder, Head, Crank case and keep the engine stand.
2. Mark the number on the connecting rod big end by using number punch
3. With the help of spanner ,remove the nuts of connecting big end bearing with the connecting rod and take the piston assembly through cylinder head.
4. Check if the bearing is depreciated and if so reconditionor replace the new bearing
5. Remove other piston assembly and keep it on a tray.

AM_English_Practicals.indd 264 12/20/2019 5:50:04 PM