6. Change the Piston Circlip if it is loose
7. Change Piston ring if it is depreciated
8. Use wooden mallet to fix piston assembly into the cylinder block



Fig 3. Piston and Connecting Rod Assembly

Assembling

Assemble in the reverse process of dismantling. Apply lubrication oil on the cylinder walls before fixing piston assembly to cylinder block.

Conclusion

Assemble the piston assembly in the Engine after servicing.

Note

Can do the piston assembly in the class room and practical exam with the aviability of different piston spares.

AM_English_Practicals.indd 265 12/20/2019 5:50:04 PM