Cleaning and Inspection

1. Clean the water pump parts by using degreaser after taking out of the engine
2. Remove the pump shaft slowly by using drift pin, copper hammer and wooden mallet.
3. Check the impeller is broken
4. Check if the pump shaft shake and replace it if the shake is more.
5. Change the bearing if it is too loose.

Precaution

Before fixing the water pump replace new water seal, oil seal and gasket.

Re-assembling

Assembling is the reverse process of dismantling in the correct order.

Conclusion

After dismantling, Inspecting and servicing the water pump is fixed in the given engine.

AM_English_Practicals.indd 268 12/20/2019 5:50:04 PM