Dismantling and Cleaning

1. Remove the diesel injector spindle, spring, washer, adjusting screw from injector and put on the tray.
2. Clean all the parts of injector using kerosene.
3. Again clean all the parts of injector using cloth.
4. Check any crack in the injector body and the nozzle.
5. If any crack is found change new injector.
6. Check any block in the inlet passage and leak off passage.
7. Check the bottom of the injector hole and also clean the carbon deposit.



Fig 3. Diesel Injector

Reassembling

Assemble is the reverse process of dismantling in the correct order.

Note

- After cleaning the diesel injector, again sent to the final inspection.
- The diesel injector is used after pressure test, spray test and leak off test are done.

Conclusion

After dismantling, inspecting and servicing fix the diesel injector in the engine.

AM_English_Practicals.indd 271 12/20/2019 5:50:05 PM