3. Ensure that all the parts of the appliance is fitted without leaving anything and connect the supply wire to the appliance.

	Open circuit	Short circuit	Earthing
Test lamp	Won't glow / Glow	Bright / Dim	Glow / Won't glow
Fault	Occurred / Not occurred	Occurred / Not occurred	Occurred / Not occurred

4. Measure the value of current flowing into the heating element.

Observation record

a. Voltage value of steam iron box = volts
b. Power of steam iron box = watts
c. Frequency of the iron box = hertz

d. Current value of the iron box = ampere
e. Resistance value of the heating element = ohms

Precautionary tips

1. Ensure that the iron box is disconnected from the main supply before handling it.
2. Select the proper range of instruments for measuring current and voltage.
3. While assembling the iron box, ensure that the heating element is placed in proper position with insulated intact.
4. Check the earth connection of the iron box properly fitted.
5. The electric iron box should not be allowed to get too heated. It will spoil the sole plate nickel plating and will get damaged.

Result

The method of dismantling the given Iron box and identify the parts, testing the Iron box, identifying and rectifying its faults, and assembling their on box was carried with proper tools. Now the Iron box is working in good condition.

BEE_ENG_Pratical.indd 179 12/27/2019 10:54:33 AM