1.5 HP pumps can deliver water up to a level of 275 feet.

When the compressor pump is running, the noise will be slightly higher.

When depreciation occurs in either shaft or bearing in the compressor, oil ring will get damaged and possibility of water gets mixed with oil. Hence, proper maintenance is essential.

4.4.4 Faults, causes and remedies of electric pump

Sl. No.	Faults	Causes	Remedies
1.	No movement in the pump.	1. Packing of the rope in the pump is tight.	1. Loose the tightened packing.
		2. The bearings are damaged.	2. Check the bearing and lubrication or change the bearing.
		3. No power supply.	3. Check whether the supply is live.
2	Pump is working. But water is not delivered.	1. No water in the suction pipe.	1. The suction pipe must be filled with water.
		2. Delivery pipe valve is closed.	2. Open the valve in the delivery pipe.
		3. Water level is below foot valve.	3. Increase the length of the suction pipe or increase the blow-up efficiency and set it below the water level.
3	Pump works on short time and deliver small quantity of water and then stopped.	1. Water leakage. Water level decreased in the suction pipe.	1. Leakage in the water pipe is rectified. The pipe length in the suction area should be increased.
		2. There is a defect in the electric motor and the starter.	2. Test the circuit of the electric motor and starter with the help of test lamp.
4.	Excessive vibration and noise in the pump	1. Alignment is changed.	1. Check alignment.
		2. Loose fitting in connecting screws.	2. Tight the screws.
		3. No lubrication in the bearing.	3. Apply the grease on the bearing or change the bearing.
		4. Shaft is slightly bent.	4. Change the shaft.
		5. Block in the impeller and friction is in the box.	5. Clean the rusts in the impeller and check before to fit.
5	Cracks in the impeller	1. Cracks due to soil or hard objects.	1. Clean it and then fix it.
		2. Holes on the top of the impeller	2. The holes should be closed with the washer.

BEE_ENG_Chapter_04.indd 69 12/27/2019 10:27:25 AM