1.8.6 Propeller Shaft

It is a type of long hollow shaft. This is located in between the gear box and differential. It transmits power from gear box to differential. It is shown Figure 1.8.6.



Figure 1.8.6 Propeller shaft

1.8.7 Front axle

Front wheels are coupled with front axle. Front axle carries the weight of the front part of the vehicle as well as facilitates steering and absorbs shocks due to road surface variations. It is shown Figure 1.8.7.



Figure 1.8.7 Front axle

1.8.8 Rear axle and Differential

Rear wheels are attached to the two ends of rear axle. The rear axle helps to turn the vehicle into the curved road. The differential gear in the center is cut by the speed of the cycle through the propeller shaft and then transported to 90° by wheels. It is shown Figure 1.8.8.



Figure 1.8.8 Rear Axle and Differential

1.8.9 Suspension system

The Spring Shock absorber has been connected to the front and back axles and helps to drive the vehicle smooth and slower from the vibrations in the road. It is shown Figure 1.8.9.



Figure 1.8.9 Suspension system

1.8.10 Steering system

The steering system operates on a very simple mechanism that directly transforms steering wheel rotation into straight line movement and helps in turn the vehicle as per the road. It is shown Figure 1.8.10.



Figure 1.8.10 Steering system

1.8.11 Braking system

Brakes are installed on the four wheels of the vehicle and work through mechanical connections, hydraulic

BAE_ENG_Chapter_01.indd 10 12/10/2019 10:47:17 AM