UNIT 10

Electrical System

Contents

10.0 Introduction
10.1 Battery
- 10.1.1 Types of Battery
- 10.1.2 Construction and Working Principle of Lead-Acid Battery
- 10.1.3 Battery Charging

10.2 Ignition System
- 10.2.1 Types of Ignition System
  - 10.2.1.1 Battery Coil Ignition System
  - 10.2.1.2 (a) Rotating Armature Type Magneto Ignition System
  - 10.2.1.2 (b) Rotating Magnet Type Magneto Ignition System
  - 10.2.1.3 Electronic Ignition System

10.3 Ignition Coil
10.4 Spark Plug
- 10.4.1 Types of Spark Plug
- 10.4.2 Ignition Switch and Key

10.5 Difference Between Battery Coil Ignition System And Magneto Ignition System
10.6 Distributor
10.7 Ignition Advance Mechanism
- 10.7.1 Types of Ignition Advance
  - 10.7.1.1 Vacuum Advance Mechanism

10.8 Engine Starting System
- 10.8.1 Starter Motor Drive Mechanism
  - 10.8.1.1 Bendix Drive Starting System
- 10.8.2 Starting Switch
- 10.8.3 Maintenance of Starter Motor

10.9 Charging System
- 10.9.1 D.C Generator (or) Dynamo
- 10.9.2 Cut Out Relay
- 10.9.3 Alternator

10.10 Lighting System
- 10.10.1 Important Lights in a Lighting System
- 10.10.2 Lighting Circuit In the Vehicle
- 10.10.3 Direction Indicator Lamps

10.11 Windscreen Wiper
10.12 Air Conditioning System
- 10.12.1 Construction and Working of Air Conditioning System

10.13 Troubleshooting, Causes and Remedies in the Ignition System
10.14 Troubleshooting, Causes and Remedies in the Starter Motor

CZT5DQ

BAE_ENG_Chapter_10.indd 184 12/20/2019 1:10:21 PM