Dismantling:

- Remove the universal joint bolts, center bed bolts, propeller shaft assembly and speedometer cables from the gear box.
- Remove clutch fork connection, gear box, clutch mounting bolts.
- Remove the gear box from the vehicle with the help of rope.
- Place the clutch in the Arber press and remove the clutch casing bolts.
- Remove pressure springs, release lever finger, pressure plate, clutch plate and etc…

Inspection:

- Inspect the clutch plate, pressure plate, linings, release lever, pressure spring, bolt, nuts, washer and etc… for any damage.
- Check the release lever spring tension it is more than 5 pounds replace by new one.
- Check the coil spring length before and after compression by using coil spring tester.
- Check the clutch free pedal play.

Assembling

- Assembling is the reversing process of dismantling.
- Place the clutch cover on the fly wheel and tighten the bolts. [Marking on clutch cover and flywheel should be in coincide].
- Check the clutch and gear box is working properly.

Result:

Thus the given clutch unit was dismantled, inspected and reassembled.

BAE_Practical.indd 227 12/20/2019 2:35:24 PM