Dismantling:

- Place the differential unit on the work bench.
- Remove the crown wheel.
- Remove the differential cage.
- Remove the sun gear, planet gears.
- Clean all the parts with kerosene.

Assembling:

Assembling is the reverse process of dismantling.

Result:

Thus the given differential was dismantled, inspected and reassembled.

BAE_Practical.indd 234 12/20/2019 2:35:28 PM