4. Clean the shock absorber by kerosene or water.
5. Loosen the outer tube nut and remove the foot value in the inner tube.
6. Remove the dust cover.
7. Remove the piston and valve assembly.

Inspection

- Inspect the upper eye and lower eye for any damage.
- Inspect the inner tube, outer tube, foot valve, cylinder, piston assembly and etc.
- Replace the defective parts by new one.

Assembling

Assembling is the reverse process of dismantling.

Result

Thus the given shock absorber was dismantled, inspected and assembled.

BAE_Practical.indd 249 12/20/2019 2:35:34 PM