

Dismantling

- Disconnect all the electrical connections.
- Disconnect the mounting bolts and nuts of the starting motor.
- Remove the starting motor from the vehicle and clean the outer portion.
- Place the starting motor on workbench.
- Remove the end cover.
- Remove the armature shaft.
- Dismantled the drive mechanism [Pinion, Bearing, Spring and etc.]

Inspection

- Clean all the parts.
- Inspect the armature, field winding, collar, sleeve unbalanced weight, pinion, drive mechanism, spring, bearing and etc… for any damage.

Insulation test

- An A.C. circuit containing two poles and one light switch is used for this test.
- One pole is connected with the armature coil and other is with the segment.
- 'ON' the light switch, if the light, glows change the brush plates.
- Connect one pole to the field terminals and other end with the vice, if the light, glows change the field.

BAE_Practical.indd 252 12/20/2019 2:35:37 PM