Dismantling

- Disconnect the electrical connections.
- Remove the belt from the dynamo pulley.
- Remove the mounting bolts and nuts.
- Place the generator on the work bench.
- Dismantling the following parts from the generator.

1. 'V' Pulley
2. End cover
3. Armature assembly
4. Commutator

Testing

Insulation test

Insulation test

- An A.C circuit containing two poles and one light switch is used for this test.
- One pole is connected with the armature coil and other is with the segment.
- 'ON' the light switch, if the light, glows change the brush plates.
- Connect one pole to the field terminals and other end with the vice, if the light, glows change the field.

Inspections

- Inspect the following parts.
- Armature winding, field coils, commutator, carbon brush, bearing, spring force, fan, 'V' pulley and etc…

Assembling

Assembling is the reverse process of dismantling.

Result

Thus the given dynamo was dismantled, inspected and assembled.

BAE_Practical.indd 257 12/20/2019 2:35:37 PM