3. Gear slip

Causes	Remedies
1. Fork in the gear shifting mechanism may not be working	Have to correct it
2. Dog clutch in the gearbox or synchronizer may have worn out	Need to change with a new one
3. Spring in the gear shifting mechanism may have loosened	Have to change the spring
4. Gears in the main shaft may have worn out	Need to change the gear with a new one

4. Lubricating oil leakages in the gear box

Causes	Remedies
1. Fault in the oil seal in the gear box	Have to change with a new oil seal
2. Lubricating oil level may be higher than the required amount	Need to discharge the excess oil
3. Oil leakage seal may be broken	Need to change with a new one
4. There may be loosen in bolts on the Gear box cap	Need to tighten it

3.9 Parts of the gear box

3.9.1 Gear box housing

The Box like arrangement where the bearings (which support the shafts) are mounted, filler plug with air vent hole, oil drain plug are present is called as the gear box housing. This box is generally made of cast iron as shown in Figure 3.9.1.



Figure 3.9.1 Gear box housing

3.9.2 Gear box input or clutch shaft

It is connected with the clutch plate at one end supported by the flywheel and a gear fitted at the other end. The view of input shaft can be seen in Figure 3.9.2.



Figure 3.9.2. Gear box input shaft

BAE_ENG_Chapter_03.indd 48 12/10/2019 11:28:17 AM