In this example code, we start with a position of 90º and jump briefly to 96º and back again each time the interval has been exceeded. Couple this movement with an event, say a timer that reminds us to get up and stretch every 10 minutes, and we have the beginnings of a really simple project. This could be adjusted to suit many applications, so rather than dwell too long on the hardware, let's look at the Servo functions.

Servo

Creating a new instance of the Servo library is quite a bit easier than with the previous library. All we need to do is use the Servo library name at the beginning of our sketch, followed by a name for our instance. In our example code this was done in the following line:

```
Servo servo;
```

And that's it for this line. Pick a name that might mean something to you whether its `servo1`, `rightSideServo`, or `george`—so long as the name is unique and each instance of the Servo library has been declared.

attach()

To use our servo, we need to bring out the `attach()` function to tell the library which pin we are using for this instance of the library. The syntax has the following two options:

```
name.attach(pin)
name.attach(pin, min, max)
```

In our example code this line took the form of

```
servo.attach(10);
```

Here we have set up servo to work with pin 10. Pins 9 and 10 seem like obvious choices because the servo function disables PWM on those pins anyway, although you are not limited to these pins.

Not all servos are created equal, however, and many will have minimum and maximum rotation angles that might be at odds with the Arduino defaults. Check the data sheet for your servo to see what these might be. If it's necessary, we can use the `attach()` function to define the minimum and maximum rotation angle specified in microseconds. The default minimum value is set to 544 for 0º and the maximum is set to 2400 for 180º. This will provide us with the greatest potential range of movement, but at the risk of possibly damaging our servo. If we were concerned about matching the specifications of our Hitec servo, we could specify the minimum and maximum as follows:

```
servo.attach(10, 900, 2100);
```

write()

Now with our servo set up, we need to do something with it. To make it move, we can use the `write()` function with the following syntax:

```
name.write(angle)
```

Simply specify an angle in degrees and the servo will move to that angle at the only speed it knows. In our sketch we wanted to start off at 90º and when the timer was triggered to move to 96º.