

Flash it right

Often the results we get using a flash aren't that great, and therefore knowing how to use the flash comes in handy. If the flash that you have in your digital camera can be detached, then a good idea would be to bounce the light on to the object in concern instead of directly focusing the flash on the object. Bouncing basically means using a reflective matter that will direct the flash light on to the object or simply tilting the flash in an angle such that it still directs the light on the object. Basically, this will ensure that the object doesn't appear too harsh with all the lights of the flash on. An aspect to remember if you use a reflective material is that the colour shouldn't be very bright or dark but should be a neutral colour such as white. Extreme colours tend to add on to the shades in the primary object being clicked.

For the Miscellaneous Occasion

And a few other tips that just about cover everything else ranging from ergonomics to usage strategies

Wear the neck strap

You may feel that the neck strap isn't too fancy and makes you conscious. However,



Another range from Kodak

er, it has a great benefit in the sense that by using your neck strap you ensure that

you don't accidentally drop your digital camera, especially when you are on an outdoor trip.

Adjusting the lens

Almost all digital cameras come with an automatic adjustable zoom lens. Therefore, you can either manually adjust the lens or if you have kept it on auto, you



And more from Kodak

can adjust the lens by pressing the shutter button by half while taking the snap. After that press the shutter button completely to take the picture.

One important thing to remember here is that the movement of lens in and out is governed by a motor, and by keeping it on auto would not only get the best focal length but you also save lots of battery power since this is one part of the camera which eats a lot more power than the LCD screen.

Use the power adapter

If the camera has come with the power adapter, always use it for transferring the image from the digital camera to the PC. This is all the more true if you happen to have a camera with the RS-232 (serial) connection, which has a slow transfer rate.

Saving on power

Always keep the power saving mode on. This makes your LCD screen consume less power. Almost all cameras have the

LCD off option, which can be used to save power while taking a photograph. Also, always remove the batteries if you are not going to use the camera for long, because if the batteries leak inside the damage can be quite expensive.

Optimising resolutions

Never keep the resolution to the maximum if you are only going to view it on the monitor, as this will unnecessarily take up more space on the camera. For such photographs, 1024x768 is the best resolution as you get good quality, without having to worry about pixelation.

However, if you are not too sure of how you are going to use the photograph, then it's better to use the highest resolution that the digital camera offers, since you can always use an image-editing tool to lower the resolution.

Part of standard accessories

If you are planning to go on a long trip,



And you thought Kodak made only conventional cameras!

the last thing you would want is to be away from civilisation and have your batteries run out. There goes the chance of capturing nature at its best. There are certain accessories that have to be part of your digital camera package.

These include batteries and chargers, especially if you are shooting with the LCD display on, which consumes a lot of

Ad will come