



Web cam conflicts, blue screens of death, unrelenting recycle bins, burning errors—we've got solutions for all of these and more...

Run in C

Q Recently, I bought an assembled PC comprising PIII 600 MHz, a KOB 810 DSMT Motherboard, 64 MB SD RAM and a 20 GB hard disk. It runs Windows 98 SE along with C and C++. I have installed the Turbo C++ 3.0 IDE. Whenever I try to compile or run any of my C or C++ programs, I get the error message saying "Unable to open include file 'stdio.h'". This happens with all the include files that I use.

Ajay Paul

Via e-mail

A C/C++ programs do not run unless all the #include files (header files) and library files are present. A single missing file will throw up an error message during compi-



Turbo C3

lation. Thus every compiler needs to know where the library files reside.

In Turbo C 3.0, the it is specified in the Options menu. Go to **Options > Directories**. Now you will be able to check the settings for the include and library folder. If they are incorrect, you have to correct the settings to the proper folder location.

The default location of Turbo C 3 is C:\tc, and that of include and library folder is C:\tc\include and C:\tc\lib, respectively. If you have not installed Turbo C in the default location then type the Directories settings as per the installation in your case. Now all your C/C++ programs will compile and execute properly.

Whats my comp's temperature?

Q Hi, I need to know a few things. What is the normal and maximum temperature for a hard disk? Is there any software utility to measure the temperature of the processor? How do I increase the sample/refresh rate of a PS/2 based optical mouse?

Carl D'Souza

Via e-mail

A For any hard disk, there are two temperature ranges to be taken care of—one while the hard disk is in operation, and the other when it is not. These temperatures vary from manufacturer to manufacturer. But the approximate range in operating condition is 2 to 55 degrees Celsius and non-operating is 40 to 65 degrees Celsius.

Most new motherboards have the capability of sensing the temperature of the installed hardware. In case you wish to see the temperature of the processor, you can download utilities such as the Motherboard Monitor from <http://www.3dnews.ru/download/tweak/mb/motherboard-monitor/>, which gives you a complete snapshot of the various temperatures of

the installed hardware.

To increase or decrease the refresh rate of a optical PS/2 mouse, go to **Control Panel > Mouse > Hardware > Select your mouse device > Properties > Advanced settings**. Now change the sample rate from within the drop box. Click OK and you're all set.

Web cam conflict

Q I have been facing a strange problem: I run Windows 98 and have only 8 GB of hard disk. Recently, I formatted my computer. It was running fine until I installed my Web camera. Now, when I restart the PC, it does not start in the Normal Mode; it always goes in the Safe Mode. If I try bringing it to the Normal Mode, it gives an error message saying "Please restart the computer". Is my hard disk about to crash?

Tushar Kapoor

Via e-mail

A First, check if your hard disk is working correctly by running ScanDisk in the Thorough mode. If the ScanDisk finds any bad sectors on the disk, the reliable solution is to replace your hard disk since you risk losing your valuable data.

But since the problem started after you installed your Web camera, it is likely that those drivers are corrupt or do not support Windows 98. Try downloading the drivers afresh from the company Web site. Before you install the new drivers, remember to uninstall the previous drivers completely. If the problem persists, browse through the