

MAINTENANCE

General Cleaning

If the printer is printing in streaks, and is smearing, it means there is excess ink in the carriage area. Follow these steps: Open the printer and remove the cartridges. Fold a letter-sized piece of paper in half, and then in half again, so that it is quartered.

Insert this paper into the regular feed slot. Gently move the paper to the left and to the right to remove excess ink under the carriage. Once the ink is removed, the printer should resume printing normally.

Call your technician at least once a year to get your printer cleaned thoroughly. There are parts that are impossible to get at without disassembling the machine. These need to be attended to only by a professional.

Printing Images

There are a few general rules that should be followed to print high-quality photographs. The first rule is to use specially designed photo papers. HP, Kodak and others have their own brand of reliable photo papers.

The second rule is to use a photo cartridge, provided your printer supports it.

The third rule is to choose the correct settings in the 'Print' dialog box. For this, click 'Printer properties', and set the print quality to the highest possible value. Choose 'photo paper', if you are using one as the paper type.

TROUBLESHOOTING

Inkjet Printers

If horizontal or vertical lines appear on your printouts, run the print head-cleaning utility three or four times, one after the other. Check the paper if the printouts appear faint. The paper might be damaged, old, or loaded incorrectly.

If you use special paper, such as photo paper, make sure you are printing on the correct side. Check the printer's manual for information regarding the compatibility of

the paper.

To unblock a cartridge's print head, place the print head in a shallow bowl of hot water for 20 to 30 minutes. This will soften the dried ink so that it flows through the print head. You should see the ink bleed out. If this doesn't solve the problem, repeat the procedure once again.

Next, insert the cartridge into the printer, and run the print head-cleaning utility. If soaking the cartridge in hot water hasn't cleaned and dissolved the dried ink, you should place the print head of the cartridge in a shallow bowl containing an equal mixture of very hot water and bleach—just enough to cover the print head. Keep the head in this mixture for two or three minutes.

This hydrates the dried ink, making it flow through the print head and you should see the dried ink flow out. Now, you can insert the cartridge into the printer, and run the printer's print head-cleaning utility. This should solve your problem.

Economic printing

To save toner or ink, it's a good idea to keep your default print settings to Draft, or EconoMode—especially for those of us who don't need high-quality prints all the time. To do this, go to **Control Panel > Printers**, and choose the printer properties by right-clicking the printer icon.

You can always change these settings temporarily through the Print dialog of the application that you are printing from. For example, when printing from Microsoft Word, just click on Properties and change the mode to Normal or Photo.

You should also save paper by printing on both sides of the page. If your printer doesn't support two-sided printing, feed the paper manually, and flip it over to print on the other side. You can also use software such as FinePrint (www.fineprint.com) for double-sided prints. Don't forget to set the page margins to the least value supported. It allows more matter to be printed on fewer pages.





Julia

The i255 is very lightweight at just 2.3 kgs, with a compact frame of 385mm*199mm*162mm. That makes it the ideal choice for homes and small offices.

TRUE 4800 DPI RESOLUTION • 5 PI INK SYSTEMS • MICROFINE DROPLET TECHNOLOGY • VIVID PHOTO TECHNOLOGY • 17 PPM MONO/9 PPM COLOR • LOW ON RUNNING COST • 3 YEARS WARRANTY
Call Canon at 1600 33 33 66 or visit www.canon.co.in



Rediffusion DYE/CANON/197