



Guide to discover

Overhaul and improve your Twitter feed using Twitter's "Discover" tab to better suite your taste. Learn how: <http://bit.ly/1JsJi2b>



Lovejoy gone

Say Sayonara to Comet Lovejoy as it won't be visible to people from earth for the next 8,000 years. <http://dgit.in/LoveIsGone>

DIY: Rejuvenate your XBox 360 Controller

Is your old XBox 360 controller not as snappy as it used to be? Are the buttons sticky and unresponsive at times? Have the analog sticks lost their grip that make you slip during a critical manoeuvre in a game? Follow this guide to breathe fresh life into your controller.

Siddhant Sharma
readersletters@digit.in

Left, Right, A, X, Up, Down...Ohh! Combo Failed! Don't you hate it when something like this happens when you're about to beat a buddy in Mortal Kombat with a fatality? Or in FIFA when you've tackled a player, took possession of the ball, dribbled past a midfielder, defender one, defender two, tried to set up a trick shot for the goal but the trick went wrong because of an unresponsive button causing you to shoot the ball way wide of goal? If yes, well it's time for you to take a long and hard look at your good old XBox 360 controller and fix it so that you can beat that wide grin off your smug friends face. We say fix it yourself because if it's out of warranty, you don't have much choice anyway do you? Apart from buying a new one or buying the new XBox One controller which if you don't already know, isn't quite budget friendly.

Using this guide, you'll be able to open, clean, fix and make your controller work almost as good as new. Regardless of whether you own a wired or a wireless XBox 360 controller, this workshop will work for both of them. So let's get cracking.

What we'll need

- XBox 360 controller (wired or wireless any);
- T8 Torx Screwdriver;
- Tissues or a soft cloth;
- Any non-conductive cleaning fluid or rubbing alcohol;



- Cotton ear buds;
- Baking soda.

Starting up

Make sure that you are in a well lit area and place the controller on a flat surface like a desk or table and flip it so that it lies on its front. Now notice the number of spots for screws. You'll be able to spot



six screw areas easily but there is one more screw that is hidden apart from the other six. If you have a wired controller, you should see a sticker strip of barcode at the back of the controller. Remove this sticker to expose the screw location. As for wireless controllers, you'll have to open the battery compartment at the back of the

controller, remove the battery and then you'll see the sticker strip that you'll need to peel off to reveal the screw beneath.

Unscrew and open

Since you've spotted the seven screws, you'll see that they are 9.3 mm T8 Security Torx screws that help keep the controller together. Use a T8 Torx screwdriver to unscrew and remove all the seven screws. Keep the screws at a safe place so that you don't lose any. Once that is done, in order to open the controller, you'll have to pry it a bit from the seam between the front and the rear part of the controllers casing. Start prying from the bottom part of the controller and you'll see that the casing opens up from near the 2.5mm headphone jack at the bottom of the controller. Now slowly lift



the casing grasping the back part of the controller (from the battery compartment side in wireless controllers) until it separates from the front casing completely.

Remove Vibration Motors

Set aside the back casing of the controller and rest the front part of the