



Apple iPhone 14 Pro Max

Comes at a cost... A big one!

Satvik Pandey | satvik@digit.in



First off... The Display

The Pro line of phones feature the new dynamic island, leaving the non-Pro models with the notch design on the front. When opening an iPhone, the first part that goes off is the screen. On the iPhone 14 Pro Max, to open the screen, all you need to do is remove the two screws next to the lightning port on the bottom of the phone. Then, you will need to heat the screen to soften the glue holding this glass sandwich together. After the glue has been softened up, take the suction cup, pull gently, and insert the spudger in the gap that shows up. Keeping the tip of the spudger right on edge, slice off the remainder of the glue, and voila! You have the iPhone 14 Pro Max's screen removed!



Do I hear you right?

After the battery, one of the first parts that tend to fail is the earpiece speaker. The iPhone 14 Pro Max does not seem to be susceptible to such an issue. However, if you do need to replace your earpiece speaker, then you can start by removing the screen using the steps mentioned above. After that, head over to the top left corner of the phone, where the earpiece speaker lies. It is held by two screws that can be undone using a simple Phillips head screwdriver. Once that is done, take the spudger and gently pry up the speakers.

