



Sony DualSense Controller v2

Tedious but interesting

Satvik Pandey | satvik@digit.in

Sony's entrant into the world of consoles, the PlayStation 5, after launch took no time to become a fan favourite. Such was the hype that two years after the launch, the console was running out of stock for the longest time after launch. Now, as the product moves into the middle stages of its life cycle, people have started experimenting with their hardware, especially controllers, modifying them and going in for self-repair using the parts that can be found online instead of sending it in for repair to Sony's authorised service centres. Some are also opening it to explore the insides of their controllers. So, if you are someone looking to tinker with your controller or just someone looking to explore the insides of the Sony DualSense Controller v2, then here's a look at its step-by-step teardown.



Off goes the trim

The first thing that you need to remove when opening your DualSense Controller v2 is the trim. For this, you need the opening pick. Start by unclipping the right end of the middle trim. Gently slide the pick in and lift it with minimal force to undo the clip, moving towards the centre of the trim as you open each clip. Now, move to the other side, and repeat the same. Once both sides have been freed, lift the trim off. When doing this, make sure you are lifting the bottom edge first to release the rest of the clips. That will release the front trim, and you can proceed with the rest of the steps.



Release L1 and R1

Once you are done removing the trim off the controller, next you need to remove the L1 and R1 buttons. For this, you will need to insert the flat end of the spudger into the gap above the L1 button and lift it gently. The trigger button should come right off. Repeat the same for the R1 button.