



...and now, the rear end and battery

After removing the trim and the L1 and R1 triggers, the next step is to remove the rear casing of the controller. To do that, all you need to do is release the clips on either side of the headphone jack. Use the pointed end of the spudger for this. Once they have been released, you can take off the rear case. Now, gently lift the battery from its position and locate the three-pin connector that is attaching it to the main board. Use the tweezers to disconnect it from the motherboard. And voila! The battery is off.



Mic check... Wait, there is none!

Well, there is a mic, but after this step, it won't be in. Once you have taken off the battery, next in line is the lower microphone. It is held inside a bracket, so first you will need to remove it using the spudger. Do not use a lot of force, else the casing holding the mic in place might get damaged. After you have taken it out of the casing, use the tweezers to disconnect the ribbon cable that connects it to the motherboard. And, while you are at it, also unscrew the battery bracket using a Phillips screwdriver. Lift it off to expose the motherboard and all the connectors attached to it.



Lift off

No, we are not launching any rockets now. Once all the trigger assemblies have been removed and the microphone and touchpad have been disconnected, all that is left is the motherboard. To remove that, you just need to lift it from its place. Be mindful of the joysticks. Do not pull it all the way, as there are some cables still connected. Remove the light guides using the pointed edge of the spudger and giving a slight lift. Now, use the Phillips driver to undo the two screws holding the midframe assembly in place. Next, gently lift the motherboard and the midframe off.



No more triggers

The next step in the process is to remove the trigger assembly. This can be done by removing the ribbon cables connecting the ribbon cable connecting the assembly to the motherboard. Use the tweezers and pull away the connectors. Remember to grab the pull tabs, not the cable itself. It is recommended that you start by disconnecting the right trigger assembly first. Once both the ribbon cables have been removed, you can also remove the upper microphone ribbon cable (orange), and the touchpad (blue), both of which are connected to the motherboard.



What more?

Now, all that you have left is the touchpad and buttons. First, remove the touchpad by unscrewing the one Philips head screw holding it in place. Be careful; there are a couple of clips holding it in place. Remove them. Next, use the tweezers to remove the microphone and the attached ribbon cable. Once that is off, using your fingers, or to be safe, the tweezers, remove them buttons, and you're done!

