

pause for. The time is specified in milliseconds (1 second = 1000 milliseconds).

## Serial Communication

The Arduino™ ecosystem allows serial communication using the serial class. The library for serial communication is built into the default Android installation.

- `Serial.begin ()`

Before data is sent over the serial communication port, the serial port needs to be initialised. The syntax for initialisation is:

- `Serial.begin (9600)`

This initialises the serial port at a baud rate of 9600 bits per second. The Digital Pins 0 (Receive - RX) and 1 (Transmit - TX) are used for serial communication. These pins can't be used for any other other task when using them for serial communication. The Arduino™ Mega has three additional serial ports: Serial1 on Pins 19 (RX) and 18 (TX), Serial2 on Pins 17 (RX) and 16 (TX) and Serial3 on Pins 15 (RX) and 14 (TX).

## Serial.print ()

After beginning the serial communication, data can be transmitted using the print command, whose syntax is:

- `Serial.print (data);`

where 'data' is the data to be transmitted over Pin 1 of the Arduino™ board. This command sends the data to the Arduino™ Serial Monitor.

To start on a new line after printing the data, use the following command

## Serial.println (data);

Code:

- ```
• void setup () {
•   Serial.begin (9600);
• }
• void loop () {
•   Serial.println ("1) This line will appear on top");
•   Serial.print ("2) This line will appear below line no
1")
• }
```

## Serial.available

When receiving data using serial communication, you need to verify that