

select and alter many features with ease. In order to bring up the Config Tool later on all that is needed is the “sudo raspi-config” in the command prompt. You can ensure that this config menu isn’t the default boot up screen by checking the Enable Boot to Desktop option. The next step to when starting up for the first time is to expand the root partition on your storage. Since the default settings don’t give access to the whole memory card you need to go to the Expand Filesystem option. You can use this to gain access to the whole of the memory card’s storage.



The boot interface is easy to navigate and implement.

Next you need to change the default username and password from “pi” and “raspberrypi” respectively to whatever you wish. This is accomplished by using the “Change User Password” guide. You can also

set up Localisation Option such as location, date, timezone etc and custom language and keyboard layouts. Once you are satisfied with all the steps of the start up so far you need to finalise changes and reboot. To do this just click on Finish in the Config Tool and you will be prompted to reboot. Say yes.

Now to connect to the internet you need to get your network details. These can be obtained from your default Windows PC which is on the network and selecting Start>Run>“cmd” - this will bring up the Command Prompt. Here, enter the command “ipconfig” and look at the output - it will display your IP address and Default Gateway details. Note these down as they will be needed for the Raspberry Pi.

Coming back to the Pi you need to open the Terminal window by entering the command: `sudo nano/etc/network/interfaces`. Here change the starting line of “eth0” to “static” in the place of “dhcp”. The last three digits (octet) of the IP address should be different from what you noted down in Windows - and it shouldn’t be used by any other device. Next you need to test your connection between the Windows PC and the Raspberry Pi. To do this you need to start the Command Prompt in Windows and run the command: `ping [Pi IP Address]`. If the connection is correct you will see a reply with no connection timeout errors.